

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	BROTHER	
	BROTHER HL 6180, 3370, MFC 8950, 8710, DCP 8155 TN 720, 750, 780	
•	Absolute Black® toner for use in Brother TN 200, HL 720, 85g	4962
•	Absolute Black® toner for use in Brother TN 200, HL 720, 22 lb. (10 kg) bag	5766
•	Unidrum™ VERTICAL gears for use in Brother TN 200, HL 720, DR 200	10187
•	Developer Roller Cover for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 10 pack	17762
•	Name Plate Cover for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 100 pack	17763
•	High Yield Reset Lever Gear with Spring and Fill Plug for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 10 pack	17764
•	Retaining Plate and Fill Plug for use in Brother TN 720, 750, 780, HL 6180, 3370, 3390, MFC 8950, 8710, DCP 8155, 8110, 100 pack	18265
•	Retaining Plate and Fill Plug for use in Brother TN 720, 750, 780, HL 6180, 3370, 3390, MFC 8950, 8710, DCP 8155, 8110, 100 pack	18485
•	Name Plate Cover for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 100 pack	18486
•	Developer Roller for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 10 pack	18862
	BROTHER MFC 3800, 4800, 6800, TN 250	
•	Absolute Black® toner for use in Brother TN 250, MFC 3800, 4800, 6800, 22 lb (10 kg) bag	9948
•	Absolute Black® toner for use in Brother TN 250, MFC 3800, 4800, 6800, 85g	9285
	BROTHER HL 2700, MFC 9420	
•	Developer roller Shipping cover for use in Brother HL 2700, 2400 CN, MFC 9420 CN, 10 pack (special order)	11378
•	X-Generation® Black toner for use in Brother HL 3450, 3400, 2700, 2600, MFC 9420 CN, 22 lb (10 kg) bag	17103
•	X-Generation® Cyan toner for use in Brother HL 3450, 3400, 2700, 2600, MFC 9420 CN, 22 lb (10 kg) bag	17104
•	X-Generation® Magenta toner for use in Brother HL 3450, 3400, 2700, 2600, MFC 9420 CN, 22 lb (10 kg) bag	17105
•	X-Generation® Yellow toner for use in Brother HL 3450, 3400, 2700, 2600, MFC 9420 CN, 22 lb (10 kg) bag	17106
	BROTHER HL 3170, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245	
•	X-Generation® Black toner for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 22 lb (10 kg) bag	18520
•	X-Generation® Cyan toner for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 22 lb (10 kg) bag	18521
•	X-Generation® Magenta toner for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 22 lb (10 kg) bag	18522
•	X-Generation® Yellow toner for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 22 lb (10 kg) bag	18523
•	X-Generation® Black toner for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 60g (2,500 pages)	18529
•	X-Generation® Cyan toner for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 60g (2,200 pages)	18530
•	X-Generation® Magenta toner for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 60g (2,200 pages)	18531
•	X-Generation® Yellow toner for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 60g (2,200 pages)	18532
•	Reset lever (flag gear) & spring (SY) for use in Brother HL 3170, 3150, 3140, MFC 9130, 9340 (TN 221, 241, 251, 261, 291) 10 pack	18549
•	Developer roller cover for use in Brother HL 3170, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 10 pack	18605
•	Drum unit cover for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 10 pack	18606
•	Name plate for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 100 pack	18621
•	Reset lever (flag gear) & spring (HY) for use in Brother HL 3170, 3150, 3140, MFC 9130, 9340 (TN 225, 245, 255, 265, 296) 10 pack	18764
•	Filler cap for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 100 pack	18836
•	Universal Color Conversion for use in Brother HL 3170, 3150, 3140, MFC 9340, 9330, 9130, TN 221, 225, 241, 245, 100 pack	18837
	BROTHER HL 5340, 5350, 5370, MFC 8480, TN 650, 3280, 3290	
•	Absolute Black® toner for use in Brother TN 650, 3280, 3290, HL 5340, 5350, 5370, 5380, MFC 8480, 200g (8,000 pages)	13913
•	Absolute Black® toner for use in Brother TN 650, 620, 3230, 3250, 3280, 3290, HL 5340, 5350, 5370, 5380, 22lb (10kg) bag	14750
•	Reset lever (flag gear) for use in Brother TN 650, 3280, 3290, HL 5340, 5350, 5370, 5380, 10 pack	13916
•	Absolute Black® toner for use in Brother TN 650, 200g	16439
	BROTHER HL 4140, 4150, 4570, MFC 9460, 9560 TN 315, 325, 328	
•	Reset lever and Spring (High Yield) for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560 (TN 315, 325, 345, 395), 10 pack	16500
•	Reset Lever and Spring (E H Y) for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560 (TN 315, 325, 328, 345, 348, 395), 10 pack	16611
•	X-Generation® Black toner for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560, 9660, TN 315, 348 (6,000 pages)	16682
•	X-Generation® Cyan toner for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560, 9660, TN 315, 325, 395 (3,500 pages)	16683
•	X-Generation® Magenta toner for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560, 9660, TN 315, 325, 395 (3,500 pages)	16684
•	X-Generation® Yellow toner for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560, 9660, TN 315, 325, 395 (3,500 pages)	16685
•	Developer roller cover for use in Brother HL 4140, 4150, 4570, TN 310, 315, 325, 340, 348, 395, 10 pack	16693
•	X-Generation® Black toner for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560, 9660, TN 315, 325, 348, 395 22lb (10kg) bag	16945
•	X-Generation® Cyan toner for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560, 9660, TN 315, 325, 348, 395, 22lb (10kg) bag	16946
•	X-Generation® Magenta toner for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560, 9660, TN 315, 325, 348, 395 22lb (10kg) bag	16947
•	X-Generation® Yellow toner for use in Brother HL 4140, 4150, 4570, MFC 9460, 9560, 9660, TN 315, 325, 348, 395 22lb (10kg) bag	16948
	BROTHER HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, TN 750, 720, DR 720	
•	SuMMiT® drum with VERTICAL gears for use in Brother DR 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110	17695
•	Developer Roller Cover for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 10 pack	17762
•	Name Plate Cover for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 100 pack	17763
•	Reset Lever Gear with Spring & Fill Plug (HY) for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 10 pack	17764
•	Retaining Plate and Fill Plug for use in Brother TN 720, 750, 780, HL 6180, 3370, 3390, MFC 8950, 8710, DCP 8155, 8110, 100 pack	18265
•	Retaining Plate and Fill Plug for use in Brother TN 720, 750, 780, HL 6180, 3370, 3390, MFC 8950, 8710, DCP 8155, 8110, 100 pack	18485
•	Name Plate Cover for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 100 pack	18486
•	Developer Roller for use in Brother TN 750, 720, HL 5470, 5450, MFC 8950, 8710, DCP 8155, 8110, 10 pack	18862
•	Absolute Black® toner for use in Brother TN 750, HL 6180, 5470, 5450, 5440, MFC 8910, 8710 (8,000 pages)	18942
•	Absolute Black® toner for use in Brother TN 750, HL 6180, 5470, 5450, 5440, MFC 8910, 8710, 22 lb (10 kg) bag	18948
	BROTHER HL 3450, 3400, 2700, 2600, MFC 9420	
•	X-Generation® Black toner for use in Brother HL 3450, 3400, 2700, 2600, MFC 9420 CN, 22 lb (10 kg) bag	17103
•	X-Generation® Cyan toner for use in Brother HL 3450, 3400, 2700, 2600, MFC 9420 CN, 22 lb (10 kg) bag	17104
•	X-Generation® Magenta toner for use in Brother HL 3450, 3400, 2700, 2600, MFC 9420 CN, 22 lb (10 kg) bag	17105
•	X-Generation® Yellow toner for use in Brother HL 3450, 3400, 2700, 2600, MFC 9420 CN, 22 lb (10 kg) bag	17106
	CANON®	
	CANON IMAGERUNNER 330, 400	
•	Unidrum™ F with gears for use in Canon Imagerunner 330, 400	7316
•	Unidrum™ with gears for use in Canon Imagerunner 330, 400	12896

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Wiper blade for use in Canon Imagerunner 330, 400	14593
	CANON IMAGERUNNER 550, 600 Absolute Black® toner for use in Canon Imagerunner 600, 550, 22lb (10kg) bag	17093
	CANON IMAGERUNNER 1018, 1019, 1020, 1022, 1023, 1024, 1025 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE) SuMMIT® drum with gears for use in Canon Imagerunner 1018, 1019,1020, 1022, 1023, 1024, 1025 PCR for use in Canon Imagerunner 1018, 1019, 1020, 1022, 1023, 1024, 1025, 10 pack Absolute Black® toner for use in Canon Imagerunner 1018, 1019, 1020, 1022, 1023, 1024,1025, 22 lb (10 kg) bag	17488 17807 17843
	CANON IMAGERUNNER 1600, 2000, 2010 Absolute Black® toner for use in Canon IR 1600, 2000, 2010, 440g Black Mag roller sleeve for use in Canon IR 1600, 2000, 2010, 10 pack Clear Seal™ adhesive for use in Canon IR 1600, 2000, 2010, 50 pack Unidrum™ with gears for use in Canon IR 1600, 2000, 2010 (21,000 pages) X-Generation® Wiper blade for use in Canon IR 1600, 2000, 2010	6027 7161 6949 12716 17933
	CANON IMAGERUNNER 2016, 2018, 2020, 2022, 2025, 2030 Unidrum™ with gears for use in Canon IR 2016, 2020 (55,000 pages) Wiper blade for us ein Canon IR 2016, 2020	12892 12898
	CANON IMAGERUNNER 2200, 2300, 2800, 3300 Unidrum™ F with gears for use in Canon IR 2200, 2800, 3300 Wiper blade for use in Canon IR 2200, 2800, 3300 SuMMIT® drum with gears for us ein Canon IR 2200, 2800, 3300 Absolute Black® toner for use in Canon IR 2200, 2800, 3300, 795g	7056 10068 12715 16710
	CANON IMAGERUNNER 2525, 2520 SuMMIT® drum with gears for use in Canon Imagerunner 2525, 2520	16774
	CANON IMAGERUNNER 6000, 5000 Absolute Black® toner for use in Canon IR 6000, 5000, 22 lb (10 kg) bag Heat roller for Canon IR 5000, 6000	11038 16241
	CANON IMAGERUNNER C 3380, 2880, 2550, 3480 Absolute Black® toner for use in Canon IR C 3380, 2880, 2550, 3480, 575g Absolute Cyan™ toner for use in Canon IR C 3380, 2880, 2550, 3480, 260g Absolute Magenta™ toner for use in Canon IR C 3380, 2880, 2550, 3480, 260g Absolute Yellow™ toner for use in Canon IR C 3380, 2880, 2550, 3480, 260g	13003 13004 13005 13006
	CANON IMAGERUNNER C 3100, 3170 Black toner for use in Canon IR C 3100, 3170, 510g Cyan toner for use in Canon IR C 3100, 3170, 180g Magenta toner for use in Canon IR C 3100, 3170, 180g Yellow toner for use in Canon IR C 3100, 3170, 180g	11110 11111 11112 11113
	CANON IMAGERUNNER C 3380, 2880, 2550, 3480 Absolute Black® toner for use in Canon IR C 3380, 2880, 2550, 3480, 575g Absolute Cyan™ toner for use in Canon IR C 3380, 2880, 2550, 3480, 260g Absolute Magenta™ toner for use in Canon IR C 3380, 2880, 2550, 3480, 260g Absolute Yellow™ toner for use in Canon IR C 3380, 2880, 2550, 3480, 260g	13003 13004 13005 13006
	CANON EP 105, MF 7280, 7460, 7470, 7480 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE) Absolute Black® toner for use in Canon EP 105, MF 7280, 7460, 7470, 7480, 22 lb (10 kg) bag Absolute Black® toner for use in Canon EP 105, MF 7280, 7460, 7470, 7480, 535g Clear Seal™ adhesive with foam for use in Canon EP 105, MF 7280, 7460, 7470, 7480, 50 pack Mag roller for use in Canon EP 105, MF 7280, 7460, 7470, 7480, 10 pack SuMMIT® drum with gears for use in Canon EP 105, MF 7280, 7270, 7260, 7240	11591 11590 11595 11596 11592
	CANON GP 200 Drum for use in Canon GP 200 F Unidrum™ with gears for use in Canon GP 200 Wiper blade for use in Canon GP 200	7411 12895 12897
	CANON GP 40 Absolute Black® toner for use in Canon GP 40, 22 lb (10 kg) Drum with gears for use in Canon GP 40	7235 7181
	CANON NP 6012, 6016 Unidrum™ F with gears for use in Canon NP 6012, 6014 Unidrum™ S with gears for use in Canon NP 6012, 6014 Wiper blade for use in Canon NP 6012, 6118, 6412, 7120, 7130, C 120, 130, 10 pack	11397 12540 8764
	CANON NP 1510, 1215, 2120 Unidrum™ F w/gears for use in Canon NP 1215, 2020, 2120(30,000 Pages) Absolute Black® toner for use in Canon NP 1510, 1215, 2120, 500g X-Generation® Wiper blade for use in Canon NP 1510, 1215, 2020, 2120 Unidrum™ with gears for use in Canon NP 1215, 2020, 2120 (30,000 Pages) Absolute Black® toner for use in Canon NP 1510, 1215, 2120, 500g Absolute Black® toner for use in Canon NP 1510, 1215, 2120, 22 lb. (10 kg) bag	102 104 105 12539 16045 16564
	CANON NP 3030, 3050, 4050, 4080 Wiper blade for use in Canon NP 3325, 3030, 4050, 4835, 10 pack	7141

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	CANON NP 6030, 6025, 6330, NPG 7	
	Absolute Black® toner for use in Canon NP 6030, 6025, 6330, NPG 7, 22 lb (10 kg) bag	8295
	Unidrum™ drum for use in Canon NP 6030, 6025, 6330 (60,000 pages)	8545
	Unidrum™ F with gears for use in Canon NP 6030, 6025, 6330 (60,000 pages)	7409
	CANON NP 6045, 6050, 6060, 6085	
	Absolute Black® toner for use in Canon NP 6045, 6050, 6060, 6085, 1,500g refill pouches	11746
	DELCOP AVANTI®	
	DELCOP AVANTI 2600, 2650, 2690	
	Absolute Black® toner for use in Delcop Avanti 2600, 2650, 2690, 180g (5,500 pages)	17939
	Drum unit cover for use in Delcop Avanti 2600, 2650, 2690, 10 pack	17942
	Smartchip™ for use in Delcop Avanti 2600, 2650, 2690 (5,500 pages)	17934
	Unidrum™ with gears for use in Delcop Avanti 2600, 2650, 2690	17940
	DELL®	
	DELL 2335, 2355 MFP	
•	Smartchip™ for use in Dell 2335, 2355 MFP (330-2208) (3,000 pages)	14793
•	Absolute Black® toner for use in Dell 2335, 2355 MFP, 90g (3,000 pages)	14807
•	SuMMIT® drum with gears for use in Dell 2335, 2355 MFP	14810
•	Wiper Blade for use in Dell 2335, 2355 MFP, 10 pack	14915
•	X-Generation® toner for use in Dell 2335, 2355 MFP, 22 lb (10 kg) bag	15579
•	Unidrum™ with gears for use in Dell 2335, 2355 MFP	15770
•	X-Generation® toner for use in Dell 2335, 2355 MFP, 90g (3,000 pages)	15884
•	X-Generation™ toner for use in Dell 2355 MFP, 285g (10,000 pages)	16656
•	Absolute Black® toner for use in Dell 2355 MFP, 280g (10,000 pages)	16657
•	Smartchip™ for use in Dell 2355 MFP (331-0611, R2W64) (10,000 pages)	16658
•	Smartchip™ for use in Dell 2335, 2355 MFP (330-2208) (3,000 pages), 10 pack	16922
•	X-Generation® Wiper Blade for use in Dell 2335, 2355 MFP, 10 pack	18119
•	PCR roller for use in Dell 2335, 2355 MFP, 10 pack	18603
•	Developer roller for use in Dell 2335, 2355 MFP 10 pack	18604
•	Absolute Black® toner for use in Dell 2335, 2355 MFP, 22lb (10kg) bag	18734
	DELL B 2375 MFP	
•	Absolute Black® toner for use in Dell B 2375 MFP, 285g (10,000 pages)	18964
•	SuMMIT® drum with gears for use in Dell B2375 MFP	18970
•	Smartchip™ for use in Dell B 2375 MFP (593-BBBJ,C7D6F,8PTH4) (10,000 pages)	18978
•	PCR roller for use in Dell B2375 MFP, 10 pack	18979
•	Developer roller for use in Dell B2375 MFP, 10 pack	18980
•	X-Generation® Wiper Blade for use in Dell B2375 MFP, 10 pack	18981
	DELL 5130 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
•	Absolute Black® toner for use in Dell 5130 cn (18,000 pages)	16705
•	Absolute Cyan™ toner for use in Dell 5130 cn (12,000 pages)	16706
•	Absolute Magenta™ toner for use in Dell 5130 cn (12,000 pages)	16707
•	Absolute Yellow™ toner for use in Dell 5130 cn (12,000 pages)	16708
•	Smartchip™ Black for use in Dell 5130 cn (330-5086)(18,000 pages)	17007
•	Smartchip™ Cyan for use in Dell 5130 cn (330-5850)(12,000 pages)	17008
•	Smartchip™ Magenta for use in Dell 5130 cn (330-5843)(12,000 pages)	17009
•	Smartchip™ Yellow for use in Dell 5130 cn (330-5852)(12,000 pages)	17010
•	Smartchip™ for drum unit Black for use in Dell 5130 cn (330-5849)(50,000 pages)	18390
•	Smartchip™ for drum unit Cyan for use in Dell 5130 cn (330-5847)(50,000 pages)	18391
•	Smartchip™ for drum unit Magenta for use in Dell 5130 cn (330-5855)(50,000 pages)	18392
•	Smartchip™ for drum unit Yellow for use in Dell 5130 cn (330-5853)(50,000 pages)	18393
•	Absolute Black® toner for use in Dell 5130 cn, 22 lb (10 kg) bag	18670
•	Absolute Magenta® toner for use in Dell 5130 cn, 22 lb (10 kg) bag	18672
•	Absolute Yellow® toner for use in Dell 5130 cn, 22 lb (10 kg) bag	18673
•	X-Generation® Black toner for use in Dell 5130 Cn (18,000 pages)	18856
•	X-Generation® Cyan toner for use in Dell 5130 Cn (12,000 pages)	18857
•	X-Generation® Magenta toner for use in Dell 5130 Cn (12,000 pages)	18858
•	X-Generation® Yellow toner for use in Dell 5130 Cn (12,000 pages)	18859
•	X-Generation® Black toner for use in Dell 5130 cn, 22 lb (10 kg) bag	18863
•	X-Generation® Cyan toner for use in Dell 5130 cn, 22 lb (10 kg) bag	18864
•	X-Generation® Magenta toner for use in Dell 5130 cn, 22 lb (10 kg) bag	18865
•	X-Generation® Yellow toner for use in Dell 5130 cn, 22 lb (10 kg) bag	18866
•	SuMMIT® drum gearless for use in Dell 5130, C 5765 MFP (50,000 pages)	18960
	DELL B 1260, 1265 MFP	
•	Smartchip™ for use in Dell B 1260, 1265 dnf (331-7328, RWXNT) (2,500 pages)	17650
•	X-Generation® toner for use in Dell B 1260, 1265 MFP, 95g (2,500 pages)	17670
•	SuMMIT® drum with gears for use in Dell B 1260, 1265 MFP	17672
	DELL 1130, 1133 MFP	
•	Unidrum™ with gears for use in Dell 1130, 1133 MFP, 1135 MFP	15713
•	PCR roller for use in Dell 1130, 1133 MFP, 1135 MFP 10 pack	15715
•	Developer roller for use in Dell 1130, 1133 MFP, 1135 MFP, 10 pack	15716
•	Doctor blade for use in Dell 1130, 1133 MFP, 1135 MFP, 10 pack	15717
•	Wiper blade for use in Dell 1130, 1133 MFP, 1135 MFP, 10 pack	15769
•	ASIC Encrypto Smartchip™ for use in Dell 1130, 1133 MFP, 1135 MFP (330-9523)(2,500 pages)(US)	16347
•	ASIC Encrypto Smartchip™ for use in Dell 1130, 1133 MFP, 1135 MFP (330-9524)(1,500 pages)(US)	16519
•	Doctor blade sealing foam for use in Dell 1130, 1133 MFP, 1135 MFP, 100 pack	16985
•	X-Generation® toner for use in Dell 1130, 1133 MFP, 1135 MFP, 95g (2,500 pages)	17030

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	X-Generation® toner for use in Dell 1130, 1133 MFP, 1135 MFP, 22lb (10kg) bag	17883
•	SuMMIT® OPC Drums with gears for use in Dell 1130, 1133 MFP, 1135 MFP	18878
•	PCR roller for use in Dell 1130, 1133 MFP, 1135 MFP, 10 pack	18888
DELL 2150 CN, 2155 MFP		
•	Absolute Black® toner for use in Dell 2150 cn, 2155 MFP, 45g (3,000 pages)	16523
•	Absolute Cyan™ toner for use in Dell 2150 cn, 2155 MFP, 45g (2,500 pages)	16524
•	Absolute Magenta™ toner for use in Dell 2150 cn, 2155 MFP, 45g (2,500 pages)	16525
•	Absolute Yellow™ toner for use in Dell 2150 cn, 2155 MFP, 45g (2,500 pages)	16526
•	Smartchip™ Black toner for use in Dell 2150, 2155 cn (331-0719, MY5TJ) (US) (3,000 pages)	16775
•	Smartchip™ Cyan toner for use in Dell 2150, 2155 cn (331-0716, THKJ8) (US) (2,500 pages)	16776
•	Smartchip™ Magenta toner for use in Dell 2150, 2155 cn (331-0717, 2Y3CM) (US) (2,500 pages)	16777
•	Smartchip™ Yellow toner for use in Dell 2150, 2155 cn (331-0718, 9X54J) (US) (2,500 pages)	16778
•	Smartchip™ Black toner for use in Dell 2150 cn (593-11040) (EU) (3,000 pages)	17151
•	Smartchip™ Cyan toner for use in Dell 2150 cn (593-11041) (EU) (2,500 pages)	17152
•	Smartchip™ Magenta toner for use in Dell 2150 cn (593-11033) (EU) (2,500 pages)	17153
•	Smartchip™ Yellow toner for use in Dell 2150 cn (593-11037) (EU) (2,500 pages)	17154
DELL 3335, 3333 MFP		
•	Superchip™ Universal for use in Lexmark E/X 460, 360, 260, Dell 2330, 2350, 3330, 3335 (3,500 pages)(US & WW)	14933
•	Superchip™ Universal for use in Lexmark E/X 460, 360, 260, Dell 2330, 2350, 3330, 3335 (18,000 pages)(US & WW)	18635
•	Superchip™ Universal for use in Lexmark E/X 460, 360, 260, Dell 2330, 2350, 3330, 3335 (15,000 pages)(US & WW)	18636
•	Absolute Black® toner for use in Dell 3330, 3333, 3335 Dn, 415g (14,000 pages)	18736
•	X-Generation® Black toner for use in Dell 3330, 3333, 3335, 415g (14,000 pages)	18793
•	Superchip™ Universal for use in Lexmark E/X 260, 360, 460, Dell 2330, 2350, 3330, 3335 (9,000 pages)(US & WW)	18924
•	Smartchip™ for use in Lexmark X 466, 464, 463, Dell 3335, 3333, Ricoh SP 4410, 4400 (15,000 pages)(Latin America)	189250
•	Smartchip™ for use in Lexmark X 463, 464, 466, Dell 3333, 3335, Ricoh MF 2400, 3400 (15,000 pages)(Asia Pacific)	18926
DELL 5530, 5230		
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (25,000 pages)(T654H21A)	18937
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (36,000 pages)(T654X21A)	18936
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (36,000 pages)(T654X21E)	18935
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (36,000 pages)(T654X21L)	18934
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (36,000 pages)(T654X21P)	18933
DELL 5535 MFP		
•	Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (25,000 pages)	18639
•	Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (36,000 pages)	18640
EPSON®		
EPSON ACULASER C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)		
•	Smartchip™ Black for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF (C13S050614)(2,000 pages)	12526
•	Smartchip™ Cyan for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF (C13S050613)(1,400 pages)	12527
•	Smartchip™ Magenta for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF (C13S050612)(1,400 pages)	12528
•	Smartchip™ Yellow for use in Epson Aculaser C 1700, 1750N, 1750W, CX17NF (C13S050611)(1,400 pages)	12529
•	Absolute Black® toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C, 40g	16659
•	Absolute Cyan™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C, 30g	16660
•	Absolute Magenta™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C, 30g	16661
•	Absolute Yellow™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C, 30g	16662
•	Absolute Black® toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C, 1kg	17344
•	Absolute Cyan™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C, 1kg	17345
•	Absolute Magenta™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C, 1kg	17346
•	Absolute Yellow™ toner for use in Epson Aculaser C 1700, 1750, CX 17, LP S 520, 620, NEC 5600C, 1kg	17347
EPSON ACULASER C 1600, CX 16		
•	Absolute Black® toner for use in Epson AcuLaser C 1600, CX 16 (2,700 pages)	17872
•	Absolute Cyan™ toner for use in Epson AcuLaser C 1600, CX 16 (2,700 pages)	17873
•	Absolute Magenta™ toner for use in Epson AcuLaser C 1600, CX 16 (2,700 pages)	17874
•	Absolute Yellow™ toner for use in Epson AcuLaser C 1600, CX 16 (2,700 pages)	17875
•	Smartchip™ Black for use in Epson aculaser C 1600 (C13S050557)(2,700 pages)	16231
•	Smartchip™ Cyan for use in Epson aculaser C 1600 (C13S050556)(2,700 pages)	16232
•	Smartchip™ Magenta for use in Epson aculaser C 1600 (C13S050555)(2,700 pages)	16233
•	Smartchip™ Yellow for use in Epson aculaser C 1600 (C13S050554)(2,700 pages)	16234
EPSON ACULASER C 3900		
•	Absolute Black® toner for use in Epson Aculaser C 3900n 160g (6,000 pages)	17322
•	Absolute Cyan® toner for use in Epson Aculaser C 3900n 160g (6,000 pages)	17323
•	Absolute Magenta® toner for use in Epson Aculaser C 3900n 160g (6,000 pages)	17324
•	Absolute Yellow® toner for use in Epson Aculaser C 3900n 160g (6,000 pages)	17325
•	Smartchip™ Black for use in Epson Aculaser C 3900n (C13S050593) (6,000 pages)	17304
•	Smartchip™ Cyan for use in Epson Aculaser C 3900n (C13S050592) (6,000 pages)	17305
•	Smartchip™ Magenta for use in Epson Aculaser C 3900n (C13S050591) (6,000 pages)	17306
•	Smartchip™ Yellow for use in Epson Aculaser C 3900n (C13S050590) (6,000 pages)(EU)(MOQ 50)	17307
EPSON ACULASER C 2900, CX 29		
•	Smartchip™ Black for use in Epson Aculaser C 2900, CX 29 NF (13S050630) (3,000 pages)	16663
•	Smartchip™ Cyan for use in Epson Aculaser C 2900, CX 29 NF (13S050629) (2,500 pages)	16664
•	Smartchip™ Magenta for use in Epson Aculaser C 2900, CX 29 NF (13S050628) (2,500 pages)	16665
•	Smartchip™ Yellow for use in Epson Aculaser C 2900, CX 29 NF (13S050627) (2,500 pages)	16666
•	Absolute Black® toner for use in Epson Aculaser C 2900, CX 29 NF	16667
•	Absolute Cyan™ toner for use in Epson Aculaser C 2900, CX 29 NF, 45g (2,500 pages)	16668

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	Absolute Magenta™ toner for use in Epson Aculaser C 2900, CX 29 NF, 45g (2,500 pages)	16669
•	Absolute Yellow™ toner for use in Epson Aculaser C 2900, CX 29 NF, 45g (2,500 pages)	16670
•	Absolute Black® toner for use in Epson Aculaser C 2900, CX 29 NF, 22lb (10kg) bag	17554
•	Absolute Cyan® toner for use in Epson Aculaser C 2900, CX 29 NF, 22lb (10kg) bag	17555
•	Absolute Magenta® toner for use in Epson Aculaser C 2900, CX 29 NF, 22lb (10kg) bag	17556
•	Absolute Yellow® toner for use in Epson Aculaser C 2900, CX 29 NF, 22lb (10kg) bag	17557
EPSON WORKFORCE M 200, MX 200		
•	Absolute Black® toner for use in Epson Aculaser WorkForce M 200, MX 200(2,500 pages)	18669
•	Absolute Black® toner for use in Epson WorkForce Aculaser M 200, MX 200, 22lb (10kg) bag	18774
EPSON WORKFORCE AL-M 200DN, MX 200		
•	Smartchip™ for use in Epson WorkForce AL-M 200DN, MX 200 (C13S050709) (2,500 pages)	18161
EPSON ACULASER WORKFORCE M 300		
•	Smartchip™ for use in Epson Aculaser WorkForce M 300 (C13S050689)	18910
•	Absolute Black® toner for use in Epson Aculaser WorkForce M 300, 225g (10,000 pages)	18916
EPSON M 2310, 2410		
•	Smartchip™ toner for use in Epson M 2310, 2410 (C13S050586) (8,000 pages)	18239
EPSON ACULASER M 1400, MX 14 NF (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)		
	Absolute Black® toner for use in Epson Aculaser M 1400, MX 14 NF, 45g (2,200 pages)	16675
	Smartchip™ Black for use in Epson Aculaser M 1400, MX 14 NF (C13S0507651) (2,200 pages)	16676
	Absolute Black® toner for use in Epson Aculaser M 1400, MX 14 NF, 22lb (10kg) bag	17553
EPSON ACULASER M 2400, 2300, MX 20 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)		
	Smartchip™ for use in Epson Aculaser M 2400, 2300, MX 20 (C13S050582)(8,000 pages)	16750
	Absolute Black® toner for use in Epson Aculaser M 2400, 2300, MX 20, 250g (8,000 pages)	17252
	Smartchip™ for use in Epson Aculaser M 2400, 2300, MX 20 (C13S050438)(3,500 pages)	17438
FUJI XEROX®		
FUJI XEROX DOCUPRINT C 2250, 3360, DOCUCENTRE C 2205, 3305 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)		
	X-Generation® drum with gears and insert for use in Fuji Xerox DocuPrint C 2250, 3360, DocuCentre C 2205, 3305	18295
	Smartchip™ CMYK drum unit for use in Fuji Xerox DocuPrint C 3360, 2250 (CT350615) (40,000 pages)	18305
FUJI XEROX DOCUPRINT C 3305, 2205 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)		
	X-Generation® drum with gears and insert for use in Fuji Xerox DocuPrint C 2250, 3360, DocuCentre C 2205, 3305	18295
	Smartchip™ CMYK drum unit for use in Fuji Xerox DocuPrint C 3305, 2205 (CT350595) (91,000 pages)	18306
FUJI XEROX DOCUPRINT C 3350		
	Smartchip™ Black for use in Fuji Xerox Docuprint C 3350 (5,000 pages) (CT201398)	18020
	Smartchip™ Cyan for use in Fuji Xerox Docuprint C 3350 (4,500 pages) (CT201399)	18021
	Smartchip™ Magenta for use in Fuji Xerox Docuprint C 3350 (4,500 pages) (CT201400)	18022
	Smartchip™ Yellow for use in Fuji Xerox Docuprint C 3350 (4,500 pages) (CT201401)	18023
	Absolute Black® toner for use in Fuji Xerox Docuprint C 3350, TBAg (5,000 pages)	18024
	Absolute Cyan® toner for use in Fuji Xerox Docuprint C 3350, TBAg (4,500 pages)	18025
	Absolute Magenta® toner for use in Fuji Xerox Docuprint C 3350, TBAg (4,500 pages)	18026
	Absolute Yellow® toner for use in Fuji Xerox Docuprint C 3350, TBAg (4,500 pages)	18027
FUJI XEROX DOCUPRINT C 1190 FS		
	Smartchip™ Black for use in Fuji Xerox Docuprint C 1190 FS (3,000 pages) (CT201260)	14895
	Smartchip™ Cyan for use in Fuji Xerox Docuprint C 1190 FS (3,000 pages) (CT201261)	14896
	Smartchip™ Magenta for use in Fuji Xerox Docuprint C 1190 FS (3,000 pages) (CT201262)	14897
	Smartchip™ Yellow for use in Fuji Xerox Docuprint C 1190 FS (3,000 pages) (CT201263)	14898
	X-Generation® Black toner for use in Fuji Xerox Docuprint C 1190 FS, 50g,(3,000 pages) (CT201260)	14899
	X-Generation® Cyan toner for use in Fuji Xerox Docuprint C 1190 FS, 50g,(3,000 pages) (CT201261)	14900
	X-Generation® Magenta toner for use in Fuji Xerox Docuprint C 1190 FS, 50g,(3,000 pages) (CT201262)	14901
	X-Generation® Yellow toner for use in Fuji Xerox Docuprint C 1190 FS, 50g,(3,000 pages) (CT201263)	14902
FUJI XEROX DOCUPRINT C 5000		
	Smartchip™ Black toner for use in Fuji Xerox Docuprint C 5000, 5005 (CT201664)(27,000 pages)	17036
	Smartchip™ Cyan toner for use in Fuji Xerox Docuprint C 5000, 5005 (CT201665)(25,000 pages)	17045
	Smartchip™ Magenta toner for use in Fuji Xerox Docuprint C 5000, 5005 (CT201666)(25,000 pages)	17046
	Smartchip™ Yellow toner for use in Fuji Xerox Docuprint C 5000, 5005 (CT201667)(25,000 pages)	17047
	Smartchip™ Black toner for use in Fuji Xerox Docuprint C 5000, (CT201688)(23,000 pages)	17584
	Smartchip™ Cyan toner for use in Fuji Xerox Docuprint C 5000, (CT201689)(12,000 pages)	17585
	Smartchip™ Yellow toner for use in Fuji Xerox Docuprint C 5000, (CT201691)(12,000 pages)	17587
FUJI XEROX DOCUPRINT CM 505		
	Smartchip™ Black toner for use in Fuji Xerox Docuprint CM 505 (CT201680) (16,000 pages)	17037
	Smartchip™ Cyan toner for use in Fuji Xerox Docuprint CM 505 (CT201681) (12,000 pages)	17038
	Smartchip™ Magenta toner for use in Fuji Xerox Docuprint CM 505 (CT201682) (12,000 pages)	17039
•	Smartchip™ Yellow toner for use in Fuji Xerox Docuprint CM 505 (CT201683) (12,000 pages)	17040
•	X-Generation® Black toner for use in Fuji Xerox Docuprint CM 505 (16,000 pages)	18944
•	X-Generation® Cyan toner for use in Fuji Xerox Docuprint CM 505 (12,000 pages)	18945
•	X-Generation® Magenta toner for use in Fuji Xerox Docuprint CM 505 (12,000 pages)	18946
•	X-Generation® Yellow toner for use in Fuji Xerox Docuprint CM 505 (12,000 pages)	18947
FUJI XEROX DOCUPRINT CP 305, CM 305		
	Smartchip™ Black toner for use in Fuji Xerox Docuprint CP 305, CM 305 (CT201632) (3,000 pages)	17041
	Smartchip™ Cyan toner for use in Fuji Xerox Docuprint CP 305, CM 305 (CT201633) (3,000 pages)	17042
	Smartchip™ Magenta toner for use in Fuji Xerox Docuprint CP 305, CM 305 (CT201634) (3,000 pages)	17043

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Smartchip™ Yellow toner for use in Fuji Xerox Docuprint CP 305, CM 305 (CT201635) (3,000 pages)	17044
	X-Generation® Black toner for use in Fuji Xerox Docuprint CP 305, CM 305, 50g (3,000 pages) (CT201632)	17935
	X-Generation® Cyan toner for use in Fuji Xerox Docuprint CP 305, CM 305, 50g (3,000 pages) (CT201633)	17936
	X-Generation® Magenta toner for use in Fuji Xerox Docuprint CP 305, CM 305, 50g (3,000 pages) (CT201634)	17937
•	X-Generation® Yellow toner for use in Fuji Xerox Docuprint CP 305, CM 305, 50g (3,000 pages) (CT201635)	17938
•	X-Generation® Black toner for use in Fuji Xerox Docuprint CP 305, CM 305, 22lb (10kg) bag	18577
•	X-Generation® Cyan toner for use in Fuji Xerox Docuprint CP 305, CM 305, 22lb (10kg) bag	18578
•	X-Generation® Magenta toner for use in Fuji Xerox Docuprint CP 305, CM 305, 22lb (10kg) bag	18579
•	X-Generation® Yellow toner for use in Fuji Xerox Docuprint CP 305, CM 305, 22lb (10kg) bag	18580
	FUJI XEROX DOCUPRINT C 2250, 3360, DOCUCENTRE C 2205, 3305	
	X-Generation® drum with gears and insert for use in Fuji Xerox DocuPrint C 2250, 3360, DocuCentre C 2205, 3305	18295
	FUJI XEROX DOCUCENTRE IV C 4430 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Fuji Xerox Docucentre IV C4430, TBAg (16,000 pages)	17276
	Absolute Cyan® toner for use in Fuji Xerox Docucentre IV C4430, TBAg (12,000 pages)	17277
	Absolute Magenta® toner for use in Fuji Xerox Docucentre IV C4430, TBAg (12,000 pages)	17278
	Absolute Yellow® toner for use in Fuji Xerox Docucentre IV C4430, TBAg (12,000 pages)	17279
	Smartchip™ Black drum unit for use in Fuji Xerox Docucentre IV C4430 (CT350895) (48,000 pages)	17469
	Smartchip™ Black toner for use in Fuji Xerox Docucentre IV C4430 (CT201676) (16,000 pages)	17286
	Smartchip™ Cyan drum unit for use in Fuji Xerox Docucentre IV C4430 (CT350896) (48,000 pages)	17470
	Smartchip™ Cyan toner for use in Fuji Xerox Docucentre IV C4430 (CT201677) (12,000 pages)	17287
	Smartchip™ Magenta drum unit for use in Fuji Xerox Docucentre IV C4430 (CT350897) (48,000 pages)	17471
	Smartchip™ Magenta toner for use in Fuji Xerox Docucentre IV C4430 (CT201678) (12,000 pages)	17288
	Smartchip™ Yellow drum unit for use in Fuji Xerox Docucentre IV C4430 (CT350898) (48,000 pages)	17472
	Smartchip™ Yellow toner for use in Fuji Xerox Docucentre IV C4430 (CT201679) (12,000 pages)	17289
	FUJI XEROX DOCUPRINT CP 405	
•	Smartchip™ Yellow drum unit for use in Fuji-Xerox Docuprint CP 405 (CT350983)(55,000 pages)	18335
	HP®	
	HP CM 6030, 6040 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in HP CP 6015, CM 6030, 6040, 340g (16,500 pages)	13290
	Absolute Cyan™ toner for use in HP CP 6015, CM 6030, 6040, 330g (21,000 pages)	13291
	Absolute Magenta™ toner for use in HP CP 6015, CM 6030, 6040, 330g (21,000 pages)	13292
	Absolute Yellow™ toner for use in HP CP 6015, CM 6030, 6040, 330g (21,000 pages)	13293
	Absolute Black® toner for use in HP CP 6015, CM 6030, 6040, 22 lb (10 kg) bag	13294
	Absolute Cyan™ toner for use in HP CP 6015, CM 6030, 6040, 22 lb (10 kg) bag	13295
	Absolute Magenta™ toner for use in HP CP 6015, CM 6030, 6040, 22 lb (10 kg) bag	13296
	Absolute Yellow™ toner for use in HP CP 6015, CM 6030, 6040, 22 lb (10 kg) bag	13297
	ASIC Smartchip® Black toner for use in HP CP 6015, CM 6030 (CB380A) (16,500 pages), 10 pack	13298
	ASIC Smartchip® Cyan toner for use in HP CP 6015, CM 6030, 6040, (CB381A) (21,000 pages), 10 pack	13299
	ASIC Smartchip® Magenta toner for use in HP CP 6015, CM 6030, 6040, (CB383A) (21,000 pages), 10 pack	13300
	ASIC Smartchip® Yellow toner for use in HP CP 6015, CM 6030, 6040, (CB382A) (21,000 pages), 10 pack	13301
	ASIC Smartchip® Black drum for use in HP CP 6015, CM 6030, 6040, (CB384A) (35,000 pages), 10 pack	13765
	ASIC Smartchip® Cyan drum for use in HP CP 6015, CM 6030, 6040, (CB385A) (35,000 pages) 10 pack	13766
	ASIC Smartchip® Magenta drum for use in HP CP 6015, CM 6030, 6040, (CB387A) (35,000 pages) 10 pack	13767
	ASIC Smartchip® Yellow drum for use in HP CP 6015, CM 6030, 6040 (CB386A) (35,000 pages)10 pack	13768
	SuMMIT® OPC drum with gears for use in HP CP 6015, CM 6030, 6040	13769
	ASIC Smartchip® Black drum for use in HP CP 6015, CM 6030, 6040, (CB384A) (35,000 pages),	15253
	ASIC Smartchip® Cyan drum for use in HP CP 6015, CM 6030, 6040, (CB385A) (35,000 pages)	15254
	ASIC Smartchip® Magenta drum for use in HP CP 6015, CM 6030, 6040, (CB387A) (35,000 pages)	15255
	ASIC Smartchip® Yellow drum for use in HP CP 6015, CM 6030, 6040 (CB386A) (35,000 pages)	15256
	ASIC Smartchip® Black toner for use in HP CP 6015, CM 6030 (CB380A) (16,500 pages)	15257
	ASIC Smartchip® Cyan toner for use in HP CP 6015, CM 6030, 6040, (CB381A) (21,000 pages)	15258
	ASIC Smartchip® Magenta toner for use in HP CP 6015, CM 6030, 6040, (CB383A) (21,000 pages)	15259
	ASIC Smartchip® Yellow toner for use in HP CP 6015, CM 6030, 6040, (CB382A) (21,000 pages)	15260
	Unidrum™ OPC with gears for use in HP CP 6015, CM 6030, 6040	16755
	HP ENTERPRISE 700 COLOR MFP M 775	
•	Absolute Black® toner for use in HP CP 5225, 5525, M 775, Canon LPB 9600 22 lb (10 kg) bag	16051
•	Absolute Cyan® toner for use in HP CP 5225, 5525, M 775, Canon LPB 9600 22 lb (10 kg) bag	16052
•	Absolute Magenta® toner for use in HP CP 5225, 5525, M 775, Canon LPB 9600 22 lb (10 kg) bag	16053
•	Absolute Yellow® toner for use in HP CP 5225, 5525, M 775, Canon LPB 9600 22 lb (10 kg) bag	16054
•	SuMMIT® OPC drum for use in HP CP 5225, 5525, Enterprise M 775	16183
•	X-Generation® Wiper Blade for use in HP CP 5225, 5525, M 775, 10 pack	16193
•	Clear Seal with double sided adhesive for use in HP CP 5225, 5525, Enterprise M 775, LBP 9100, 9500, 9600, 50 pack	16495
•	Drum cover for use in HP CP 5225, 5525, Enterprise M 775, Canon 322, 322 (II), 10 pack	17625
•	Absolute Black® toner for use in HP Enterprise 700 color MFP M 775, 295g (13,500 pages)	18031
•	Absolute Cyan® toner for use in HP Enterprise 700 color MFP M 775, 295g (16,000 pages)	18032
•	Absolute Magenta® toner for use in HP Enterprise 700 color MFP M 775, 295g (16,000 pages)	18033
•	Absolute Yellow® toner for use in HP Enterprise 700 color MFP M 775, 295g (16,000 pages)	18034
•	ASIC Smartchip® Black for use in HP Enterprise 700 color MFP M 775 (13,500 pages), 10 pack	18035
•	ASIC Smartchip® Cyan for use in HP Enterprise 700 color MFP M 775 (16,000 pages), 10 pack	18036
•	ASIC Smartchip® Magenta for use in HP Enterprise 700 color MFP M 775 (16,000 pages)10 pack	18037
•	ASIC Smartchip® Yellow for use in HP Enterprise 700 color MFP M 775 (16,000 pages)10 pack	18038
	HP M 4555, P 4014, 4015, 4515	
•	Soft PCR roller for use in HP 4014, 4015, 4515, M 4555 10 pack	6497
•	Recovery blade for use in HP P 4014, 4015, 4515, M 455550 pack	13074
•	Retaining blade for use in HP P 4014, 4015, 4515, M 4555, 50 pack	13076
•	Mag roller sleeve for use in HP P 4014, 4015, 4515, M 4555, (NO HUB) 10 pack	13143
•	SuMMIT® OPC drum with gears for use in HP P 4014, 4015, 4515, M 4555, 5 pack	13145

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	Mag roller wipers for use in HP P 4014, 4015, 4515, M 4555, 10 sets	13146
•	Shipping lock for use in HP P 4014, 4015, 4515, M 4555, 10 pack	13177
•	Unidrum™ F with gears for use in HP P 4014, 4015, 4515, M 4555 (Sold 50/box)	13692
•	X' version high yield toner hopper for use in HP P 4014, 4015, 4515, M 4555 (unsealed)	13898
•	Top metal clip for use in HP P 4014, 4015, 4515, M 4555, 100 pack	13900
•	X-Generation® Wiper blade for use in HP 4100, 4000, P 4014, 4015, 4515, M 4555, 10 pack	14115
•	Mag roller stabilizer bearing for use in HP P 4515, 4015, 4014, M 4555, 10 sets	15709
•	X-Generation® Doctor blade for use in HP P 4014, 4015, 4515, M 4555, 10 pack	16148
•	ASIC Smartchip® for use in HP Laserjet Enterprise M4555, M 603, 602, 601 (CE390A)(10,000 pages), 10 pack	16278
•	ASIC Smartchip® for use in HP Laserjet Enterprise M4555, M 603, 602, 601 (CE390X)(24,000 pages), 10 pack	16279
•	Unidrum™ OPC with gear for use in HP P 4014, 4015, 4515, M 4555,	16292
•	Rail foam for use in HP P 4014, 4015, 4515, M 4555, 100 pack	16435
•	Universal Jumbo waste toner hopper for use in HP P 4014, 4015, 4515, M 4555,	16749
•	SuMMIT® OPC drum with gears for use in HP P 4014, 4015, 4515, M 4555, 100 pack	17416
•	Mag roller sleeve for use in HP P 4014, 4015, 4515, M 4555, 10 pack (High Yield Coating)	17702
•	X-Generation® Black toner for use in HP P 4014, 4015, 4515, M 4555, 1100g (24,000 pages) (MPT-4015 XGEN)	17703
•	X-Generation® Black toner for use in HP P 4014, 4015, 4515, M 4555, 22 lb (10 kg) bag (MPT-4015 XGEN)	17705
•	Soft PCR roller for use in HP 4014, 4015, 4515, M 4555, 10 pack	18611
•	X-Generation® toner for use in HP P 4014, 4015, 4515, M 4555, 445g (10,000 pages) (MPT 4015 X GEN)	18763
HP CM 1312, 1415, 2320		
•	X-Generation® Wiper blade for use in HP CM 1312, 1415, 2320,(10 PACK)	12611
•	X-Generation® drum with gears for use in HP CM 1312,1415, 2320	13220
•	X-Generation® Cyan toner for use in HP CM 1312, 1415, 2320, 22 lb (10 kg) bag (MPT-251)	13540
•	X-Generation® Magenta toner for use in HP CM 1312, 1415, 2320, 22 lb (10 kg) bag (MPT-251)	13542
•	X-Generation® Yellow toner for use in HP CM 1312, 1415, 2320, 22 lb (10 kg) bag (MPT-251)	13544
•	ASIC Smartchip® Black for use in HP CM 1312 MFP, Canon LBP 5050, (2,200 pages)	14148
•	ASIC Smartchip® Magenta for use in HP CM 1312 MFP, Canon LBP 5050 (1,400 pages)	14151
•	ASIC Smartchip® Yellow for use in HP CM 1312 MFP, Canon LBP 5050 (1,400 pages)	14155
•	ASIC Smartchip® Cyan for use in HP CM 1312 MFP, Canon LBP 5050 (1,400 pages), 10 pack	14690
•	ASIC Smartchip® Magenta for use in HP CP 1215, 1518, CM 1312 MFP, Canon LBP 5050 (1,400 pages), 10 pack	14691
•	ASIC Smartchip® Yellow for use in HP CM 1312 MFP, Canon LBP 5050 (1,400 pages), 10 pack	14692
•	ASIC Smartchip® Cyan for use in HP CM 1312 MFP, Canon LBP 5050 (1,400 pages) 100 pack	15428
•	ASIC Smartchip® Magenta for use in HP CM 1312 MFP, Canon LBP 5050 (1,400 pages) 100 pack	15429
•	ASIC Smartchip® Yellow for use in HP CM 1312 MFP, Canon LBP 5050 (1,400 pages) 100 pack	15430
•	X-Generation® Cyan toner for use in HP CM 1312, 1415, 2320, 1kg (MPT-2025)	17425
•	X-Generation® Magenta toner for use in HP CM 1312, 1415, 2320, 1kg (MPT-2025)	17426
•	X-Generation® Yellow toner for use in HP CM 1312, 1415, 2320, 1kg (MPT-2025)	17427
•	ASIC Smartchip® Cyan for use in HP CM 1312 MFP, Canon LBP 5050, 10 pack (For starter cartridges) (700 pages)	17457
•	ASIC Smartchip® Magenta for use in HP CM 1312 MFP, Canon LBP 5050, 10 pack(For starter cartridges) (700 pages)	17458
•	ASIC Smartchip® Yellow for use in HP CM 1312 MFP, Canon LBP 5050, 10 pack (For starter cartridges) (700 pages)	17459
•	X-Generation® Cyan toner for use in CM 1312, 1415, 2320, 1 kg bottle (MPT-251)	18267
•	X-Generation® Magenta toner for use in HP CM 1312, 1415, 2320, 1 kg bottle (MPT-251)	18268
•	X-Generation® Yellow toner for use in HP CM 1312, 1415, 2320, 1 kg bottle (MPT-251)	18269
•	X-Generation® Cyan toner for use in HP CM 1312, 1415, 2320, 22lb (10kg) bag (MPT-2025)	18337
•	X-Generation® Magenta toner for use in HP CM 1312, 1415, 2320, 22lb(10kg) bag (MPT-2025)	18338
•	X-Generation® Yellow toner for use in HP CM 1312, 1415, 2320, 22lb (10kg) bag (MPT-2025)	18339
HP LASERJET PRO 300, 400 M 375, 475, 451, MFP		
•	X-Generation® Wiper blade for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451, 10 pack	12611
•	X-Generation® drum with gears for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 MFP	13220
•	Doctor Blade shims for use in HP Laserjet Pro 300, 400, MFP M 375,475, 451 MFP, 100 pack	13620
•	Jumbo hopper for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 451, 475	15134
•	Jumbo hopper for use in HP Laserjet Pro 300, 400, MFP M 351, 375, 451, 475	15135
•	ASIC Smartchip® for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Black (CE410A)(2,200 pages) 10 pack	17064
•	ASIC Smartchip® for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Black (CE410X)(4,000 pages) 10 pack	17065
•	ASIC Smartchip™ for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Cyan (CE411A)(2,600 pages) 10 pack	17066
•	ASIC Smartchip® for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Magenta (CE413A)(2,600 pages) 10 pack	17067
•	ASIC Smartchip™ for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Yellow (CE412A)(2,600 pages) 10 pack	17068
•	Outer left end cap conversion (to convert HP CP 2025, CM 2320) for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451, 10 pack	17146
•	Outer right end cap conversion(to convert HP CP 2025, CM 2320) for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451,10 pack	17147
•	ASIC Smartchip™ for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Cyan (CE411A)(2,600 pages)	17258
•	ASIC Smartchip® for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Black (CE410X)(4,000 pages)	17259
•	ASIC Smartchip® for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Black (CE410A)(2,200 pages)	17260
•	ASIC Smartchip® for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Magenta (CE413A)(2,600 pages)	17261
•	ASIC Smartchip™ for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451 Yellow (CE412A)(2,600 pages)	17262
•	SuMMIT® drum with gears for use in HP Laserjet Pro 300, 400, MFP M 375,475, 451, 100 pack	17414
•	X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451, 60g (2,200 pages)	18207
•	X-Generation® Cyan toner for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451, 60g (2,600 pages)	18208
•	X-Generation® Magenta toner for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451, 60g (2,600 pages)	18209
•	X-Generation® Yellow toner for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451, 60g (2,600 pages)	18210
•	X-Generation® Black toner for use in HP Laserjet Pro 300, 400, MFP M 375, 475, 451, 90g (4,000 pages)	18211
HP LASERJET PRO 200 M 276 MFP		
•	Unidrum™ with gears for use in HP Laserjet Pro 200, M 276 MFP	12610
•	X-Generation® Black toner for use in HP Laserjet Pro 200, M 276 MFP 22 lb (10 kg) bag (MPT-251)	13538
•	X-Generation® Cyan toner for use in HP Laserjet Pro 200, M 276 MFP, 22 lb (10 kg) bag (MPT-251)	13540
•	X-Generation® Magenta toner for use in HP Laserjet Pro 200, M 276 MFP, 22 lb (10 kg) bag (MPT-251)	13542
•	X-Generation® Yellow toner for use in HP Laserjet Pro 200, M 276 MFP 22 lb (10 kg) bag (MPT-251)	13544
•	X-Generation® Black toner for use in HP Laserjet Pro 200 M 251, 276 MFP, 65g (2,400 pages)(MPT-251)	17910
•	X-Generation® Cyan toner for use in HP Laserjet Pro 200 M 276 MFP, 40g (1,800 pages)(MPT-251)	17911
•	X-Generation® Magenta toner for use in HP Laserjet Pro 200 M 276 MFP, 40g (1,800 pages)(MPT-251)	17912

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	X-Generation® Yellow toner for use in HP Laserjet Pro 200 M 276 MFP, 40g (1,800 pages)(MPT-251)	17913
•	X-Generation® Black toner for use in HP Laserjet Pro 200 M 276 MFP, 45g (1,600 pages)(MPT-251)	18030
•	X-Generation® Black toner for use in HP Laserjet Pro 200, M 276 MFP 1 kg bottle (MPT-251)	18266
•	X-Generation® Cyan toner for use in HP Laserjet Pro 200, M 276 MFP 1 kg bottle (MPT-251)	18267
•	X-Generation® Magenta toner for use in HP Laserjet Pro 200, M 276 MFP 1 kg bottle (MPT-251)	18268
•	X-Generation® Yellow toner for use in HP Laserjet Pro 200, M 276 MFP 1 kg bottle (MPT-251)	18269
•	Waste section for use in HP Laserjet Pro 200, M 276 MFP	18346
HP CM 4540, 3530, M 575 MFP		
•	Clear Seal™ adhesive for use in HP CM 4540, 3530, M 575 MFP, 50 pack	13656
•	Drum cover shipping protector for use in HP CM 4540, 3530, M 575 MFP, 10 pack	14282
•	X-Generation® Wiper blade for use in HP CM 4540, 3530, M 575 10 pack	14503
•	ASiC Smartchip® for use in HP CM 4540, 3530, M 575 Black (CE260A)(8,500 pages), 10 pack	14923
•	X-Generation® Black toner for use in HP CM 4540, 3530, M 575, 22 lb (10 kg) bag (MPT 4525)	14987
•	X-Generation® Cyan toner for use in HP CM 4540, 3530, M 575 22 lb (10 kg) bag (MPT 4525)	14988
•	X-Generation® Magenta toner for use in HP CM 4540, 3530, M 575 22 lb (10 kg) bag (MPT 4525)	14989
•	X-Generation® Yellow toner for use in HP CM 4540, 3530, M 575 22 lb (10 kg) bag (MPT 4525)	14990
•	X-Generation® Black toner for use in HP CM 4540, 3530, M 575 MFP (8,500 pages)	14996
•	X-Generation® Cyan toner for use in HP CM 4540, 3530, M 575 MFP (CE261A)(11,000 pages)	14997
•	X-Generation® Magenta toner for use in HP CM 4540, 3530, M 575 MFP (CE263A)(11,000 pages)	14998
•	X-Generation® Yellow toner for use in HP CM 4540, 3530, M 575 MFP (CE262A)(11,000 pages)	14999
•	X-Generation® Black toner for use in HP CM 4540, 3530, M 575 MFP (17,000 pages)	15033
•	ASiC Smartchip® for use in HP CM 4540, 3530, M 575 Black (CE260A)(8,500 pages)	15248
•	ASiC Smartchip® Black toner for use in HP CM 4540, 3530, M 575 (CE264X) (17,000 pages), 10 pack	17309
•	ASiC Smartchip® Cyan toner for use in HP CM 4540, 3530, M 575 (CF031A) (12,500 pages), 10 pack	17310
•	ASiC Smartchip® Magenta toner for use in HP CM 4540, 3530, M 575 (CF033A)	17311
•	ASiC Smartchip® Yellow toner for use in HP CM 4540, 3530, M 575 (CF032A)	17312
•	Unidrum™ with gears for use in HP CM 4540, 3530, M 575 (with longer hub)	17523
•	Developer roller sealing blade for use in HP CM 4540, 3530, M 575, 50 pack	17628
•	Recovery blade for use in HHP CM 4540, 3530, M 575 50 pack	17629
•	X-Generation® Black toner for use in HP CM 4540, 3530, M 575 1kg (MPT 4525)	18233
•	X-Generation® Cyan toner for use in HP CM 4540, 3530, M 575 1kg (MPT 4525)	18234
•	X-Generation® Magenta toner for use in HP CM 4540, 3530, M 575 1kg (MPT 4525)	18235
•	X-Generation® Yellow toner for use in HP CM 4540, 3530, M 575 1kg (MPT 4525)	18236
•	Developer roller for use in HP CM 4540, 3530, M 575 10 pack	18321
HP M 175, 275 MFP		
•	Clear Seal™ adhesive for use in HP M175, 275, MFP, 50 pack	12613
•	ASiC Smartchip® Black for use in HP M 175, 275 (1200 pages)	15763
•	ASiC Smartchip® Cyan for use in HP M 175, 275 (1,000 pages)	15764
•	ASiC Smartchip® Magenta for use in HP M 175, 275 (1,000 pages)	15765
•	ASiC Smartchip® Yellow for use in HP M 175, 275 (1,000 pages)	15766
•	ASiC Smartchip® Black for use in HP M 175, 275 (1,200 pages) 10 pack	15830
•	ASiC Smartchip® Cyan for use in HP M 175, 275 (1,000 pages) 10 pack	15831
•	ASiC Smartchip® Magenta for use in HP M 175, 275 (1,000 pages) 10 pack	15832
•	ASiC Smartchip® Yellow for use in HP M 175, 275 (1,000 pages) 10 pack	15833
•	X-Generation® Black toner for use in HP M 175, 176, 177, 275, 30g (1,300 pages)	15834
•	X-Generation® Cyan toner for use in HP M 175, 176, 177, 275, 26g (1,000 pages)	15835
•	X-Generation® Magenta toner for use in HP M 175, 176, 177, 275, 26g (1,000 pages)	15836
•	X-Generation® Yellow toner for use in HP M 175, 176, 177, 275, 26g (1,000 pages)	15838
•	X-Generation® Black toner for use in HP M 175, 275, 22lb (10kg) bag	15875
•	X-Generation® Cyan toner for use in HP M 175, 275, 22 lb (10kg) bag	15876
•	X-Generation® Magenta toner for use in HP M 175, 275, 22lb (10kg) bag	15877
•	X-Generation® Yellow toner for use in HP M 175, 275, 22lb (10kg) bag	15878
•	Doctor Blade shims for use in HP M 175, 275, 100 pack	16222
•	Unidrum™ with gears for use in M 175, 275	16223
•	ASiC Smartchip® drum unit for use in HP M 175, 275	16285
•	Developer roller cover for use in HP M 175, 176, 177, 275, 10 pack	16971
•	Drum cover for use in HP M 175, 176, 177, 275, 10 pack	17072
•	SuMMiT® drum with gears for use in HP M 175, 275	17524
•	Wiper blade for use in HP M 175, 275, 10 pack	17701
HP PRO 400, MFP M 425		
•	Mag roller sleeve for use in HP Laserjet Pro 401, MFP M425 10 pack	5089
•	Soft PCR roller for use in HP Laserjet Pro 401, MFP M425, 10 pack (Universal)	7080
•	Clear Seal™ adhesive for use in HP Laserjet Pro 401, MFP M425, 50 pack	7400
•	Mag roller bushing set for use in HP 4200, 4250, 4300, 4350, 4345, 10 pack	8714
•	Seal pull tab for use in HP Laserjet Pro 401, MFP M425, 100 pack	9955
•	OPC drum shutter for use in HP Laserjet Pro 401, MFP M425, 10 pack	9956
•	Seal exit port plug for use in HP M 401, 425 MFP, 100 pack	9957
•	Mag roller bushing set for use in HP Laserjet Pro 401, MFP M425, 10 pack	9958
•	Doctor blade stabilizer for use in HP Laserjet Pro 401, MFP M425, 10 pack	9959
•	Mag roller wipers for use in HP Laserjet Pro 401, MFP M425 (left & right), 10 sets	9960
•	Cartridge pin for use in HP 1320, 1160, Laserjet Pro 401, MFP M425, 100 pack	9961
•	Mag roller contact TEFLON w/spring for use in HP Laserjet Pro 401, MFP M425, 100 pack	10384
•	Drive gears set for use in HP Laserjet Pro 401, MFP M425, 10 pack	10640
•	Mag roller stabilizers for use in HP Laserjet Pro 401, MFP M425 (Left & Right) set, 10 pack	10641
•	Left end cap for use in HP Laserjet Pro 401, MFP M425 10 pack	13908
•	Right end cap for use in HP Laserjet Pro 401, MFP M425, 10 pack	13909
•	SuMMiT® drum with contact hub and drive gear insert for use in HP Pro 400, MFP M 425	14013
•	Absolute Black® toner for use in HP Pro 400, MFP M 425, 290g (6,900 pages)	14014
•	Absolute Black® toner for use in HP Pro 400, MFP M 425, 120g (2,700 pages)	14015

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	Absolute Black® toner for use in HP P 2035, 2055, Pro 400, MFP M425, 22 lb (10 kg) bag	14104
•	Mag roller sealing blade for use in HP Laserjet Pro 401, MFP M425, 50 pack	14371
•	Recovery blade for use in HP Laserjet Pro 401, MFP M 425 50 pack	14376
•	Unidrum™ F with contact hub and drive gear insert for use in HP Pro 400, MFP M 425	15725
•	X-Generation® Wiper blade for use in HP Pro 400, MFP M 425, 10 pack	16147
•	Unidrum™ OEM style with contact hub and drive gear insert for use in HP Pro 400, MFP M 425	16283
•	Absolute Black® toner for use in HP Pro 400, MFP M 425, 1kg	17087
•	Universal Jumbo waste toner hopper conversion kit for use in HP M 401, 425 MFP	17450
•	ASIC Smartchip® for use in HP Laserjet Pro M 425 MFP, M 401 High Yield (CF280X) (6,900 pages), 10 pack	17463
•	ASIC Smartchip® for use in HP Laserjet Pro M 425 MFP, M 401 Low Yield (CF280A) (2,700 pages) 10 pack	17464
•	Jumbo hopper for use in HP M 401, 425, MPF, 500g fill	17529
•	Drum shutter with spring for use in HP M 401, 425,	17656
•	Absolute MICR™ toner for use in HP Pro 400, 401, MFP M 425, 330g (6,900 pages)	17794
•	Soft PCR roller for use in HP Laserjet Pro 401, MFP M425, 10 pack (High Yield Universal)	18610
•	ASIC Smartchip® for use in HP Laserjet Pro M 425 MFP, M 401 High Yield (CF280X) (6,900 pages), 100 pack	18624
•	ASIC Smartchip® for use in HP Laserjet Pro M 425 MFP, M 401 Low Yield (CF280A) (2,700 pages) 100 pack	18625
•	Doctor blade sealing foam for use in HP M 401, 425 MFP, 100 pack	18867
HP LASERJET ENTERPRISE 700 M 725 MFP		
•	Absolute Black® toner for use in HP Laserjet Enterprise 700 M 725 MFP, M 712, 815g (17,500 pages)	18600
•	Absolute Black® toner for use in HP Laserjet Enterprise 700 M 712, 725, 22 lb (10 kg) bag	18602
•	Absolute Black® toner for use in HP Laserjet Enterprise 700 M 725, 712, 465g (10,000 pages)	18601
•	X-Generation® black toner for use in HP Laserjet Enterprise 700 M 712, 725, 22 lb (10 kg) bag	18614
•	X-Generation® black toner for use in HP Laserjet Enterprise 700 M 725, 712, 465g (10,000 pages)	18613
•	X-Generation® black toner for use in HP Laserjet Enterprise 700 M 725, 712, 815g (17,500 pages)	18612
IBM®		
IBM 4312		
•	Absolute Black® toner for use in IBM 4312, 280g	334
•	Wiper blade for use in IBM 4312	338
•	Recovery blade for use in IBM 4312, 25 pack	4881
•	OPC shutter door felt for use in IBM 4019, 4039, 4037, 4312, 4317, 100 pack	6058
•	Doctor blade for use in IBM 4312, 10 pack	7744
•	Clear Seal™ OEM style adhesive for use in IBM 4312, 50 pack	8250
•	SuMMIT® drum with gears for use in IBM 4312	18667
IBM 4317		
•	Absolute Black® toner for use in IBM 4317, 400g	339
•	Absolute Black® toner for use in IBM 4317, 22 lb (10 kg) bag	340
•	PCR for use in IBM 4317 (recoated) roller, 10 pack	342
•	OPC shutter door felt for use in IBM 4019, 4039, 4037, 4312, 4317, 100 pack	6058
•	Unidrum™ S with gears & insert for use in IBM 4317	6100
•	Doctor blade for use in IBM 4317, 10 pack	7745
•	Wiper blade for use in IBM 4317	7746
•	X-Generation® Doctor blade for use in IBM 4317, 10 pack	17084
IBM 4320		
•	Absolute Black® toner for use in IBM 4320, 22 lb (10 kg) bag	6325
•	Absolute Black® toner for use in IBM 4320, 280g	5562
•	Clear Seal™ adhesive for use in IBM 4320, 10 pack	7479
•	Wiper blade for use in IBM 4320, 10 pack	7480
IBM 4019		
•	Absolute Black® toner for use in IBM 4019, 22 lb. (10 kg) bag	5533
•	Absolute Black® toner for use in IBM 4019, 300g	300
•	Absolute Black® toner for use in IBM 4019, 400g	301
•	Absolute MICR™ toner (for checks) for use in IBM 4019, 4039, 300g	303
•	Antistatic heat seal foil bag 14x18 NX, IBM 4019, 4039, 4049, Xerox 4517, 100 pack	4947
•	OPC shutter door felt for use in IBM 4019, 4039, 4037, 4312, 4317, 100 pack	6058
•	Wand for use in IBM 4019, 10 pack	305
IBM INFOPRINT 1145		
•	Absolute Black® toner for use in IBM Infoprint 1145, 1025g	12261
•	Absolute Black® toner for use in IBM Infoprint 1145, 22 lb (10 kg) bag	12263
•	Smartchip™ with housing for use in IBM Infoprint 1145	8277
•	Unidrum™ with gears & insert for use in IBM Infoprint 1145	14984
IBM INFOPRINT 1585		
•	Absolute Black® developer for drum unit for use in IBM Infoprint 1585, (75P6878) (60,000 pages)	14473
•	Absolute Black® toner for use in IBM Infoprint 1585, 650g	14469
•	Developer unit seal For use in IBM Infoprint 1585, 50 pack	14557
•	Smartchip™ drum unit for use in IBM Infoprint 1585 (75P6878)(60,000 pages)	14471
•	Smartchip™ toner for use in IBM Infoprint 1585 (75P6877) (30,000 pages)	14470
•	Unidrum™ OPC with gears for use in IBM Infoprint 1585 (75P6878) (60,000 pages)	14472
•	Wiper blade for use in IBM Infoprint 1585, 10 pack (75P6878) (60,000 pages)	14474
KYOCERA®		
KYOCERA FS C 5400, TK 570, 572, 574 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)		
•	Absolute Black® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 22lb(10kg) bag	18077
•	Absolute Black® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 380g (16,000 pages)	17676
•	Absolute Cyan® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 195g (12,000 pages)	17677
•	Absolute Cyan® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 22lb (10kg) bag	18078

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Absolute Magenta® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 190g (12,000 pages)	17678
	Absolute Magenta® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 22lb(10kg) bag	18079
	Absolute Yellow® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 195g (12,000 pages)	17679
	Absolute Yellow® toner for use in Kyocera FS C 5400, TK 570, 572, 574, 22lb(10kg) bag	18080
	Smartchip™ for use in Kyocera FS C 5400 TK 570, Black (16,000 pages) (EU)	17439
	Smartchip™ for use in Kyocera FS C 5400 TK 570 Cyan (12,000 pages) (EU)	17440
	Smartchip™ for use in Kyocera FS C 5400 TK 570 Magenta (12,000 pages) (EU)	17441
	Smartchip™ for use in Kyocera FS C 5400 TK 570, Yellow (12,000 pages) (EU)	17442
	Smartchip™ for use in Kyocera FS C 5400 TK 572, Black (16,000 pages) (US)	17620
	Smartchip™ for use in Kyocera FS C 5400 TK 572 Cyan (12,000 pages) (US)	17621
	Smartchip™ for use in Kyocera FS C 5400 TK 572 Magenta (12,000 pages) (US)	17622
	Smartchip™ for use in Kyocera FS C 5400, TK 572, Yellow (12,000 pages) (US)	17623
	Smartchip™ for use in Kyocera FS C 5400, TK 574, Black (16,000 pages) (AU)	17200
	Smartchip™ for use in Kyocera FS C 5400, TK 574, Cyan (12,000 pages) (AU)	17201
	Smartchip™ for use in Kyocera FS C 5400, TK 574, Magenta (12,000 pages) (AU)	17202
	Smartchip™ for use in Kyocera FS C 5400, TK 574, Yellow (12,000 pages) (AU)	17203
	KYOCERA FS 4200, TK 3124, 3122, 3120 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
•	Absolute Black® toner for use in Kyocera FS 4200 TK 3124, 3122, 3120, 450g (21,000 pages) (AMES Certified)	18123
•	Smartchip™ toner for use in Kyocera FS 4200 TK 3120, (21,000 pages), 10 pack (EU)	18129
•	Smartchip™ toner for use in Kyocera FS 4200 TK 3122, (21,000 pages), 10 pack (USA)	18130
•	X-Generation® toner for use in Kyocera FS 4200 TK 3124, 3122, 3120, (21,000 pages)	18845
	KYOCERA FS 4300, TK 3134, 3132, 3130 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
•	Absolute Black® toner for use in Kyocera FS 4300 TK 3134, 3132, 3130, 650g (25,000 pages)	18124
•	Smartchip™ toner for use in Kyocera FS 4300 TK 3130, (25,000 pages), 10 pack (EU)	18133
•	Smartchip™ toner for use in Kyocera FS 4300 TK 3132 (25,000 pages), 10 pack (USA)	18132
•	Smartchip™ toner for use in Kyocera FS 4300 TK 3134 (25,000 pages), 10 pack (AUS)	18757
•	X-Generation® toner for use in Kyocera FS 4300 TK 3134, 3132, 3130, (25,000 pages)	18846
	KYOCERA FS 1370, 1320, TK 174, 172, 170	
	Absolute Black® toner for use in Kyocera FS 1370, 1320, TK 174, 172, 170, 22lb (10kg) bag (AMES Certified)	17318
	Absolute Black® toner for use in Kyocera FS 1370, 1320, TK 174, 172, 170, 250g (7,200 pages) (AMES Certified toner)	15968
	Empty toner cartridge for use in Kyocera FS 1370, 1320, TK 174, 173, 172, 170	15969
	Smartchip™ for use in Kyocera FS 1320, TK 170 (7,200 pages) (EU)	17074
	Smartchip™ for use in Kyocera FS 1320, TK 172 (7,200 pages) (US)	17167
	Smartchip™ for use in Kyocera FS 1320, TK 174 (7,200 pages) (AU)	17168
	KYOCERA FS 1000, TK 17 H	
	Absolute Black® toner for use in Kyocera FS 1000 TK 17 H, 235g (AMES Certified toner)	8694
	Absolute Black® toner for use in Kyocera FS 1000, 1020, KM 1500, TK 17 H, LA, 18 H, 1 kg bottle (AMES Certified toner)	16494
	Absolute Black® toner for use in Kyocera FS 1000, 1020, KM 1500, TK 17 H, LA, 18 H, 22 lb (10 kg) bag (AMES Certified)	7158
	Black Airbag for Kyocera FS 1000 Cartridges (L 240mm, W 415mm), 100 pack	14972
	Toner hopper fill plug for use in Kyocera FS 1000, 1020, KM 1500, TK 17, LA, TK 18 H, 100 pack	9972
	KYOCERA FS 1020, 1118, TK 18 H	
	Absolute Black® toner for use in Kyocera FS 1020, 1118, TK 18 H, 22 lb (10 kg) bag (AMES Certified)	9787
	Absolute Black® toner for use in Kyocera FS 1020, 1118, TK 18 H, 295g (AMES Certified toner)	8881
	KYOCERA FS 1700, TK 20 H	
	Absolute Black® toner for use in Kyocera FS 1700, TK 20 H, 22 lb (10 kg) bag (AMES Certified toner)	6074
	Absolute Black® toner for use in Kyocera FS 1700, TK 20 H, 650g (20,000 pages) (AMES Certified toner)	8341
	Waste hopper bottle for use in Kyocera FS 1700, TK 20 H, 10 pack	7315
	KYOCERA FS 3900, TK 322, 320	
	Absolute Black® toner for use in Kyocera FS 3900, TK 322, 320, 465g (15,000 pages) (AMES Certified)	10979
	Smartchip™ for use in Kyocera FS 3900, TK 324, (15,000 pages) (AU)	17170
	Smartchip™ for use in Kyocera FS 3900, TK 320, (15,000 pages) (EU)	12684
	Smartchip™ for use in Kyocera FS 3900, TK 322, (15,000 pages) (USA)	11546
	KYOCERA FS 4000, TK 332, 330	
	Absolute Black® toner cartridge for Kyocera FS 4000 ,TK 332, 330,	11119
	Absolute Black® toner for use in Kyocera FS 4000 ,TK 332, 330 465g (AMES Certified toner)	14058
	Absolute Black® toner for use in Kyocera FS 4000 ,TK 332, 330 650g (20,000 pages) (AMES Certified)	10978
	Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330 (20,000 pages) (AU)	17171
	Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330 (20,000 pages) (EU)	16784
	Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330 (20,000 pages) (EU)	12685
	Smartchip™ for use in Kyocera FS 4000 ,TK 332, 330 (20,000 pages) (US)	11547
	KYOCERA FS 9100, 9500, TK 70 H	
	Absolute Black® toner for use in Kyocera FS 9100, 9500, TK 70 H, 1350g (AMES Certified)	13726
	Absolute Black® toner for use in Kyocera FS 9100, 9500, TK 70 H, 22 lb (10 kg) bag (AMES Certified)	8966
	Absolute Black® toner for use in Kyocera FS 9100, 9500, TK 70 H, 675g (use 2 per cartridge) (AMES Certified)	7599
	Waste toner bottle for use in Kyocera FS 9100, 9500, TK 70 H, 10 pack	9606
	KYOCERA FS 1920, TK 57 H, 55 H	
	Absolute Black® toner for use in Kyocera FS 1920, TK 57 H, 55 H, 22 lb (10 kg) bag (AMES Certified)	5308
	Absolute Black® toner for use in Kyocera FS 1920, TK 57 H, 55 H, 520g (AMES Certified)	6444
	KYOCERA FS 3820, TK 67, 65	
	Absolute Black® toner for use in Kyocera FS 3820, TK 67, 65, 22 lb (10 kg) bag (AMES Certified)	5254
	Absolute Black® toner for use in Kyocera FS 3820, TK 67, 65, 580g (AMES Certified)	13663
	Absolute Black® toner for use in Kyocera FS 3820, TK 67, 65, 680g (AMES Certified)	5253

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	KYOCERA FS 1035, 1135, TK 1140 MFP, TK 1142, TK 1144, TK 1147 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Kyocera FS 1035, 1135 MFP, TK 1140, 1142, 1144, 1147, 22lb (10kg) bag (AMES Certified)	17579
	Absolute Black® toner for use in Kyocera FS 1035, 1135 MFP, TK 1140, 1142, 1144, 1147, 235g (7,200 pages) (AMES Certified)	17375
	X-Generation® Black toner for use in Kyocera FS 1035, 1135 MFP, TK 1147, 1144, 1142, 1140, 22lb (10kg) bag (AMES Certified)	17581
	X-Generation® Black toner for use in Kyocera FS 1035, 1135 MFP, TK 1147, 1144, 1142, 1140, 235g (7,200 pages) (AMES Certified)	17580
	Smartchip™ for use in Kyocera FS 1035, 1135 MFP, TK 1140 (7,200 pages) (EUR)	17361
	Smartchip™ for use in Kyocera FS 1035, 1135 MFP, TK 1147 (7,200 pages) (Asia)	17831
	Smartchip™ for use in Kyocera FS 1035, 1135MFP, TK 1142 (7,200 pages) (USA)	17371
	Smartchip™ for use in Kyocera FS 1035, 1135MFP, TK 1144 (7,200 pages) (AUS)	17372
	KYOCERA FS 4020, TK 360, 362, 364	
	Absolute Black® toner for use in Kyocera FS 4020, TK 360, 362, 364, 22 lb (10kg) bag (AMES Certified)	14641
	Absolute Black® toner for use in Kyocera FS 4020, TK 360, 362, 364, 760g (AMES Certified)	14536
	Smartchip™ for use in Kyocera FS 4020, TK 364 (20,000 pages) (AU)	17176
	Smartchip™ for use in Kyocera FS 4020, TK 360 (20,000 pages) (EU)	14522
	Smartchip™ for use in Kyocera FS 4020, TK 362 (20,000 pages) (US)	16090
	KYOCERA FS 720, 820, 1016, TK 112, 110	
	Absolute Black® toner for use in Kyocera FS 720, 820, 1016, TK 112, 110, 115g (3,000 pages) (AMES Certified toner)	9115
	Absolute Black® toner for use in Kyocera FS 720, 820, 1016, TK 112, 110, FS 720, 820, 1016, 22 lb (10 kg) bag (AMES Certified)	9976
	Absolute Black® toner for use in Kyocera FS 720, 820, 1016, TK 112, 110, FS 720, 820, 1016, 225g (6,000 pages) (AMES Certified toner)	9975
	KYOCERA FS 1030, 1130 MFP, TK 1130, 1132, 1134 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Kyocera FS 1030, 1130 MFP, TK 1130, 1132, 1134, 100g (3,000 pages)	17376
	Absolute Black® toner for use in Kyocera FS 1030, TK 122, 120, 22 lb (10 kg) bag (AMES Certified)	10290
	Absolute Black® toner for use in Kyocera FS 1030, TK 122, 120, 300g(AMES Certified toner)	10289
	Smartchip™ toner for use in Kyocera FS 1030, 1130 MFP, TK 1130 (3,000 pages)	17360
	Smartchip™ toner for use in Kyocera FS 1030, 1130 MFP, TK 1132 (3,000 pages)	17369
	Smartchip™ toner for use in Kyocera FS 1030, 1130 MFP, TK 1134 (3,000 pages)	17370
	KYOCERA FS 1100, 1110, 1024, 1300, 1350, TK 132, 130, 140, 142, 1100, 1102, 1104 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Kyocera FS 1100, 1110, 1024, 1300, 1350, TK 132, 130, 140, 142, 1100, 1102, 1104, 22 lb (10 kg) bag (AMES Certified)	12617
	Absolute Black® toner for use in Kyocera FS 1300, 1350, TK 132, 130, 310g (7,200 pages) (AMES Certified toner)	12616
	Smartchip™ for use in Kyocera FS 1300, 1350, 1128, 1028, TK 134 (7,200 pages) (AU)	17158
	Smartchip™ for use in Kyocera FS 1300, TK 130 (7,200 pages) (EU)	12686
	Smartchip™ for use in Kyocera FS 1300, TK 132 (7,200 pages) (US)	16067
	KYOCERA FS 1061, 1041, MFP 1320, 1220, TK 1129, 1127, 1125, 1119, 1117, 1115	
	Absolute Black® toner for use in Kyocera FS-1061, 1041, MFP 1320, 1220, TK 1129, 1127, 1125, 1119, 1117, 1115, 22lb (10kg) bag	18908
	Absolute Black® toner for use in Kyocera FS-1061DN, TK 1129, 1127, 1125, 92g (2,100 pages)	18906
	Smartchip™ toner for use in Kyocera FS-1061DN, TK 1129, (2,100 pages)(Australia), 10 pack	18619
	KYOCERA FS C 1020 MFP, TK 152, 150	
	Absolute Black® toner for use in Kyocera FS C 1020 MFP, TK 152, 150, 200g (6,500 pages)	14760
	Absolute Black® toner for use in Kyocera FS C 1020 MFP, TK 152, 150, 22lb (10kg) bag	15742
	Absolute Cyan® toner for use in Kyocera FS C 1020 MFP, TK 152, 150, 22lb (10kg) bag	15743
	Absolute Cyan® toner for use in Kyocera FS C 1020 MFP, TK 152, 150, 200g (6,000 pages)	14761
	Absolute Magenta® toner for use in Kyocera FS C 1020 MFP, TK 152, 150, 22lb (10kg) bag	15744
	Absolute Magenta® toner for use in Kyocera FS C 1020 MFP, TK 152, 150, 200g (6,000 pages)	14762
	Absolute Yellow® toner for use in Kyocera FS C 1020 MFP, TK 152, 150, 200g (6,000 pages)	14763
	Absolute Yellow® toner for use in Kyocera FS C 1020 MFP, TK 152, 150, 22lb (10kg) bag	15745
	Smartchip™ for use in Kyocera FS C 1020 MFP, Black toner (TK 150K)(EU)(6,500 page)	14755
	Smartchip™ for use in Kyocera FS C 1020 MFP, Cyan toner (TK 150C)(EU)(6,000 page)	14756
	Smartchip™ for use in Kyocera FS C 1020 MFP, Magenta toner (TK 150M)(EU)(6,000 page)	14757
	Smartchip™ for use in Kyocera FS C 1020 MFP, Yellow toner (TK 150Y)(EU)(6,000 page)	14758
	Smartchip™ for use in Kyocera FS C 1020 MFP, TK 152, Black toner (US)(6,500 pages)	14751
	Smartchip™ for use in Kyocera FS C 1020 MFP, TK 152, Cyan toner (US)(6,000 pages)	14752
	Smartchip™ for use in Kyocera FS C 1020 MFP, TK 152, Magenta toner (US)(6,000 pages)	14753
	Smartchip™ for use in Kyocera FS C 1020 MFP, TK 152, Yellow toner (US)(6,000 pages)	14754
	Smartchip™ for use in Kyocera FS C 1020, Black (TK 154K)(6,500 pages)(Australia)	16021
	Smartchip™ for use in Kyocera FS C 1020, Cyan (TK154C)(6,000 pages)(Australia)	16022
	Smartchip™ for use in Kyocera FS C 1020, Magenta (TK154M)(6,000 pages)(Australia)	16023
	Smartchip™ for use in Kyocera FS C 1020, Yellow (TK154Y)(6,000 pages)(Australia)	16024
	KYOCERA FS 2000, TK 314, 312, 310	
	Absolute Black® toner for use in Kyocera FS 2000, TK 312, 310, 385g (12,000 pages) (AMES Certified)	10982
	Smartchip™ for use in Kyocera FS 2000, TK 314 (12,000 pages) (AU)	17169
	Smartchip™ for use in Kyocera FS 2000, TK 310 (12,000 pages) (EU)	12683
	Smartchip™ for use in Kyocera FS 2000, TK 312 (12,000 pages) (US)	11545
	KYOCERA FS 2020,TK 340, 342, 344	
	Absolute Black® toner for use in Kyocera FS 2020,TK 340, 342, 344, 22 lb (10kg) bag (AMES Certified)	15185
	Absolute Black® toner for use in Kyocera FS 2020, TK 340, 342, 344, FS 2020, 450g (AMES Certified toner)	14585
	Smartchip™ for use in Kyocera FS 2020, TK 342 (12,000 pages)(US)	17172
	Smartchip™ for use in Kyocera FS 2020, TK 344 (12,000 pages)(AU)	17173
	Smartchip™ for use in Kyocera FS 2020, TK 340 (12,000 pages)(EU)	15020
	KYOCERA FS 1900, TK 50	
	Absolute Black® toner for use in Kyocera FS 1900, TK 50, 320g (AMES Certified)	8877
	Absolute Black® toner for use in Kyocera FS 1900, TK 50 H, 22 lb (10 kg) bag (AMES Certified)	9597
	Absolute Black® toner for use in Kyocera FS 1900, TK 50 H, 480g (AMES Certified)	12287

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	KYOCERA FS 2100, TK 3104, 3102, 3100 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
•	Absolute Black® toner for use in Kyocera , FS 2100, TK 3104, 3102, 3100, 210g (12,500 pages) (AMES Certified)	18125
•	Absolute Black® toner for use in Kyocera FS 2100, TK 3104, 3102, 3100, 22lb (10kg) bag	18445
•	Smartchip™ toner for use in Kyocera FS 2100, TK 3100 (12,500 pages), 10 pack (EU)	18134
•	Smartchip™ toner for use in Kyocera FS 2100, TK 3102 (12,500 pages) 10 pack (USA)	18135
•	Smartchip™ toner for use in Kyocera FS 2100, TK 3104 (12,500 pages) 10 pack (AUS)	18755
•	X-Generation® toner for use in Kyocera FS 2100, TK 3104, 3102, 3100, 22lb (10kg) bag	18844
•	X-Generation® toner for use in Kyocera FS 2100, TK 3104, 3102, 3100,(12,500 pages)	18847
	KYOCERA FS 4100, TK 3114, 3112, 3110 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
•	Absolute Black® toner for use in Kyocera FS 4100, TK 3114, 3112, 3110, 310g (15,500 pages)	18122
•	Smartchip™ toner for use in Kyocera FS 4100, TK 3110, (15,500 pages) 10 pack (EU)	18128
•	Smartchip™ toner for use in Kyocera FS 4100 TK 3112 (15,500 pages), 10 pack (USA)	18127
•	Smartchip™ toner for use in Kyocera FS 4100 TK 3114 (15,500 pages), 10 pack (AUS)	18156
	KYOCERA FS 3800, TK 60 H	
•	Absolute Black® toner for use in Kyocera FS 3800, TK 60 H, 22 lb (10 kg) bag(AMES Certified toner)	6171
	Absolute Black® toner for use in Kyocera FS 3800, TK 60 H, 675g (AMES Certified toner)	8342
	KYOCERA FS 3920, FS 3640, 3540, 3140, 3040 MFP, TK 354, 352, 350 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Kyocera FS 3920, FS 3640, 3540, 3140, 3040 MFP,TK 350, 352, 22lb (10kg) bag (AMES Certified)	14808
	Absolute Black® toner for use in Kyocera FS 3920, FS 3640, 3540, 3140, 3040 MFP, TK 354, 352, 350, 560g(AMES Certified toner)	14586
	Smartchip™ for use in Kyocera FS 3920, TK 350 (15,000 pages) (EU)	17141
	Smartchip™ for use in Kyocera FS 3920, TK 352, FS 3920 (15,000 pages) (US)	17174
	Smartchip™ for use in Kyocera FS 3920, TK 354, FS 3920 (15,000 pages) (AU)	17175
	KYOCERA FS C 5350, 5300, TK 560, 562, 564 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564, 22lb(10kg) bag	18081
	Absolute Black® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564, 240g (12,000 pages)	17547
	Absolute Cyan® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564, 165g (10,000 pages)	17548
	Absolute Cyan® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564, 22lb (10kg) bag	18082
	Absolute Magenta® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564, 160g (10,000 pages)	17549
	Absolute Magenta® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564, 22lb(10kg) bag	18083
	Absolute Yellow® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564, 150g (10,000 pages)	17550
	Absolute Yellow® toner for use in Kyocera FS C 5350, 5300, TK 560, 562, 564, 22lb(10kg) bag	18084
	Smartchip™ for use in Kyocera FS C 5350, 5300,TK 560, Black (12,000 pages)(EU)	17212
	Smartchip™ for use in Kyocera FS C 5350, 5300, TK 560, Cyan (10,000 pages)(EU)	17213
	Smartchip™ for use in Kyocera FS C 5350, 5300,TK 560, Magenta (10,000 pages)(EU)	17214
	Smartchip™ for use in Kyocera FS C 5350, 5300,TK 560, Yellow (10,000 pages)(EU)	17215
	Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Black (12,000 pages)	17016
	Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Cyan (10,000 pages)	17017
	Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Magenta (10,000 pages)	17018
	Smartchip™ for use in Kyocera FS C 5350, 5300, TK 562, Yellow (10,000 pages)	17019
	KYOCERA FS C 5200, TK 550, 552, 554 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
•	Absolute Black® toner for use in Kyocera FS C 5200, TK 550, 552, 554, 140g (7,000 pages)	17208
•	Absolute Cyan® toner for use in Kyocera FS C 5200, TK 550, 552, 554, 100g (6,000 pages)	17209
	Absolute Magenta® toner for use in Kyocera FS C 5200, TK 550, 552, 554, 100g (6,000 pages)	17210
	Absolute Yellow® toner for use in Kyocera FS C 5200, TK 550, 552, 554, 100g (6,000 pages)	17211
	Smartchip™ for use in Kyocera FS C 5200, TK 550, Black (7,000 pages) (EU)	17685
	Smartchip™ for use in Kyocera FS C 5200, TK 550, Cyan (6,000 pages) (EU)	17686
	Smartchip™ for use in Kyocera FS C 5200, TK 550, Magenta (6,000 pages) (EU)	17687
	Smartchip™ for use in Kyocera FS C 5200, TK 550, Yellow (6,000 pages) (EU)	17688
	Smartchip™ for use in Kyocera FS C 5200, TK 552, Black (7,000 pages) (US)	17204
	Smartchip™ for use in Kyocera FS C 5200, TK 552, Cyan (6,000 pages) (US)	17205
	Smartchip™ for use in Kyocera FS C 5200, TK 552, Magenta (6,000 pages) (US)	17206
	Smartchip™ for use in Kyocera FS C 5200, TK 552, Yellow (6,000 pages) (US)	17207
	X Generation® Black toner for use in Kyocera FS C 5200, TK 550, 552, 554, 22 lb (10kg) bag	17630
	X Generation® Cyan toner for use in Kyocera FS C 5200, TK 550, 552, 554, 22 lb (10kg) bag	17631
	X Generation® Magenta toner for use in Kyocera FS C 5200, TK 550, 552, 554, 22 lb (10kg) bag	17632
	X Generation® Yellow toner for use in Kyocera FS C 5200, TK 550, 552, 554, 22 lb (10kg) bag	17633
	KYOCERA FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 180g (7,000 pages)	17465
	Absolute Black® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 594, 22lb (10kg) bag	17766
	Absolute Cyan® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 22lb (10kg) bag	17767
	Absolute Cyan® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 594, 120g	17466
	Absolute Magenta® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 100g (5,000 pages)	17467
	Absolute Magenta® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 22lb (10kg) bag	17768
	Absolute Yellow® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 100g (5,000 pages)	17468
	Absolute Yellow® toner for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, 592, 22 lb (10kg) bag	17769
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Black (7,000 pages) (EU)	17434
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Cyan (5,000 pages) (EU)	17435
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Magenta (5,000 pages) (EU)	17436
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 590, Yellow (5,000 pages) (EU)	17437
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Black (7,000 pages) (US)	17430
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Cyan (5,000 pages) (US)	17431
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Magenta (5,000 pages) (US)	17432
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 592, Yellow (5,000 pages) (US)	17433
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Black (7,000 pages) (Australia)	18446
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Cyan (5,000 pages) (Australia)	18447
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Magenta (5,000 pages) (Australia)	18448
	Smartchip™ for use in Kyocera FS C 5250, 2626, 2526, 2126, 2026 MFP, TK 594, Yellow (5,000 pages) (Australia)	18449

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	KYOCERA FS 9530, 9130, TK 712, 710	
	Absolute Black® toner for use in Kyocera TK 712, 710, FS 9530, 9130, 22 lb (10 kg) bag (AMES Certified)	13382
	Absolute Black® toner for use in Kyocera TK 712, 710, FS 9530, 9130, 675g (use 2 per cartridge) (AMES Certified)	10983
	Replacement toner cartridge for use in Kyocera TK 712, FS 9530, 9130, 1,350g	11372
	Smartchip™ for use in Kyocera TK 710, FS 9130, 9530 (40,000 pages) (EU)	17223
	Smartchip™ for use in Kyocera TK 712, FS 9530, 9130	14432
	Smartchip™ for use in Kyocera TK 714, FS 9130, 9530 (40,000 pages) (AU)	17224
	KYOCERA KM 1505, 1510, 1810	
	Absolute Black® toner for use in Kyocera KM 1505, 1510, 1810, 22 lb (10kg) bag (AMES Certified toner)	13519
	Absolute Black® toner for use in Kyocera KM 1505, 1510, 1810, 300g (AMES Certified toner)	11650
	KYOCERA KM 2530, 3035, 3530, 4030, 4035, 5035	
	Absolute Black® toner for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035, 1900g (AMES Certified toner)	14713
	Absolute Black® toner for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035, 22 lb (10 kg) bag (AMES Certified toner)	10700
	Waste hopper bottle for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035, 10 pack	10422
	KYOCERA KM 3050, 4050, 5050, TK 717, 715	
	Absolute Black® toner for use in Kyocera KM 3050, 4050, 5050, TK 717, 715, 22 lb (10 kg) bag	11373
	Absolute Black® toner for use in Kyocera KM 3050, 4050, 5050, TK 717, 715	11374
	Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 715 (34,000pages) (EU)	17225
	Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 717 (34,000pages) (US)	13690
	Smartchip™ for use in Kyocera KM 3050, 4050, 5050, TK 719 (34,000pages) (AU)	17226
	KYOCERA KM 4230, 5230, Ai 4040, 5050	
	Absolute Black® toner for use in Kyocera KM 4230, 5230, Ai 4040, 5050, 700g	11652
	KYOCERA KM Ai 2310, 3010	
	Absolute Black® toner for use in Kyocera KM Ai 2310, 3010, 315g	11653
	Absolute Black® for use in Kyocera KM 1510, 1530, 1810, Ai 2310, 4040, 22 lb (10 kg) bag	5519
	KYOCERA KM 1500, 1815, TK 100	
	Absolute Black® toner for use in Kyocera KM 1500, 1815, TK 100, 22 lb (10 kg) bag (AMES Certified toner)	8287
	Absolute Black® toner for use in Kyocera KM 1500, 1815, TK 100, 295g (AMES Certified toner)	8075
	Wiper blade for use in Kyocera™ KM 1500, 10 pack	13158
	KYOCERA KM 1525, 1530, 1570, 2030, 2070	
	Absolute Black® toner for use in Kyocera KM 1525, 1530, 1570, 2030, 2070, 22 lb (10 kg) bag (AMES Certified toner)	10257
	Absolute Black® toner for use in Kyocera KM 1525, 1530, 1570, 2030, 2070, 450g (AMES Certified toner)	11651
	Unidrum™ with gears for use in Kyocera KM 1525, 1530, 1570, 2030, 2070	12358
	Waste hopper bottle for use in Kyocera KM 1525, 1530, 1570, 2030, 2070	10421
	KYOCERA KM 1620, 1650, 2020, 2050, TK 410, 411	
	Absolute Black® toner for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411, 22 lb (10 kg) bag (AMES Certified)	10299
	Absolute Black® toner for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411, 480g (AMES Certified)	10298
	Absolute Black® toner for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411, 870g (AMES Certified)	11033
	Waste toner bottle for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411, 10 pack	10417
	Unidrum™ with gears for use in Kyocera KM 1620, 1650, 2020, 2050, TK 410, 411	13002
	Smartchip™ for use in Kyocera TK 410, KM 1620,1635, 1650, 2020, 2035, 2050 (15,000 pages) (EU)	17177
	Smartchip™ for use in Kyocera TK 412, KM 1620,1635, 1650, 2020, 2035, 2050 (15,000 pages) (US)	17178
	Smartchip™ for use in Kyocera TK 414, KM 1620,1635, 1650, 2020, 2035, 2050 (15,000 pages) (AU)	17179
	KYOCERA KM 2540, TK 677	
	Smartchip™ for use in Kyocera KM 2540, TK 677 (20,000 pages) (US)	17221
	Absolute Black toner® for use in Kyocera™ KM 2540, 2560, 3040, 3060 (TK 675, 679) 1160g	18287
	Absolute Black toner® for use in Kyocera™ KM 2540, 2560, 3040, 3060 (TK 675, 679) 22lb (10kg) bag	18274
	KYOCERA Mita TASKalfa 180, 220, KM 1620 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Kyocera Mita TASKalfa 180, 220, KM 1620, 22lb (10kg) bag (AMES Certified)	17319
	Absolute Black® toner for use in Kyocera Mita TASKalfa 180, 220, KM 1620, 870g (AMES Certified toner)	16565
	Smartchip™ for use in Kyocera TaskAlfa 180,181,222, TK435 (15,000 pages) (EU)	17180
	Smartchip™ for use in Kyocera TaskAlfa 180,181,222, TK437 (15,000 pages) (US)	17181
	Smartchip™ for use in Kyocera TaskAlfa 180,181,222, TK439 (15,000 pages) (AU)	17182
	KYOCERA Mita TaskAlfa 420i, 520i, TK 725 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Kyocera Mita TaskAlfa 420i, 520i ,TK 725, 1900g (34,000 pages)	16612
	Smartchip™ for use in Kyocera TaskAlfa 420i, 520i, TK 725 (15,000 pages) (EU)	17227
	Smartchip™ for use in Kyocera TaskAlfa 420i, 520i, TK 727 (15,000 pages) (US)	17228
	Smartchip™ for use in Kyocera TaskAlfa 420i, 520i, TK 729 (15,000 pages) (AU)	17229
	KYOCERA TaskAlfa TK 865, 250ci, 300ci	
	Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Black (20,000 pages) (EU)	17242
	Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Cyan (12,000 pages) (EU)	17243
	Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Magenta (12,000 pages) (EU)	17244
	Smartchip™ for use in Kyocera Copiadora TaskAlfa TK 865, 250ci, 300ci Yellow (12,000 pages) (EU)	17245
	KONICA MINOLTA®	
	KONICA MINOLTA BIZHUB 200, 250, 350	
	Absolute Black® toner for use in Minolta Bizhub 200, 250, 350, 10kg (22lb) bag	17976
	Unidrum® with gears for use in Konica Minolta Bizhub C 200, 203,253, 353	18573
	KONICA MINOLTA BIZHUB 160, 161	
	Absolute Black® toner for use in Minolta Bizhub 160, 161, 200g (6,000 pages)	11146

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	KONICA MINOLTA BIZHUB C 451, 550, 650	
•	SuMMIT® drum for CMY with gears for use in Konica Minolta Bizhub C 451, 550, 650	18574
	KONICA MINOLTA BIZHUB 223, 283, 363, 423	
	Absolute Black® toner for use in Minolta Bizhub 223, 283, 363, 423 10kg (22lb) bag	17977
	KONICA MINOLTA BIZHUB C 203, 253, 353	
•	Absolute Black toner® for use in Konica Minolta Bizhub C 253, 353, 22lb (10kg) bag	18537
•	Absolute Cyan toner® for use in Konica Minolta Bizhub C 253, 353, 22lb (10kg) bag	18538
•	Absolute Magenta toner® for use in Konica Minolta Bizhub C 253, 353, 22lb (10kg) bag	18539
	Absolute Yellow toner® for use in Konica Minolta Bizhub C 253, 353, 22lb (10kg) bag	18544
	Smartchip™ Black drum unit for use in Konica Minolta Bizhub C 203, 253 (A0DE02F)	18073
	Smartchip™ Black for use in Konica Minolta Bizhub C 203,253 (A0D7132)	18069
	Smartchip™ Cyan drum unit for use in Konica Minolta Bizhub C 203, 253 (A0DE0HF)	18074
	Smartchip™ Cyan for use in Konica Minolta Bizhub C 203,253 (A0D7432)	18070
	Smartchip™ Magenta drum unit for use in Konica Minolta Bizhub C 203, 253 (A0DE0CF)	18075
	Smartchip™ Magenta for use in Konica Minolta Bizhub C 203,253 (A0D7332)	18071
	Smartchip™ Yellow for use in Konica Minolta Bizhub C 203,253 (A0D7232)	18072
	Smartchip™ Yellow drum unit for use in Konica Minolta Bizhub C 203, 253 (A0DE06F)	18076
	Smartchip™ Yellow for use in Konica Minolta Bizhub C 20 (A0DK253, TN318Y) (8,000 pages) (EU)	15068
	Smartchip™ Black drum unit for use in Konica Minolta Bizhub C 253, 353 (120,000 pages)	16308
	Smartchip™ Black for use in Konica Minolta Bizhub C 253, 353 (26,000 pages)	16304
	Smartchip™ Cyan drum unit for use in Konica Minolta Bizhub C 253, 353 (90,000 pages)	16309
	Smartchip™ Cyan for use in Konica Minolta Bizhub C 253, 353 (20,000 pages)	16305
	Smartchip™ Magenta drum unit for use in Konica Minolta Bizhub C 253, 353 (90,000 pages)	16310
	Smartchip™ Magenta for use in Konica Minolta Bizhub C 253, 353 (20,000 pages)	16306
	Smartchip™ Yellow drum unit for use in Konica Minolta Bizhub C 253, 353 (90,000 pages)	16312
	Smartchip™ Yellow for use in Konica Minolta Bizhub C 253, 353 (20,000 pages)	16307
•	Unidrum® with gears for use in Konica Minolta Bizhub C 200, 203,253, 353 (special order)	18573
	KONICA MINOLTA Di 181, 350	
	Absolute Black® toner for use in Minolta Di 181, 350, 22 lb (10 kg) bag	5200
	KONICA MINOLTA Di 200, 250, 350	
•	Absolute Black® toner for use in Minolta Di 200, 250, 350, 400g	8968
•	Unidrum™ with gears for use in Minolta Di 200, 250, 251, 350, 351 (67,000 pages)	12671
	Wiper blade for use in Minolta Di 200, 250	12670
	KONICA MINOLTA Di 550, 470, 450	
	Absolute Black™ toner for use in Minolta Di 550, 470, 450, 1100g	17814
	Unidrum™ F with gears for use in Minolta Di 450, 470, 550 (240,000 pages)	12541
	Wiper blade for use in Minolta Di 450, 470, 550	12572
	KONICA MINOLTA Di 551, 650, 5510, 7210	
	Wiper blade for use in Minolta Di 551, 650, 5510, 7210	12343
	KONICA MINOLTA Di 750	
	Absolute Black® toner for use in Minolta Di 750, 22 lb (10 kg) bag	10225
	KONICA MINOLTA EP 1030, 1031, 1053	
	Unidrum™ F with gears for use in Minolta EP 1030, 1031, 1053 (30,000 pages)	9002
	Wiper blade for use in Minolta EP 1030, 1031, 1053	12545
	KONICA MINOLTA EP 1050, 1052, 1054, 1080, 1082, 1083, 2010	
	Unidrum™ F with gears for use in Minolta EP 1050, 1052, 1054, 1080, 1082, 1083, 2010 (180,000 pages)	12546
	Wiper blade for use in Minolta EP 1050, 1052, 1054, 1080, 1082, 1083, 2010	12547
	KONICA MINOLTA EP 2120	
	Unidrum™ S with gears for use in Minolta EP 2120	5689
	KONICA MINOLTA EP 8015, 6001, 6000, 5050	
	Absolute Black® toner for use in Minolta EP 8015, 6001, 6000, 5050, 22lbs (10kgs) bag	12302
	KONICA MINOLTA CF 2002, 3102	
	Unidrum™ gearless for use in Minolta CF 2002, 3102,	11963
	LEXMARK®	
	LEXMARK X 950, 952, 954 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Smartchip™ Black toner for use in Lexmark X 950, 952, 954 (X950X2KG) (32,000 pages)	17513
	Smartchip™ CMYK drum unit for use in Lexmark C 950, 952, X 954, 952, 950 (C950X71G, C950X73G) (115,000 pages)	18304
	Smartchip™ Cyan toner for use in Lexmark X 950, 952, 954 (X950X2CG) (22,000 pages)	17518
	Smartchip™ Magenta toner for use in Lexmark X 950, 952, 954 (X950X2MG) (22,000 pages)	17519
	Smartchip™ Yellow toner for use in Lexmark X 950, 952, 954 (X950X2YG) (22,000 pages)	17520
	X-Generation® Black toner for use in Lexmark C 950, 952, X 950, 952, 954, (32,000 pages)	17634
	X-Generation® Cyan toner for use in Lexmark C 950, 952, X 950, 952, 954, (22,000 pages)	17635
•	X-Generation® Magenta toner for use in Lexmark C 950, 952, X 950, 952, 954, (22,000 pages)	17636
	X-Generation® Yellow toner for use in Lexmark C 950, 952, X 950, 952, 954, (22,000 pages)	17637
	X-Generation® drum with gears and insert for use in Lexmark C 950, 952, X 954, 952, 950	18298
	LEXMARK X 734, 736, 738	
•	Smartchip™ Black for use in Lexmark C 730, 734, 736, X 734, 736, 738, (8,000 pages)	15800
•	Smartchip™ Cyan for use in Lexmark C 730, 734, 736, X 734, 736, 738, (6,000 pages)	15801
•	Smartchip™ Magenta for use in Lexmark C 730, 734, 736, X 734, 736, 738, (6,000 pages)	15802

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	Smartchip™ Yellow for use in Lexmark C 730, 734, 736, X 734, 736, 738, (6,000 pages)	15803
•	X-Generation® Black toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, (8,000 pages)	15792
•	X-Generation® Black toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, 22lb (10kg) bag	16739
•	X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, (6,000 pages)	15793
•	X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, 22lb (10kg) bag	16740
•	X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, (6,000 pages)	15794
•	X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, 22lb (10kg) bag	16741
•	X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, (6,000 pages)	15795
•	X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, 22lb (10kg) bag	16742
LEXMARK X 560		
•	Absolute Black® toner developer for use in Lexmark X 560n, 70g	13424
•	Absolute Black® toner for use in Lexmark X 560n (10,000 pages)	13412
•	Absolute Cyan™ toner developer for use in Lexmark X 560n, 70g	13425
•	Absolute Cyan™ toner for use in Lexmark X 560n (10,000 pages)	13413
•	Absolute Cyan™ toner for use in Lexmark X 560n	13417
•	Absolute Magenta™ toner developer for use in Lexmark X 560n, 70g	13426
•	Absolute Magenta™ toner for use in Lexmark X 560n (10,000 pages)	13414
•	Absolute Magenta™ toner for use in Lexmark X 560n	13418
•	Absolute Yellow™ toner developer for use in Lexmark X 560n, 70g	13427
•	Absolute Yellow™ toner for use in Lexmark X 560n (10,000 pages)	13416
•	Absolute Yellow™ toner TBAg for use in Lexmark X 560n	13419
•	Clear seal™ adhesive for use in Lexmark X 560n, 50 pack	13797
•	Developer chamber plastic seal for use in Lexmark X 560n, 100 pack	13799
•	Fill hole plastic seal for use in Lexmark X 560n toner, 100 pack	13798
•	Lexmark X 560n Smartchip™ Black (4,000 pages)	13792
•	OPC drum cover for use in Lexmark X 560n, 10 pack	14125
•	Smartchip™ Black for use in Lexmark X 560n (10,000 pages)	13420
•	Smartchip™ Cyan for use in Lexmark X 560n (10,000 pages)	13421
•	Smartchip™ Cyan for use in Lexmark X 560n (4,000 pages)	13793
•	Smartchip™ Magenta for use in Lexmark X 560n (10,000 pages)	13422
•	Smartchip™ Magenta for use in Lexmark X 560n (4,000 pages)	13794
•	Smartchip™ Yellow for use in Lexmark X 560n (10,000 pages)	13423
•	Smartchip™ Yellow for use in Lexmark X 560n (4,000 pages)	13795
•	SuMMIT® Drum with gears for use in Lexmark X 560n	14049
•	Unidrum™ with gears for use in Lexmark X 560n	13796
LEXMARK X 203, 204		
•	SuMMIT® drum w/gears for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, X 203, 204 (Dell 1700, 1720) 5 pack	12021
•	Superchip™ Universal for use in Lexmark E/X 230, 232, 240, 330, 332, 340, 342, 203, 204 Dell 1700, 1710 (2,500 pages)	13435
•	Superchip™ Universal for use in Lexmark E/X 330, 332, 340, 342, 203, 204, Dell 1700, 1710 (6,000 pages)	13450
•	Superchip™ Universal for use in Lexmark E/X 330, 332, 340, 342, 203, 204 (6,000 pages),10 pack	14841
•	Superchip™ Universal for use in Lexmark E/X 230, 232, 240, 330, 332, 340, 342, 203, 204 (2.5K pages)10 pack	14857
•	Unidrum™ with gears for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, X 203, 204 (Dell 1700, 1720)	16465
•	SuMMIT® drum w/gears for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, X 203, 204, (Dell 1700, 1720), 100 pack	18416
LEXMARK X 215		
•	PCR roller for use in Lexmark X 215, 10 pack	7027
•	Smartchip™ fuse for toner cartridge for use in Lexmark X 215, 10 pack	7372
•	Wiper blade for use in Lexmark X 215, 10 pack	7424
•	Absolute Black® toner for use in Lexmark X 215, 100g	9166
•	Developer roller for use in Lexmark X 215, 9 pack	9264
•	Unidrum™ with gears for use in Lexmark X 215	15210
LEXMARK X 230, 232, 238, 330, 332, 340		
•	PCR for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, 10 pack (Dell 1700, 1720, IBM 1412)	5922
•	Absolute Black® toner for use in Lexmark E 230, 232, 238, 330, 332, 340, X 204, 75g (2,500 pages)	9253
•	Absolute Black® toner for use in Lexmark E 230, 232, 238, 330, 332, 340, X 204, Dell 1700, 22 lb (10 kg) bag	9254
•	Absolute Black® toner for use in Lexmark E 230, 232, 238, 330, 332, 340, X 204 Dell 1700, 185g (6,000 pages)	9295
•	Shipping lock for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, 10 pack (Dell 1700, 1720, IBM 1412)	9616
•	Doctor bar for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, Dell 1720 10 pack (15,000 pages)	9897
•	Supply roller for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, Dell P 1720, 20 pack	10392
•	Absolute MICR™ toner for use in Lexmark E 230, 232, 238, 330, 332, 340, Dell 1700, 205g	11964
•	SuMMIT® drum w/gears for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, X 203, 204 (Dell 1700, 1720), 5 pack	12021
•	Recovery blade for use in Lexmark E 230, 232, 234, 330, 332, 50 pack (thickness 0.05mm)	12040
•	Superchip™ Universal for use in Lexmark E/X 230, 232, 240, 330, 332, 340, 342, 203, 204 Dell 1700, 1710 (2,500 pages)	13435
•	Superchip™ Universal for use in Lexmark E/X 230, 232, 240, 330, 332, 340, 342, 203, 204 (2.5K pages) 10 pack	14857
•	Unidrum™ with gears for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, X 203, 204 (Dell 1700, 1720)	16465
•	X-Generation® Wiper blade for use in Lexmark E 230, 232, 238, 250, 260, 330, 332, 340, 350, 360, 450, 460, Dell 1720, 5 pack	16955
•	X-Generation® Doctor blade for use in Lexmark E 230, 232, 330, 332, 340, Dell 1700, IBM 1412, 1512, 10 pack	17149
•	Developer roller for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, Dell 1720, 5 pack	17922
•	SuMMIT® drum w/gears for use in Lexmark E 230, 232, 238, 250, 330, 332, 340, 350, 450, X 203, 204, (Dell 1700, 1720), 100 pack	18416
LEXMARK X 260, 360, 460		
•	Black toner for use in Lexmark T 650, E 460, 260, 360 22lb (10kg) bag	2016
•	Developer roller end seal for use in Lexmark T 640, 630, 620, 610, 520, E 460, 360, 260, X 264, 363, 364 (left & right) 100 sets	10659
•	X-Generation® toner for use in Lexmark E 460, 360, 260, X 364, 363, 264, Dell 2330, 2350, 22 lb (10 kg) bag	14022
•	SuMMIT® OPC drum with gears for use in Lexmark T 650, 652, 654, E 460, 360, 260, X 364, 363, 264 (No shaft)	14023
•	Developer roller for use in Lexmark E 460, 360, 260, X 364, 363, 264, 5 pack	14026
•	Doctor bar, 10 pack for use in Lexmark E 460, 360, 260, X 364, 363, 264	14041
•	X-Generation® toner for use in Lexmark E 460, 360, 260, X 364, 363, 264, 95g (3,500 pages)	14045
•	Superchip™ Universal for use in Lexmark E/X 460, 360, 260, Dell 2330, 2350, 3330, 3335 (3,500 pages)	14933

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Absolute MICR™ toner for use in Lexmark E 260, 360, 460, X 264, 363, 364, 95g (3,000pages)	15398
	Absolute MICR™ toner for use in Lexmark E 260, 360, 460, X 264, 363, 364, 250g (10,000pages)	15399
	Unidrum™ OPC drum with gears & shaft for use in Lexmark E 460, 360, 260, X 364, 363, 264	15965
	SuMMIT® OPC drum with gears & shaft for use in Lexmark E 460, 360, 260, X 364, 363, 264	16301
	X-Generation® Wiper blade for use in Lexmark E 230, 232, 238, 250, 260, 330, 332, 340, 350, 360, 450, 460, Dell 1720, 5 pack	16955
	Absolute Black® toner for use in Lexmark E 460, 360, 260, X 364, 363, 264, 95g (3,500 pages)	17253
	Absolute Black® toner for use in Lexmark E 460, 360, 260, X 364, 363, 264, Dell 2330, 2350, 22 lb (10 kg) bag	17256
	SuMMIT® OPC drum with gears & shaft for use in Lexmark E 460, 360, 260, X 364, 363, 264, 100 pack	18115
	Absolute Black® toner for use in Lexmark E 460, 360, 260, X 364, 363, 264, Dell 2330, 2350, 1kg	18514
	Superchip™ Universal for use in Lexmark E/X 460, 360, 260, Dell 2330, 2350, 3330, 3335 (18,000 pages)	18635
	Superchip™ Universal for use in Lexmark E/X 460, 360, 260, Dell 2330, 2350, 3330, 3335 (15,000 pages)	18636
	Smartchip™ for use in Lexmark E 260, 360, 460 (3,500 pages)(E260A11L)	18644
	Doctor bar sealing foam for use in Lexmark E 260, 360, 460, 50 pack	18758
	Superchip™ Universal for use in Lexmark E/X 260, 360, 460, Dell 2330, 2350, 3330, 3335 (9,000 pages)	18924
	LEXMARK X 364	
	X-Generation® toner for use in Lexmark E 460, 360, 260, X 364, 363, 264, Dell 2330, 2350, 22 lb (10 kg) bag	14022
	SuMMIT® OPC drum with gears for use in Lexmark T 650, 652, 654, E 460, 360, 260, X 364, 363, 264 (No shaft)	14023
	Doctor bar, 10 pack for use in Lexmark E 460, 360, 260, X 364, 363, 264	14041
	X-Generation® toner for use in Lexmark E 460, 360, X 364, 363, 264 MFP, 250g (9,000 pages)	14043
	X-Generation® toner for use in Lexmark E 460, 360, 260, X 364, 363, 264, 95g (3,500 pages)	14045
	Smartchip™ toner (3,500 pages) for use in Lexmark X 364, 363, 264	14921
	Smartchip™ toner (9,000 pages) for use in Lexmark X 364, 363, 264	14922
	Unidrum™ OPC drum with gears & shaft for use in Lexmark E 460, 360, 260, X 364, 363, 264	15965
	Superchip™ Universal for use in Lexmark X 364, 363, 264 (9,000 pages), 10 pack	16186
	Superchip™ Universal for use in Lexmark X 364, 363, 264 (3,500 pages), 10 pack	16187
	SuMMIT® OPC drum with gears & shaft for use in Lexmark E 460, 360, 260, X 364, 363, 264	16301
	SuMMIT® OPC drum with gears & shaft for use in Lexmark E 460, 360, 260, X 364, 363, 264, 100 pack	18115
	LEXMARK X 422	
	Shipping lock for use in Lexmark T 420, X 422, 10 pack	6008
	Superchip™ Universal for use in Lexmark X 422 (12,000 pages)	7536
	Absolute Black® toner for use in Lexmark T 420, X 422, 255g (10,000 pages)	8393
	Absolute Black® toner for use in Lexmark T 420, X 422, 22 lb (10 kg) bag	8394
	Wiper blade for use in Lexmark T 420, 430, X 422, IBM 1422, 10 pack	8396
	Absolute Black® toner for use in Lexmark T 430, X 422, IBM 1422, 325g (12,000 pages)	9623
	Absolute Black® toner for use in Lexmark T 430, X 422, IBM 1422, 155g (6,000 pages)	9625
	Absolute Black® toner for use in Lexmark T 430, X 422, IBM 1422, 22 lb (10kg) bag	10780
	Developer roller for use in Lexmark T 420, 430, X 422, 10 pack	11857
	SuMMIT® drum w/gears for use in Lexmark T 420, 430, X 422, IBM 1422, 5 pack	12025
	LEXMARK X 463, 464, 466	
	Smartchip™ for use in Lexmark X 463, 464, 466, Dell 3333, 3335, Ricoh MF 2400, 3400 (15,000 pages)	18926
	Smartchip™ for use in Lexmark X 466, 464, 463, Dell 3335, 3333, Ricoh SP 4410, 4400 (15,000 pages)	18925
	LEXMARK X 646, 644, 640, 630	
	Superchip™ Universal High Yield for use in Lexmark T/X 646, 644, 640, 630, 620, 520	5109
	Superchip™ Universal Extra High Yield for use in Lexmark T/X 646,644, 640, 630	5110
	Superchip™ Universal High Yield for use in Lexmark T/X 646, 644, 640, 630, 620, 520, 10 pack	14829
	Superchip™ Universal Extra High Yield for use in Lexmark T/X 646, 644, 640, 630, 10 pack	14834
	LEXMARK X 652, 654	
	Cleaning wand for use in Lexmark T 640, 650, 652	12709
	SuMMIT® OPC drum with gears for use in Lexmark T 650, 652, 654, E 460, 360, 260, X 364, 363, 264 (No shaft)	14023
	Shipping lock for use in Lexmark T 650, 652, 654, 10 pack	14303
	X-Generation® toner for use in Lexmark T 650, 652, 654, 725g (25,000 pages)	15382
	X-Generation® toner for use in Lexmark T 656, 654, 652, 650, 1000g (36,000 pages)	15383
	X-Generation® toner for use in Lexmark T 650, 652, 654, 10 kg (22 lb) bag	15578
	Unidrum™ F with gears for use in Lexmark T 650, 652, 654 (with shaft)	15888
	Unidrum™ OPC with gears & shaft for use in Lexmark T 650, 654, 652 (High yield)	16235
	Absolute MICR™ toner for use in Lexmark T 650, 654, 652, 650g	16298
	Absolute MICR™ toner for use in Lexmark T 650, 654, 652, 22lb (10kg) bag	16576
	SuMMIT® OPC drum with gears & shaft for use in Lexmark T 650, 652, 654	16613
	X-Generation® Wiper blade for use in Lexmark T 650, 652, 654, 10 pack	17073
	Developer roller for use in Lexmark T 650, 652, 654, 5 pack	17075
	Absolute Black® toner for use in Lexmark T 650, 652, 654, 725g (25,000 pages)	17126
	SuMMIT® OPC drum with gears & shaft for use in Lexmark T 650, 654, 652, 100 pack	18116
	Smartchip™ for use in Lexmark T 650, 652, 654, 656 (25,000pages) (T650H21E)	18620
	Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (25,000 pages)	18639
	Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (36,000 pages)	18640
	Smartchip™ for use in Lexmark T 650, 652, 654, 656 (25,000pages) (T650H11L)	18647
	Smartchip™ for use in Lexmark T 650, 652, 654, 656 (25,000pages) (T650H11P)	18648
	Developer roller for use in Lexmark T 650, 652, 654, 5 pack	18668
	Absolute Black® toner for use in Lexmark T 650, 652, 654, 725g (25,000 pages)	18728
	Absolute Black® toner for use in Lexmark T 650, 652, 654, 22lb (10kg) bag	18729
	Doctor bar for use in Lexmark T 650, 652, 654, 10 pack	18828
	Absolute Black® toner for use in Lexmark T 656, 654, 652, 650, 1000g (36,000 pages)	18914
	LEXMARK X 656, 658	
	Absolute Black® toner for use in Lexmark T 656, 654, 652, 650, 1000g (36,000 pages)	18914
	Smartchip™ for use in Lexmark T 650, 652, 654, 656 (25,000pages) (T650H11L)	18647
	Smartchip™ for use in Lexmark T 650, 652, 654, 656 (25,000pages) (T650H11P)	18648

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	Smartchip™ for use in Lexmark T 650, 652, 654, 656 (25,000pages) (T650H21E)	18620
•	Smartchip™ for use in Lexmark T 654, 656 (36,000pages)	18875
•	Smartchip™ for use in Lexmark T 654, 656 (36,000pages)	18732
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (25,000 pages) (T654H21A)	18937
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (36,000 pages) (T654X21A)	18936
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (36,000 pages) (T654X21E)	18935
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (36,000 pages) (T654X21L)	18934
•	Smartchip™ for use in Lexmark T 654, 656, Dell 5530, 5230 (36,000 pages) (T654X21P)	18933
•	Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (25,000 pages)	18639
•	Superchip™ Universal for use in Lexmark T/X 650, 652, 654, 656, 658, Dell 5530, 5535 (36,000 pages)	18640
•	X-Generation® toner for use in Lexmark T 656, 654, 652, 650, 1000g (36,000 pages)	15383
LEXMARK X 734		
•	Developer roller cover for use in Lexmark C 520, 522, 524, 530, 532, 534, 730, 734, 736, 10 pack	14120
•	Developer roller for use in Lexmark C 736, 734, 730, 534, 532, 530, 524, 522, 520, 10 pack	18876
•	Doctor blade for use in Lexmark C 736, 734, 730, 534, 532, 530, 524, 522, 520, 10 pack	18877
•	Seal toner hopper fill plug for use in Lexmark C 520, 522, 524, 530, 532, 534, 734, 736, 100 pack (32mm)	11626
•	Smartchip™ Black for use in Lexmark C 730, 734, 736, X 734, 736, 738, (8,000 pages)	15800
•	Smartchip™ Cyan for use in Lexmark C 730, 734, 736, X 734, 736, 738, (6,000 pages)	15801
•	Smartchip™ Magenta for use in Lexmark C 730, 734, 736, X 734, 736, 738, (6,000 pages)	15802
•	Smartchip™ Yellow for use in Lexmark C 730, 734, 736, X 734, 736, 738, (6,000 pages)	15803
•	Supply adder roller for use in Lexmark C 730, 734, 736, 10 pack	18623
•	X-Generation® Black toner for use in Lexmark C 730, 734, 736, X 734, 736, 738 (8,000 pages)	15792
•	X-Generation® Black toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, 22lb (10kg) bag	16739
•	X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, X 734, 736, 738 (6,000 pages)	15793
•	X-Generation® Cyan toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, 22lb (10kg) bag	16740
•	X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, X 734, 736, 738 (6,000 pages)	15794
•	X-Generation® Magenta toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, 22lb (10kg) bag	16741
•	X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, X 734, 736, 738 (6,000 pages)	15795
•	X-Generation® Yellow toner for use in Lexmark C 730, 734, 736, X 734, 736, 738, 22lb (10kg) bag	16742
LEXMARK X 782		
•	Absolute Cyan™ toner for use in Lexmark C 770, 772, 780, 782, (10,000 pages)	11905
•	Absolute Magenta™ toner for use in Lexmark C 770, 772, 780, 782, (10,000 pages)	11906
•	Absolute Yellow™ toner for use in Lexmark C 770, 772, 780, 782, (10,000 pages)	11907
•	Smartchip™ Black for use in Lexmark C 770, 772, 780, 782 (10,000 pages)	14053
•	Smartchip™ Cyan for use in Lexmark C 770, 772, 780, 782 (10,000 pages)	14054
•	Smartchip™ Magenta for use in Lexmark C 770, 772, 780, 782 (10,000 pages)	14055
•	Smartchip™ Yellow for use in Lexmark C 770, 772, 780, 782 (10,000 pages)	14056
•	Absolute Cyan™ toner for use in Lexmark C 772, 780, 782, (16,500 pages)	14057
•	Absolute Black® toner for use in Lexmark C 772, 780, 782, (16,500 pages)	14059
•	Absolute Magenta™ toner for use in Lexmark C 772, 780, 782, (16,500 pages)	14060
•	Absolute Yellow™ toner for use in Lexmark C 772, 780, 782, (16,500 pages)	14061
•	Smartchip™ Black for use in Lexmark C 780, 782, X 782 (16,500 pages)	14062
•	Smartchip™ Cyan for use in Lexmark C 780, 782, X 782 (16,500 pages)	14063
•	Smartchip™ Magenta for use in Lexmark C 780, 782, X 782 (16,500 pages)	14064
•	Smartchip™ Yellow for use in Lexmark C 780, 782, X 782 (16,500 pages)	14065
•	Absolute Black® toner for use in Lexmark C 770, 772, 780, 782, 22lb (10kg) bag	14515
•	Absolute Cyan™ toner for use in Lexmark C 770, 772, 780, 782, 22lb(10kg) bag	14516
•	Absolute Magenta™ toner for use in Lexmark C 770, 772, 780, 782, 22lb(10kg) bag	14517
•	Absolute Yellow™ toner for use in Lexmark C 770, 772, 780, 782, 22lb(10kg) bag	14518
•	Shipping lock set for use in Lexmark® C 750, 752, 760, 780, 782, X 782, 10 sets	14642
•	X-Generation® OPC drum gearless for use in Lexmark C 780, 782, X 782	16251
•	X-Generation® Black toner for use in Lexmark C 770, 772, 780, 782 (16,500 pages)	16254
•	X-Generation® Cyan toner for use in Lexmark C 770, 772, 780, 782 (16,500 pages)	16255
•	X-Generation® Magenta toner for use in Lexmark C 770, 772, 780, 782 (16,500 pages)	16256
•	X-Generation® Yellow toner for use in Lexmark C 770, 772, 780, 782 (16,500 pages)	16257
•	X-Generation® Black toner for use in Lexmark C 770, 772, 780, 782 22lb (10kg) bag	17781
•	X-Generation® Cyan toner for use in Lexmark C 770, 772, 780, 782 22lb (10kg) bag	17782
•	X-Generation® Magenta toner for use in Lexmark C 770, 772, 780, 782 22lb (10kg) bag	17783
•	X-Generation® Yellow toner for use in Lexmark C 770, 772, 780, 782, 22lb (10kg) bag	17784
•	X-Generation® Black toner for use in Lexmark C 770, 772, 780, 782 (10,000 pages)	18510
•	X-Generation® Cyan toner for use in Lexmark C 770, 772, 780, 782 (10,000 pages)	18511
•	X-Generation® Magenta toner for use in Lexmark C 770, 772, 780, 782 (10,000 pages)	18512
•	X-Generation® Yellow toner for use in Lexmark C 770, 772, 780, 782 (10,000 pages)	18513
LEXMARK X 850		
•	Developer unit seal for use in Lexmark® W 850 dn, 50 pack	14590
•	Developer unit seal for use in Lexmark® X 850, 852, 854, 50 pack	14592
•	Smartchip™ toner for use in Lexmark W 850 (W850H21G)	16614
•	Absolute Black® toner for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864, 650g (35,000 pages)	16787
•	Unidrum™ with gears for use in Lexmark W 850 (60,000 pages)	16788
•	Smartchip™ toner for use in Lexmark X 850, 852, 854 (35,000 pages)	17150
•	Smartchip™ drum unit for use in Lexmark X 850, 852 854 (60,000 pages) (X850H22G)	18092
•	Smartchip™ toner for use in Lexmark W 850 (35,000 pages) (W85021G)	18567
•	Smartchip™ drum unit for use in Lexmark W 850 (60,000 pages) (W850H22G)	18622
•	Developer for drum unit for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864 (60,000 pages)	18990
•	SuMMIT® OPC drum with gears for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864	18991
LEXMARK X 860		
•	Absolute Black® toner for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864, 650g (35,000 pages)	16787
•	Smartchip™ toner for use in Lexmark X 860, 862, 864 (X860H21G) (35,000pages)	17884

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	Smartchip™ drum unit for use in Lexmark X 860, 862, 864 (W860H22G) (60,000pages)	17885
•	Developer for drum unit for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864 (60,000 pages)	18990
•	SuMMit® OPC drum with gears for use in Lexmark W 850, X 850, 852, 854, 860, 862, 864	18991
LEXMARK MX 310, 410, 510, 511, 610, 611		
•	Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (10,000 pages)(US)	18654
•	Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (10,000 pages)(EUR)	18660
•	Absolute Black® toner for use in Lexmark MS 410, 510, 610, MX 310, 410, 510, 511, 610, 611, 320g (10,000 pages)	18679
•	X-Generation® Black toner for use in Lexmark MS 410, 510, 610, MX 310, 410, 510, 511, 610, 611, 290g (10,000 pages)	18688
•	X-Generation® Black toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812, 22lb (10kg) bag	18693
•	Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (10,000 pages)(SE Asia)	18698
•	Smartchip™ for use in Lexmark MX 310, 410, 510, 511, 610, 611 (10,000 pages)(Latin America)	18713
•	X-Generation® Black toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812, 1kg	18715
•	Absolute Black® toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812, 22lb (10kg) bag	18883
LEXMARK MX 710, 711, 810, 811, 812		
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811, 812 (6,000 pages)(US)	18662
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811, 812 (25,000 pages)(US)	18663
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811 (45,000 pages)(US)	18664
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811 (6,000 pages)(EUR)	18665
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811, 812 (25,000 pages)(EUR)	18666
•	Absolute Black® toner for use in Lexmark MS/MX 710, 711, 810, 811, 812, 710g (25,000 pages)	18681
•	Absolute Black® toner for use in Lexmark MS 711, 811, MX 710, 711, 810, 811, 812, 1,150g (45,000 pages)	18682
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811 (45,000 pages)(EUR)	18687
•	X-Generation® Black toner for use in Lexmark MS/MX 710, 711, 810, 811, 812, 650g (25,000 pages)	18689
•	X-Generation® Black toner for use in Lexmark MS 711, 811, MX 710, 711, 810, 811, 812, 1,050g (45,000 pages)	18692
•	X-Generation® Black toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812, 22lb (10kg) bag	18693
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811 (45,000 pages)(SE Asia)	18702
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811, 812 (25,000 pages) (SE Asia)	18703
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811, 812 (6,000 pages) (SE Asia)	18704
•	X-Generation® Black toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812, 1kg	18715
•	Smartchip™ for use in Lexmark MX 710, 711, 810, 811, 812 (25,000 pages)(Latin America)	18796
•	Absolute Black® toner for use in Lexmark MS/MX 310, 410, 510, 511, 610, 611, 710, 711, 810, 811, 812, 22lb (10kg) bag	18883
LEXMARK X 930, 935		
•	PCR roller for use in Lexmark C 935, 930, X 945, 940, 10 pack	11968
•	Smartchip™ Black toner for use in Lexmark C 935, 930	11965
•	Smartchip™ CMYK drum unit for use in Lexmark C 935, 930, X 945, 940	11971
•	Smartchip™ Cyan toner for use in Lexmark C 935, 930	11966
•	Smartchip™ Magenta toner for use in Lexmark C 935, 930	11967
•	Smartchip™ Yellow toner for use in Lexmark C 935, 930	11969
•	Unidrum™ gearless for use in Lexmark C 935, 930, X 945, 940	11970
•	X-Generation® Black toner for use in Lexmark C 935, 930, X 940, 945, 700g (38,000 pages)	17593
•	X-Generation® Cyan toner for use in Lexmark C 935, 930, X 940, 945, 500g (24,000 pages)	17594
•	X-Generation® Magenta toner for use in Lexmark C 935, 930, X 940, 945, 500g (24,000 pages)	17597
•	X-Generation® Yellow toner for use in Lexmark C 935, 930, X 940, 945, 500g (24,000 pages)	17600
LEXMARK X 940, 945		
•	Absolute Black® toner for use in Lexmark C 935, 930, X 940, 945, 695g (38,000 pages)	11912
•	Absolute Cyan® toner for use in Lexmark C 935, 930, X 945, 940, 495g (24,000 pages)	11913
•	Absolute Magenta® toner for use in Lexmark C 935, 930, X 945, 940, 495g (24,000 pages)	11914
•	Absolute Yellow® toner for use in Lexmark C 935, 930, X945, 940, 495g (24,000 pages)	11915
•	PCR roller for use in Lexmark C 935, 930, X 945, 940, 10 pack	11968
•	Smartchip™ CMYK drum unit for use in Lexmark C 935, 930, X 945, 940	11971
•	Smartchip™ Black toner for use in Lexmark X 940, 945 (X945X2KG)(36,000pages) (WWW)	18417
•	Smartchip™ Cyan toner for use in Lexmark X 940, 945 (X945X2CG)(22,000pages) (WWW)	18418
•	Smartchip™ Magenta toner for use in Lexmark X 940, 945 (X945X2MG)(22,000pages) (WWW)	18419
•	Smartchip™ Yellow toner for use in Lexmark X 940, 945 (X945X2YG)(22,000pages) (WWW)	18420
•	Unidrum™ gearless for use in Lexmark C 935, 930, X 945, 940	11970
•	X-Generation® Black toner for use in Lexmark C 935, 930, X 940, 945, 700g (38,000 pages)	17593
•	X-Generation® Cyan toner for use in Lexmark C 935, 930, X 940, 945, 500g (24,000 pages)	17594
•	X-Generation® Magenta toner for use in Lexmark C 935, 930, X 940, 945, 500g (24,000 pages)	17597
•	X-Generation® Yellow toner for use in Lexmark C 935, 930, X 940, 945, 500g (24,000 pages)	17600
LEXMARK C 540, 543, 544, X 548, 546 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)		
•	Absolute Black® toner for use in Lexmark C 540, 543, 544 (2,500 pages)	13841
•	Absolute Cyan™ toner for use in Lexmark C 540, 543, 544 (2,000 pages)	13842
•	Absolute Magenta™ toner for use in Lexmark C 540, 543, 544 (2,000 pages)	13843
•	Absolute Yellow™ toner for use in Lexmark C 540, 543, 544 (2,000 pages)	13844
•	Developer roller for use in Lexmark C 544, 543, 540, X 548, 546, 544, 543, 540, 5 pack	18890
•	Smartchip™ Black toner for use in Lexmark C 540, 543, 544 (C544H2KG)(2,500 pages)	13845
•	Smartchip™ Cyan toner for use in Lexmark C 540, 543, 544 (C544H2CG)(2,000 pages)	13846
•	Smartchip™ Magenta toner for use in Lexmark C 540, 543, 544 (C544H2MG)(2,000 pages)	13847
•	Smartchip™ Yellow toner for use in Lexmark C 540, 543, 544 (C544H2YG)(2,000 pages)	13848
OKIDATA®		
OKIDATA CX 2033 MFP, C 6050, 6051, 6150, MC 560 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)		
•	Absolute Yellow™ toner for use in Okidata C 6050, 6051, 6150, CX 2033 MFP (6,000 pages)	14223
•	Drum unit toner sealing cover for use in Okidata C 5000, 5500, 5900, 6000, 6100, 6150, CX 2033, 10 pack	14301
•	Smartchip™ Black toner for use in Okidata CX 2033 MFP (43865768) (8,000 pages) (US region)	14224
•	Smartchip™ Cyan toner for use in Okidata CX 2033 MFP (43865719) (6,000 pages) (US region)	14225

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	Smartchip™ drum fuse for use in Okidata CX 2033, MC 560 MFP (20,000 pages)	14228
•	Smartchip™ Magenta toner for use in Okidata CX 2033 MFP (43865718) (6,000 pages) (US region)	14226
•	Smartchip™ Yellow toner for use in Okidata CX 2033 MFP (43865717) (6,000 pages) (US region)	14227
•	Unidrum™ with gears for use in Okidata CX 2033 MFP (20,000 pages)	14232
•	X-Generation® Black toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP (8,000 pages)	17266
•	X-Generation® Cyan toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP (6,000 pages)	17267
•	X-Generation® Magenta toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP (6,000 pages)	17268
•	X-Generation® Yellow toner for use in Okidata C 610, 6150, MC 560, CX 2033 MFP (6,000 pages)	17269
OKIDATA C 130, 110, MC 160 MFP		
	Absolute Black® toner for use in Okidata MC 160 MFP, C 130, 110, 115g (2,500 pages)	14568
	Absolute Cyan™ toner for use in Okidata MC 160 MFP, C 130, 110, 115g (2,500 pages)	14569
	Absolute Magenta™ toner for use in Okidata MC 160 MFP, C 130, 110, 115g (2,500 pages)	14570
	Absolute Yellow™ toner for use in Okidata MC 160 MFP, C 130, 110, 115g (2,500 pages)	14571
	Developer roller cover for use in Okidata C 130, 110, MC 160 MFP, 10 pack	18288
	Developer roller cover for use in Okidata MC 160 MFP, 10 pack	14581
	Smartchip™ Black for use in Okidata MC 160 MFP, C 130, 110 (44250716) (2,500 pages) (US)	14572
	Smartchip™ Cyan for use in Okidata MC 160 MFP, C 130, 110 (44250715) (2,500 pages) (US)	14573
	Smartchip™ Magenta for use in Okidata MC 160 MFP, C 130, 110 (44250714) (2,500 pages) (US)	14574
	Smartchip™ Yellow for use in Okidata MC 160 MFP, C 130, 110 (44250713) (2,500 pages) (US)	14575
OKIDATA C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)		
	Smartchip™ Black for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU) (44469803) (3,500 pages)	17727
	Smartchip™ Cyan for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU) (44469706) (2,000 pages)	17728
	Smartchip™ Magenta for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU) (44469705) (2,000 pages)	17729
	Smartchip™ Yellow for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562 (EU) (44469704) (2,000 pages)	17730
•	Unidrum™ drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562 MFP	17793
	Absolute Black® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562, 68g (3,500 pages)	17719
	Absolute Yellow® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562, 35g (3,000 pages)	17722
	Absolute Cyan® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562, 40g (3,000 pages)	17720
	Absolute Magenta® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562, 45g (3,000 pages)	17721
	Unidrum™ drum for use in Okidata C 310, 330, 510, 530, 511, 531, MC 562 MFP	17793
	Color cartridges chip holder and retainer for use in Okidata C 310, 330, 510, 511, 530, 531, MC 562, 561, 361 MFP, 10 pack	18566
OKIDATA B 8300		
	Absolute Black® developer carrier for use in Okidata B 8300, 390g	11937
	Absolute Black® toner for use in Okidata B 8300, 810 grams	9092
	Smartchip™ for use in Okidata B 8300	11936
	Unidrum™ gearless for use in Okidata B 8300	11938
OKIDATA B 930		
	Developer carrier for drum unit for use in Okidata B 930	13037
	Absolute Black® toner for use in Okidata B 930, 650g (52117101) (33,000 pages)	13036
	Smartchip™ Black for use in Okidata C 930, 910 (15,000 pages)(WWW)	18283
	Smartchip™ Cyan for use in Okidata C 930, 910 (15,000 pages)(WWW)	18284
	Smartchip™ Drum for use in Okidata B 930	13038
	Smartchip™ Magenta for use in Okidata C 930, 910 (15,000 pages)(WWW)	18285
	Smartchip™ Yellow for use in Okidata C 930, 910 (15,000 pages)(WWW)	18286
	Unidrum™ with gears for use in Okidata B 930	13040
OKIDATA B 6500		
	Absolute Black® toner for use in Okidata B 6500, 1010g (22,000 pages)	13309
	Absolute Black® toner for use in Okidata B 6500, 620g (13,000 pages)	13308
	Absolute Black® toner for use in Okidata B 6500, 820g (22,500 pages)	11231
	Doctor blade for use in Okidata B 6500, 10 pack	11710
	Drum shutter spring for use in Okidata B 6500, 6300, 6200, 100 pack	11989
	Smartchip™ for use in Okidata B 6500 (13,000 pages) (EU)	13311
	Smartchip™ for use in Okidata B 6500 (18,000 pages) (USA)	11234
	Smartchip™ for use in Okidata B 6500 (22,000 pages) (09004462) (EU)	13310
	SuMMiT® drum with gears for use in Okidata B 6500	15230
	X-Generation® Doctor blade for use in Okidata B 6500, 5 pack	17923
	X-Generation® Wiper blade for use in Okidata B 6500, 10 pack	17924
OKIDATA C 5100		
	Absolute Black® toner for use in Okidata C 5100, 160g (5,000 pages)	9934
	Absolute Black® toner for use in Okidata C 5100, 190g (6,000 pages)	8555
	Absolute Yellow™ toner for use in Okidata C 5100, 160g (5,000 pages)	9937
	Absolute Yellow™ toner for use in Okidata C 5100, 190g (6,000 pages)	8558
	Absolute Yellow™ toner for use in Okidata C 5100, 22 lb (10 kg) bag	8804
	Drum unit wiper blade for use in Okidata C 5100, 5200, 5250 5300, 5400, 5450, 10 pack	9884
	Smartchip™ fuse for drum unit for use in Okidata C 5100, 5200, 5250 5300, 5400, 5450, 10 pack	9362
	Unidrum™ with gears for use in Okidata C 5100, 5200, 5250 5300, 5400, 5450	16543
OKIDATA C 511, 531, MC 562 MFP		
	Absolute Black® toner for use in Okidata C 511, 531, MC 562 MFP, 135g (7,000 pages)	17741
	Absolute Cyan® toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP, 70g (5,000 pages)	17724
	Absolute Magenta® toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP, 75g (5,000 pages)	17725
	Absolute Yellow® toner for use in Okidata C 310, 330, 511, 530, 531, MC 351, 352, 361, 362, 561, 562, 35g (3,000pages)	17722
	Absolute Yellow® toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP, 58g (5,000 pages)	17726
	Smartchip™ Black toner for use in Okidata C 511, 531, MC 562 MFP (EU)(44469508)(7,000 pages)	17736
	Smartchip™ Cyan toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP (EU)(44469724)(5,000 pages)	17732
	Smartchip™ Magenta toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP (EU)(44469723)(5,000 pages)	17733
	Smartchip™ Yellow toner for use in Okidata C 511, 530, 531, MC 561, 562 MFP (EU)(44469722)(5,000 pages)	17734

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	OKIDATA C 810, 830	
	Absolute Black® toner for use in Okidata C 810, 830, TBAg (8,000 pages)	17378
	Absolute Cyan® toner for use in Okidata C 810, 830 (8,000 pages)	14229
	Absolute Magenta® toner for use in Okidata C 810, 830 (8,000 pages)	14230
	Absolute Yellow® toner for use in Okidata C 810, 830 (8,000 pages)	14231
	Smartchip™ Black toner for use in Okidata C 810, 830 (44059108)(8,000 pages) (EU)	15422
	Smartchip™ Cyan toner for use in Okidata C 810, 830 (44059107)(8,000 pages) (EU)	15423
	Smartchip™ Magenta toner for use in Okidata C 810, 830 (44059106)(8,000 pages) (EU)	15424
	Smartchip™ Yellow toner for use in Okidata C 810, 830 (44059105)(8,000 pages) (EU)	15425
	OKIDATA C 9000	
	Absolute Black® toner for use in Okidata C 9000, 460g (15,000 pages)	8389
	Drum unit cover for use in Okidata C9000, 9100, 9200, 9300, 9400, 9500, 10 pack	14564
	Drum unit wiper blade for use in Okidata C 9000	9885
	Smartchip™ fuse for OPC drum unit for use in Okidata C 9000, 10 pack	9648
	Unidrum™ with gears for use in Okidata C 9000	7522
	OKIDATA C 3000, 3100, 3200	
	Absolute Cyan® Glossy toner for use in Okidata C 3000, 3100, 3200, 110g (3,000 pages)	16995
	Absolute Cyan® toner for use in Okidata C 3000, 3100, 3200, 110g (3,000 pages)	9322
	Absolute Cyan® Glossy toner for use in Okidata C 3000, 3100, 3200, 22 lb (10 kg) bag	10209
	Absolute Magenta® Glossy toner for use in Okidata C 3000, 3100, 3200, 22 lb (10 kg) bag	10210
	Absolute Magenta® Glossy toner for use in Okidata C 3000, 3100, 3200, 110g (3,000 pages)	16996
	Absolute Magenta® toner for use in Okidata C 3000, 3100, 3200, 110g (3,000 pages)	9323
	Absolute Yellow® Glossy toner for use in Okidata C 3000, 3100, 3200, 110g (3,000 pages)	16997
	Absolute Yellow® Glossy toner for use in Okidata C 3000, 3100, 3200, 22 lb (10 kg) bag	10211
	Absolute Yellow® toner for use in Okidata C 3000, 3100, 3200, 110g (3,000 pages)	9324
	Drum unit wiper blade for use in Okidata C 3000, 3100, 3200, 10 pack	11314
	Smartchip™ drum unit fuse for use in Okidata C 3000, 3100, 3200, 10 pack	11313
	Unidrum™ with gears for use in Okidata C 3000, 3100, 3200	16545
	OKIDATA C 3600, 3530, 3400, 3450, 3300, MC 360	
	Absolute Cyan™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360 (2,500 pages)	10830
	Absolute Black® Glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360 (2,500 pages)	10829
	Absolute Black® Glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360 22lb (10kgs) bag	14496
	Absolute Cyan™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360 22lb (10kgs) bag	14497
	Absolute Magenta™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360 (2,500 pages)	10831
	Absolute Magenta™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360 22lb (10kg) bag	14498
	Absolute Yellow™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360 (2,500 pages)	10832
	Absolute Yellow™ glossy toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, MC 360 22lb (10kg) bag	14499
	Drum unit toner sealing cover for use in Okidata C 3600, 3400, 3300, MC 360, 10 pack	14306
	Smartchip™ Black for use in Okidata C 3300, 3600, 3400, 3450, 3530 (43459304) (2,500 pages)	16267
	Smartchip™ Black toner for use in Okidata C 3450, 3600 (43459332)(2,500 pages) (EU)	13612
	Smartchip™ Black toner for use in Okidata C 3450, 3600 (43459436)(1,500 pages) (EU)	13608
	Smartchip™ Cyan for use in Okidata C 3300, 3600, 3400, 3450, 3530 (3459303)(2,000 pages)	16268
	Smartchip™ Cyan toner for use in Okidata C 3450, 3600 (43459331)(2,500 pages) (EU)	13613
	Smartchip™ fuse drum unit for use in Okidata C 3600, 3400, 3300, MC 360, 10 pack	10838
	Smartchip™ Magenta for use in Okidata C 3300, 3600, 3400, 3450, 3530 (43459302) (2,000 pages)	16269
	Smartchip™ Magenta toner for use in Okidata C 3450, 3600 (43459330)(2,500 pages) (EU)	13614
	Smartchip™ Magenta toner for use in Okidata C 3450, 3600 (43459434)(1,500 pages) (EU)	13610
	Smartchip™ Yellow for use in Okidata C 3300, 3600, 3400, 3450, 3530 (43459301) (2,000 pages)	16270
	Smartchip™ Yellow toner for use in Okidata C 3450, 3600 (43459329) (2,500 pages) (EU)	13615
	Smartchip™ Yellow toner for use in Okidata C 3450, 3600 (43459433) (1,500 pages) (EU)	13611
	X-Generation® Black toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360, 70g	17715
	X-Generation® Cyan toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360, 55g	17716
	X-Generation® Magenta toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360, 60g	17717
	X-Generation® Yellow toner for use in Okidata C 3600, 3530, 3400, 3450, 3300, 301, 321, MC 360, 55g	17718
	OKIDATA C 5700, 5750, 5600, 5650	
	Absolute Cyan™ Glossy toner for use in Okidata C 5700, 5750, 5600, 5650 (2,000 pages)	11162
	Absolute Magenta™ Glossy toner for use in Okidata C 5700, 5750, 5600, 5650 (2,000 pages)	11163
	Absolute Yellow™ Glossy toner for use in Okidata C 5700, 5750, 5600, 5650 (2,000 pages)	11164
	OKIDATA C 5900, 5800, 5500, CX 2032 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Cyan™ Glossy toner for use in Okidata C 5900, 5800, 5500 (2,000 pages)	11748
	Absolute Black® Glossy toner for use in Okidata C 5900, 5800, 5500 (2,000 pages)	11747
	Absolute Black® Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032, (6,000 pages)	10612
	Absolute Black® Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032, 22 lb (10 kg) bag	10616
	Absolute Cyan™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032 (5,000 pages)	10613
	Absolute Cyan™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032, 22 lb (10 kg) bag	10617
	Absolute Magenta™ Glossy toner for use in Okidata C 5900, 5800, 5500 (2,000 pages)	11749
	Absolute Magenta™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032 (5,000 pages)	10614
	Absolute Magenta™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032, 22 lb (10 kg) bag	10618
	Absolute Yellow™ Glossy toner for use in Okidata C 5900, 5800, 5500 (2,000 pages)	11750
	Absolute Yellow™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032 (5,000 pages)	10615
	Absolute Yellow™ Glossy toner for use in Okidata C 5900, 5800, 5500, CX 2032, 22 lb (10 kg) bag	10619
	Drum unit toner sealing cover for use in Okidata C 5000, 5500, 5900, 6000, 6100, 610, 6150, CX 2033, 10 pack	14301
	Smartchip™ Black Toner for use in Okidata C 5900, 5800, 5550 (43324424)(6,000 pages) (EU/Asia Region)	11957
	Smartchip™ Cyan Toner for use in Okidata C 5900, 5800, 5550 (43324423)(5,000 pages) (EU/Asia Region)	11958
	Smartchip™ fuse for drum unit for use in Okidata C 6100, 6050, 6000, 5900, 5800, 5500, 610, 10 pack	10695
	Smartchip™ Magenta Toner for use in Okidata C 5900, 5800, 5550 (43324422)(5,000 pages) (EU/Asia Region)	11959
	Smartchip™ Yellow Toner for use in Okidata C 5900, 5800, 5550 (43324421)(5,000 pages) (EU/Asia Region)	11960

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Unidrum™ drum with gears for use in Okidata C 6100, 6000, 5900, 5800, 5500	10620
	OKIDATA C 6100, 5550 MFP	
	Absolute Black® Glossy toner for use in Okidata C 6100, 5550 MFP, (6,000 pages)	10629
	Absolute Black® toner for use in Okidata B 6100, 510 grams	8364
	Absolute Cyan™ glossy toner for use in Okidata C 6100, 5550 MFP (5,000 pages)	10630
	Absolute Magenta™ glossy toner for use in Okidata C 6100, 5550 MFP (5,000 pages)	10631
	Absolute MICR™ toner for use in Okidata B 6100, 480g	8365
	Absolute Yellow™ glossy toner for use in Okidata C 6100, 5550 MFP (5,000 pages)	10632
	Doctor blade for use in Okidata B 6100, 10 pack	8367
	Drum unit toner sealing cover for use in Okidata C 5000, 5500, 5900, 6000, 6100, 610, 6150, CX 2033, 10 pack	14301
	PCR roller for use in Okidata B 6100, 10 pack	8890
	Seal adhesive for use in Okidata B 6100, 50 pack	8891
	Smartchip™ Black for use in Okidata C 6100, 5550 MFP (43324420)(6,000 pages) USA	11402
	Smartchip™ Black for use in Okidata C 6100, 5550 MFP (43324420)(6,000 pages) USA	18251
	Smartchip™ Cyan for use in Okidata C 6100, 5550 MFP (43324419)(5,000 pages) USA	18252
	Smartchip™ fuse for drum unit for use in Okidata C 6100, 6050, 6000, 5900, 5800, 5500, 610, 10 pack	10695
	Smartchip™ Magenta for use in Okidata C 6100, 5550 MFP (43324418)(5,000 pages) USA	18253
	Smartchip™ Yellow for use in Okidata C 6100, 5550 MFP (43324417)(5,000 pages) USA	11405
	Smartchip™ Yellow for use in Okidata C 6100, 5550 MFP (43324417)(5,000 pages) USA	18254
	Unidrum™ drum with gears for use in Okidata C 6100, 6000, 5900, 5800, 5500	10620
	Wiper blade for use in Okidata B 6100, 10 pack	8862
	OKIDATA C 7000, 7300, 7400, 7500	
	Absolute Black® Glossy toner for use in Okidata C 7000, 7300, 7400, 7500, 22 lb (10 kg) bag	11039
	Absolute Black® Glossy toner for use in Okidata C 7000, 7300, 7400, 7500, 320g (10,000 pages)	11043
	Absolute Cyan™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500, 320g (10,000 pages)	11044
	Absolute Cyan™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500, 22 lb (10 kg) bag	11040
	Absolute Cyan™ toner for use in Okidata C 7000, 7300, 7400, 7500, 22 lb (10 kg) bag	8597
	Absolute Cyan™ toner for use in Okidata C 7000, 7300, 7400, 7500, 320g (10,000 pages)	8386
	Absolute Cyan™ toner for use in Okidata C 7000, 7300, 7400, 7500, 375g (12,000 pages)	8771
	Absolute Magenta™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500, 22 lb (10 kg) bag	11041
	Absolute Magenta™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500, 320g (10,000 pages)	11045
	Absolute Magenta™ toner for use in Okidata C 7000, 7300, 7400, 7500, 22 lb (10 kg) bag	8598
	Absolute Magenta™ toner for use in Okidata C 7000, 7300, 7400, 7500, 320g (10,000 pages)	8387
	Absolute Magenta™ toner for use in Okidata C 7000, 7300, 7400, 7500, 375g (12,000 pages)	8772
	Absolute Yellow™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500, 22 lb (10 kg) bag	11042
	Absolute Yellow™ glossy toner for use in Okidata C 7000, 7300, 7400, 7500, 320g (10,000 pages)	11046
	Absolute Yellow™ toner for use in Okidata C 7000, 7300, 7400, 7500, 22 lb (10 kg) bag	8599
	Absolute Yellow™ toner for use in Okidata C 7000, 7300, 7400, 7500, 320g (10,000 pages)	8388
	Absolute Yellow™ toner for use in Okidata C 7000, 7300, 7400, 7500, 375g (12,000 pages)	8773
	Drum unit toner sealing cover for use in Okidata C 7000, 7300, 7500, 10 pack	14296
	Okidata C 7000, 9000 GEAR set for drum (336 per box)	751
	Smartchip™ fuse for OPC drum unit for use in Okidata C 7000, 7300, 7500, 10 pack	9992
	Unidrum™ with gear for use in Okidata C 7000, 7300, 7500	8913
	OKIDATA C 710	
	Absolute Cyan™ Glossy toner for use in Okidata C 710 (11,500 pages)	13043
	Absolute Magenta™ Glossy toner for use in Okidata C 710 (11,500 pages)	13044
	Absolute Yellow™ Glossy toner for use in Okidata C 710 (11,500 pages)	13045
	Smartchip™ Black for use in Okidata C 710, 711 (44318608)(EU)(11,000 pages)	15092
	Smartchip™ Cyan for use in Okidata C 710, 711 (44318607)(EU)(11,500 pages)	15093
	Smartchip™ Magenta for use in Okidata C 710, 711 (44318606)(EU)(11,500 pages)	15094
	Smartchip™ Yellow for use in Okidata C 710, 711 (44318605)(EU)(11,500 pages)	15095
	OKIDATA C 8600, 8800	
	Absolute Black® Glossy toner for use in Okidata C 8600, 8800, (6,000 pages)	11928
	Absolute Cyan™ glossy toner for use in Okidata C 8600, 8800 (6,000 pages)	11929
	Absolute Magenta™ glossy toner for use in Okidata C 8600, 8800 (6,000 pages)	11930
	Absolute Yellow™ glossy toner for use in Okidata C 8600, 8800 (6,000 pages)	11931
	Drum unit sealing cover for use in Okidata C 8600, 8800, 10 pack	15241
	Smartchip™ Black toner for use in Okidata C 8600, 8800 (6,000 pages)	11932
	Smartchip™ Cyan toner for use in Okidata C 8600, 8800 (6,000 pages)	11933
	Smartchip™ Magenta toner for use in Okidata C 8600, 8800 (6,000 pages)	11934
	Smartchip™ OPC drum unit fuse for use in Okidata C 8600, 8800, 10 pack	13028
	Smartchip™ Yellow toner for use in Okidata C 8600, 8800 (6,000 pages)	11935
	SuMMIT® drum with gears for use in Okidata C 8600, 8800	16264
	X-Generation® Black glossy toner for use in Okidata C 8600, 8800 (6,000 pages)	13105
	X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 1kg	16099
	X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 22 lb (10kg) bag	12721
	X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800 (6,000 pages)	13106
	X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 1kg	16100
	X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 22 lb (10 kg) bag	12722
	X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800 (6,000 pages)	13107
	X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 1kg	16101
	X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 22 lb (10kg) bag	12723
	X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800 (6,000 pages)	13108
	X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 1kg	16102
	X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 22 lb (10 kg) bag	12724
	OKIDATA C 9600, 9800	
	Absolute Black® Glossy toner for use in Okidata C 9600, 9800, (15,000 pages)	10621
	Absolute Black® Glossy toner for use in Okidata C 9600, 9800, 22 lb (10 kg) bag	11315

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Absolute Black™ glossy toner for use in Okidata C 9600, 9800, 1kg	14576
	Absolute Cyan™ glossy toner for use in Okidata C 9600, 9800 (15,000 pages)	10622
	Absolute Cyan™ glossy toner for use in Okidata C 9600, 9800, 1kg	14582
	Absolute Cyan™ glossy toner for use in Okidata C 9600, 9800, 22 lb (10 kg) bag	11316
	Absolute Magenta™ glossy toner for use in Okidata C 9600, 9800 (15,000 pages)	10623
	Absolute Magenta™ glossy toner for use in Okidata C 9600, 9800, 1kg	14578
	Absolute Magenta™ glossy toner for use in Okidata C 9600, 9800, 22 lb (10 kg) bag	11317
	Absolute Yellow™ glossy toner for use in Okidata C 9600, 9800 (15,000 pages)	10624
	Absolute Yellow™ glossy toner for use in Okidata C 9600, 9800, 1kg	14579
	Absolute Yellow™ glossy toner for use in Okidata C 9600, 9800, 22 lb (10 kg) bag	11318
	Drum unit toner sealing cover for use in Okidata C 9600, 9800, 10 pack	14307
	Smartchip™ Black for use in Okidata C 9600, 9800 (42918904)(15,000 pages)	10625
	Smartchip™ Cyan for use in Okidata C 9600, 9800 (42918903)(15,000 pages)	10626
	Smartchip™ Magenta for use in Okidata C 9600, 9800 (42918902)(15,000 pages)	10627
	Smartchip™ OPC drum unit fuse for use in Okidata C 9600, 9800, 10 pack	10849
	Smartchip™ Yellow for use in Okidata C 9600, 9800 (42918901)(15,000 pages)	10628
	Unidrum™ drum with gears for use in Okidata C 9600, 9800	10850
	X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 1kg	16099
	X-Generation® Black glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 22 lb (10kg) bag	12721
	X-Generation® Black glossy toner for use in Okidata C 9600, 9650, 9800, 9850, 360g (15,000 pages)	12290
	X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 1kg	16100
	X-Generation® Cyan glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 22 lb (10 kg) bag	12722
	X-Generation® Cyan glossy toner for use in Okidata C 9600, 9650, 9800, 9850, 360g (15,000 pages)	13617
	X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 1kg	16101
	X-Generation® Magenta glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 22 lb (10kg) bag	12723
	X-Generation® Magenta glossy toner for use in Okidata C 9600, 9650, 9800, 9850, 360g (15,000 pages)	13618
	X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 1kg	16102
	X-Generation® Yellow glossy toner for use in Okidata C 8600, 8800, 9600, 9650, 9800, 9850, 22 lb (10 kg) bag	12724
	X-Generation® Yellow glossy toner for use in Okidata C 9600, 9650, 9800, 9850, 360g (15,000 pages)	13619
	OKIDATA CX 2366 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Okidata CX 2366, TBAg (9,000 pages)	14336
	Absolute Cyan™ toner for use in Okidata CX 2366, TBAg (9,000 pages)	14337
	Absolute Magenta™ toner for use in Okidata CX 2366, TBAg (9,000 pages)	14338
	Absolute Yellow™ toner for use in Okidata CX 2366, TBAg (9,000 pages)	14339
	Smartchip™ Black toner for use in Okidata CX 2366, (44059236) (9,000 pages)	14340
	Smartchip™ Cyan toner for use in Okidata CX 2366 (44059235) (9,000 pages)	14341
	Smartchip™ Magenta toner for use in Okidata CX 2366 (44059234) (9,000 pages)	14342
	Smartchip™ Yellow toner for use in Okidata CX 2366, (44059233) (9,000 pages)	14343
	OKIDATA ES 3640 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Smartchip™ Yellow for use in Okidata ES 3640 Pro (43837105) (16,500 pages)	17485
	Smartchip™ Black for use in Okidata ES 3640 Pro (43837108) (16,500 pages)	17482
	Smartchip™ Cyan for use in Okidata ES 3640 Pro (43837107) (16,500 pages)	17483
	Smartchip™ Black for use in Okidata ES 3640 (42918928) (15,000 pages)	16177
	Smartchip™ Cyan for use in Okidata ES 3640 (42918927) (15,000 pages)	16178
	Smartchip™ Magenta for use in Okidata ES 3640 (42918925) (15,000 pages)	16180
	Smartchip™ Magenta for use in Okidata ES 3640 Pro (43837106) (16,500 pages)	17484
	Smartchip™ Yellow for use in Okidata ES 3640 (42918926) (15,000 pages)	16179
	OKIDATA B 431, 411, MB 491, 471, 461 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Okidata B 431, 411, MB 491, 471, 461, 235g (10,000 pages)	17573
	Smartchip™ for use in Okidata B 431, 411, MB 491, 471, 461 (3,000 pages) (44574702) (EU)	15100
	Smartchip™ for use in Okidata B 431, MB 461, 471, 491 (44574901) (10,000 pages) (US, Latin America)	17297
	OKIDATA B 710, 720, 730	
•	Absolute Black® toner for use in Okidata B 710, 720, 730, 700g (15,000 pages)	18439
•	Clear Seal™ adhesive for use in Okidata B 6200, 6300, 6500, 710, 720, 730, 50 pack	7208
•	Smartchip™ for use in Okidata B 710, 720, 730 (15,000 pages)	18394
•	SuMMIT® drum with gears for use in Okidata B 6500, 710, 720, 730	15230
•	X-Generation® Doctor blade for use in Okidata B 6200, 6300, 6500, 710, 720, 730, 5 pack	17923
•	X-Generation® Wiper blade for use in Okidata B 6500, 710, 720, 730, 10 pack	17924
	OKIDATA MB 260, 280, 290 MFP	
	Absolute black® toner for use in Okidata MB 260, 280, 290 MFP, 175g (5,500 pages)	14601
	Smartcard™ reset smartchip for use in Okidata MB 260, 280, 290 MFP (56123401) 3,000 pages (US)	14288
	Smartcard™ toner reset smartchip for use in Okidata MB 260, 280, 290 MFP (56123402) 5,500 pages	14600
	Unidrum™ with gears for use in Okidata MB 290, 280, 260	14930
	OKIDATA MC 160 MFP, C 130, 110	
	Absolute Black® toner for use in Okidata MC 160 MFP, C 130, 110, 115g (2,500 pages)	14568
	Absolute Cyan™ toner for use in Okidata MC 160 MFP, C 130, 110, 115g (2,500 pages)	14569
	Absolute Magenta™ toner for use in Okidata MC 160 MFP, C 130, 110, 115g (2,500 pages)	14570
	Absolute Yellow™ toner for use in Okidata MC 160 MFP, C 130, 110, 115g (2,500 pages)	14571
	Developer roller cover for use in Okidata C 130, 110, MC 160 MFP, 10 pack	18288
	Developer roller cover for use in Okidata MC 160 MFP, 10 pack	14581
	Smartchip™ Black for use in Okidata MC 160 MFP, C 130, 110 (44250716) (2,500 pages) (US)	14572
	Smartchip™ Cyan for use in Okidata MC 160 MFP, C 130, 110 (44250715) (2,500 pages) (US)	14573
	Smartchip™ Magenta for use in Okidata MC 160 MFP, C 130, 110 (44250714) (2,500 pages) (US)	14574
	Smartchip™ Yellow for use in Okidata MC 160 MFP, C 130, 110 (44250713) (2,500 pages) (US)	14575
	OKIDATA MC 860 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Okidata MC 860, TBAg (9,500 pages)	14310

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Absolute Cyan™ toner TBAg for use in Okidata MC 860 (10,000 pages)	14311
	Absolute Magenta™ toner TBAg for use in Okidata MC 860 (10,000 pages)	14312
	Absolute Yellow™ toner TBAg for use in Okidata MC 860 (10,000 pages)	14313
	Smartchip™ Black drum unit toner for use Okidata MC 860 (44064012) (20,000 pages) (EU)	15554
	Smartchip™ Black toner for use in Okidata MC 860 (44059212) (9,500 pages) (EU)	15550
	Smartchip™ Black toner for use in Okidata MC 860 (44059216) (9,500 pages)	14314
	Smartchip™ Cyan drum unit toner for use Okidata MC 860 (44064011) (20,000 pages) (EU)	15555
	Smartchip™ Cyan toner for use in Okidata MC 860 (44059211) (10,000 pages) (EU)	15551
	Smartchip™ Cyan toner for use in Okidata MC 860 (44059215) (10,000 pages)	14315
	Smartchip™ Magenta drum unit toner for use Okidata MC 860 (44064009) (20,000 pages) (EU)	15557
	Smartchip™ Magenta drum unit toner for use Okidata MC 860 (44064010) (20,000 pages) (EU)	15556
	Smartchip™ Magenta toner for use in Okidata MC 860 (44059210) (10,000 pages) (EU)	15552
	Smartchip™ Magenta toner for use in Okidata MC 860 (44059214) (10,000 pages)	14316
	Smartchip™ Yellow toner for use in Okidata MC 860 (44059209) (10,000 pages) (EU)	15553
	Smartchip™ Yellow toner for use in Okidata MC 860 (44059213) (10,000 pages)	14317
	OKIDATA 5900, 5780, 5750, 5700, 5680, 4515	
	Absolute Black® toner for use in Okidata 5900, 5780, 5750, 5700, 5680, 4515, 100g	5636
	PANASONIC®	
	PANASONIC DP 2000, 2500, 3000	
	Absolute Black® toner for use in Panasonic DP 2000, 2500, 3000, 22lb (10kg)	13912
	Absolute Black® toner for use in Panasonic DP 2000, 2500, 3000, 585g	16715
	Absolute Black® toner for use in Panasonic DP 2000, 2500, 3000, 585g kit, 6 pack	11678
	PANASONIC WORKIO DP 310, 2330, 3010, 3030	
	Unidrum™ drum with gears for use in Panasonic Workio DP 2310, 2330, 3010, 3030 (60,000 pages)	10297
	PANASONIC UF 9000, 8000, 7000, UG 5530, 5540	
	Absolute Black® toner for use in Panasonic UF 9000, 8000, 7000, UG 5530, 160g (5,000 pages)	10293
	SuMMIT® OPC drum with gears for use in Panasonic UF 9000, 8000, 7000, UG 5530, 5540	10294
	Hopper fill plug for use in Panasonic UF 9000, 8000, 7000, UG 5530, 5540, 100 pack	10718
	Developer roller for use in Panasonic UF 9000, 8000, 7000, UG 5530, 5540, 10 pack	11087
	Developer roller cover for use in Panasonic UF 9000, 8000, 7000, UG 5530, 5540, 100 pack	11169
	Absolute Black® toner for use in Panasonic UF 9000, 8000, 7000, UG 5540, 320g (10,000 pages)	11170
	Wiper blade for use in Panasonic UF 9000, 8000, 7000, UG 5530	11409
	Absolute Black® toner for use in Panasonic UF 9000, 8000, 7000, UG 5540, 210g	13340
	Common top for use in Panasonic UF 9000, 8000, 7000, UG 5530, 5540	14731
	Absolute Black® toner for use in Panasonic UF 9000, 8000, 7000, UG 5540, 22lb (10kg) bag	15872
	OPC drum with gears for use in Panasonic UF 9000, 8000, 7000, UG 5530, 5540	16472
	SuMMIT® OPC drum gearless for use in Panasonic UF 9000, 8000, 7000, UG 5530, 5540	18998
	RICOH®	
	RICOH AFICIO 200, 250	
	Absolute Black® toner for use in Ricoh Aficio 200, 250, 22 lb (10 kg) bag	9470
	SuMMIT® toner for use in Ricoh Aficio 200, 250, 360g	8735
	Developer for use in Ricoh Aficio 200, 250, 22 lb (10 kg) bag	8793
	Developer for use in Ricoh Aficio 200, 250, 345g	8794
	Drum with gears for use in Ricoh Aficio 200, 250 F	7272
	Drum with gears for use in Ricoh Aficio 200, 250 S	8548
	Wiper blade for use in Ricoh Aficio 200, 250, 10 pack	5148
	RICOH AFICIO 350, 450	
	Absolute Black® toner for use in Ricoh Aficio 350, 450, 22 lb (10 kg) bag	9469
	Absolute Black® toner for use in Ricoh Aficio 350, 450, 220 lb (100 kg)	6953
	Absolute Black® toner for use in Ricoh Aficio 350, 450, 700g	8734
	Unidrum™ F with gears for use in Ricoh Aficio 350, 450, 450, 1035, 2035, 2045, 3035, 3045 (150,000 pages)	7412
	Unidrum™ S with gears for use in Ricoh Aficio 340, 350, 450 (150,000 pages)	7271
	Wiper blade for use in Ricoh Aficio 350, 450, 450, 1035, 2035, 2045, 3035, 3045	12575
	X-Generation® Wiper blade for Ricoh Aficio 350, 450, 450, 1035, 2035, 2045, 3035, 3045 (150,000 pages)	16522
	RICOH AFICIO 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085	
	Unidrum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085 (720,000 pages)	7270
	Unidrum™ S with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085, 1105 (720,000 pages)	8547
	Wiper blade for use in Ricoh Aficio 550, 650, 850	12553
	RICOH AFICIO 1015, 1018	
	Unidrum™ F with gears for use in Ricoh Aficio 1015, 1018, 1022, 1027, 1032, 1113, 2015, 2022, 2027	12712
	Wiper blade for use in Ricoh Aficio 1015, 1018	12550
	RICOH AFICIO 1022, 1027, 2022	
	Drum with gears for use in Ricoh Aficio 1022, 1027, 2022	12713
	Unidrum™ F with gears for use in Ricoh Aficio 1015, 1018, 1022, 1027, 1032, 1113, 2015, 2022, 2027	12712
	RICOH AFICIO 1060, 1075, 2051, 2060	
	Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060, 22lb (10kg) bag	12299
	Absolute Black® toner for use in Ricoh Aficio 1060, 1075, 2051, 2060, 1200g	17925
	RICOH AFICIO 2035, 2045, 3035, 3045	
	Wiper blade for use in Ricoh Aficio 2035, 2045, 3035, 3045	12575
	X-Generation® Wiper blade for Ricoh Aficio 2035, 2045, 3035, 3045 (150,000 pages)	16522

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	RICOH AFICIO 3800, 3850 Black toner for use in Ricoh Aficio 3800, 3850 520g Drum with gears for use in Ricoh Aficio 3800 Yellow toner for use in Ricoh Aficio 3800, 275g	8134 9694 8136
	RICOH AFICIO 551, 700 Copier toner for use in Ricoh Aficio 551, 700, Type 5105, 1220g Unidrum™ F with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085 (720,000 pages) Unidrum™ S with gears for use in Ricoh Aficio 550, 551, 650, 700, 850, 1050, 1060, 1075, 1085, 1105 (720,000 pages)	16713 7270 8547
	RICOH AFICIO SP 100e, 100 SF • Smartchip™ for use in Ricoh SP 100e, 100SF, 100SU (407166) (1200 pages) • Smartchip™ for use in Ricoh SP 100e, 100SF, 100SU (407167) (1,200 pages) • Absolute Black® toner for use in Ricoh Aficio SP 100e, 100SF, 100SU, 68g (1,200 pages) • Smartchip™ for use in Ricoh Aficio SP 100e, 100SF, 100SU (407165) (1,200 pages) (US) • SuMMIT® drum with gears for use in Ricoh Aficio SP 100e, 100SF, 100SU • SuMMIT® drum with gears for use in Ricoh Aficio SP 100e, 100SF, 100SU, 100 pack	18576 18912 18527 18550 18524 18528
	RICOH AFICIO SP 300 Absolute Black® toner for use in Ricoh Aficio SP 300, 125g (1,500 pages) Smartchip™ for use in Ricoh Aficio SP 300 (406956)(EU)(1,500 pages) Unidrum™ OPC with gears for use in Ricoh SP 300, 3400, 3410, 3410SF, 3500, 3510, 3510SF Unidrum™ with gears for use in Ricoh Aficio SP 300 dn	17834 17837 17735 17835
	RICOH AFICIO SP 3300 • Absolute Black® toner for use in Ricoh Aficio SP 3300,145g (5,000 pages) • PCR roller for use in Ricoh Aficio SP 3300, 10 pack • Smartchip™ for use in Ricoh Aficio SP 3300 (406212)(US)(5,000 pages) • Unidrum™ with gears for use in Ricoh Aficio SP 3300 • Wiper blade for use in Ricoh Aficio SP 3300, 10 pack	14817 14821 14818 15674 14820
	RICOH AFICIO SP 3400, 3410 Smartchip™ for use in Ricoh Aficio SP 3400, 3410, 3410SF (US)(406465)(5,000 pages) Absolute Black® toner for use in Ricoh Aficio SP 3400, 3410, 3410SF, 142g (5,000 pages) Absolute Black® toner for use in Ricoh Aficio SP 3500, 3510, 3510SF, 3400, 3410, 3410SF, 22lb (10kg) bag Unidrum™ OPC with gears for use in Ricoh Aficio SP 300, 3400, 3410, 3410SF, 3500, 3510, 3510SF	17301 17742 17770 17735
	RICOH AFICIO SP 4420, 4410, 4400 SF • Absolute Black® toner for use in Ricoh Aficio SP 4420 SF, 4410 SF, 4400 SF, 500g (18,000 pages) • Smartchip™ for use in Ricoh Aficio SP 4420, 4410, 4400 (406978)(18,000 pages)	18839 18840
	RICOH AFICIO SP 5200, 5210 Absolute Black® toner for use in Ricoh Aficio SP 5200, 5210, 730g (25,000 pages) Smartchip™ for use in Ricoh Aficio SP 5200, 5210 (406683) (25,000 pages) (USA) Smartchip™ for use in Ricoh Aficio SP 5200, 5210 (406685) (25,000 pages) (EU)	18257 18255 18256
	RICOH AFICIO SP C 430, 431 Absolute Black® toner for use in Ricoh Aficio SPC 430, 431 (24,000 pages) Absolute Cyan® toner for use in Ricoh Aficio SPC 430, 431 (21,000 pages) Absolute Magenta® toner for use in Ricoh Aficio SPC 430, 431 (21,000 pages) Absolute Yellow® toner for use in Ricoh Aficio SPC 430, 431 (21,000 pages) Smartchip for use in Ricoh Aficio SPC 430, 431 Black (821070)(24,000 pages) Smartchip for use in Ricoh Aficio SPC 430, 431 Cyan (821073)(15,000 pages) Smartchip for use in Ricoh Aficio SPC 430, 431 Magenta (821072)(15,000 pages) Smartchip for use in Ricoh Aficio SPC 430, 431 Yellow (821071)(15,000 pages)	17826 17827 17828 17829 17756 17757 17758 17759
	RICOH AFICIO SP 4100 Smartchip™ for use in Ricoh Aficio SP 4100 NL (403073)(7,500 pages) Smartchip™ for use in Ricoh Aficio SP 4100N KP, 4110N KP, 4210N (402809)(15,000 pages) Wiper blade for use in Ricoh Aficio SP 4100, 4110, 4210, 4310, 4 pack Clear Seal™ adhesive for carrier hopper for use in Ricoh Aficio SP 4100, 4110, 4210, 4310, 50 pack Clear Seal™ adhesive for toner hopper for use in Ricoh Aficio SP 4100, 4110, 4210, 4310, 50 pack Unidrum™ with gears for use in Ricoh Aficio SP 4100, 4110, 4210, 4310 X-Generation® Black toner for use in Ricoh Aficio SP 4100 NL, 360g (7,500 pages) X-Generation® Black toner for use in Ricoh Aficio SP 4100, 4110, 4210, 4310, 500g (15,000 pages) X-Generation® toner developer for use in Ricoh Aficio SP 4100, 4110, 4210, 4310, 45g	15956 13313 15808 12260 12259 15809 17624 17331 17342
	RICOH AFICIO SP C 220, 221, 222 Absolute Black® toner for use in Ricoh Aficio SP C 220, 221, 222, 185g Absolute Black® toner for use in Ricoh Aficio SP C 220, 221, 222, 22lb (10kg) bag Absolute Cyan™ toner for use in Ricoh Aficio SP C 220, 221, 222, 185g Absolute Cyan™ toner for use in Ricoh Aficio SP C 220, 221, 222, 22lb (10kg) bag Absolute Magenta™ toner for use in Ricoh Aficio SP C 220, 221, 222, 185g Absolute Magenta™ toner for use in Ricoh Aficio SP C 220, 221, 222, 22lb (10kg) bag Absolute Yellow™ toner for use in Ricoh Aficio SP C 220, 221, 222, 185g Absolute Yellow™ toner for use in Ricoh Aficio SP C 220, 221, 222, 22lb (10kg) bag Smartchip™ Black toner for use in Ricoh Aficio SP C 220, 221, 222, (EU) Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222 (2,000 pages)(Australia) Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222 (406047) (2,000 pages) 10 pack Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222 (406047) 2,000 pages Smartchip™ Cyan toner for use in Ricoh Aficio SP C 220, 221, 222 (EU) Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222 (2,000 pages)(Australia) Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222 (406048) 2,000 pages	12310 16550 12311 16551 12312 16552 12313 16553 13064 14939 16925 13127 13065 14940 13128

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222, (406048) (2,000 pages) 10 pack	16926
	Smartchip™ Magenta toner for use in Ricoh Aficio SP C 220, 221, 222, (EU)	13066
	Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222 (2,000 pages)(Australia)	14941
	Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222 (406044) (2,000 pages) 10 pack	16927
	Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222 (406044) 2,000 pages	13129
	Smartchip™ Yellow toner for use in Ricoh Aficio SP C 220, 221, 222, (EU)	13067
	SuMMiT® drum with gears for use in Ricoh Aficio 220, 270	12711
	Unidrum™ S with gears for use in Ricoh Aficio 220, 270 S (60,000 pages)	8542
	Wiper blade for use in Ricoh Aficio 220, 270	12552
	RICOH AFICIO MP C 3500, 4500	
	Absolute Cyan™ toner for use in Ricoh Aficio MP C 3500, 4500, 400g	14630
	Absolute Magenta® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500, 22lb (10kg) bag	14638
	Absolute Magenta™ toner for use in Ricoh Aficio MP C 3500, 4500, 400g	12560
	Absolute Yellow® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500, 22lb (10kg) bag	14639
	Absolute Yellow™ toner for use in Ricoh Aficio MP C 3500, 4500, 400g	12561
	Smartchip™ Black for use in Ricoh Aficio MP C 3500, 4500 (23,000 pages)	14631
	Smartchip™ Black for use in Ricoh Ipsio SPC 810, 811 (635008)(Japan)(20,000 pages)	13722
	Smartchip™ Cyan for use in Ricoh Aficio MP C 3500, 4500 (17,000 pages)	14632
	Smartchip™ Magenta for use in Ricoh Aficio MP C 3500, 4500, (17,000 pages)	14633
	Smartchip™ Yellow for use in Ricoh Aficio MP C 3500, 4500, (17,000 pages)	14634
	RICOH AFICIO MP C 2000, 2500, 3000	
	Absolute Black® toner for use in Ricoh Aficio MP C 2000, 2500, 3000, 400g	13173
	Absolute Black® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500, 22lb (10kg) bag	14635
	Absolute Cyan® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 22lb(10kg) bag	14636
	Absolute Cyan™ toner for use in Ricoh Aficio MP C 2000, 2500, 3000, 360g	13174
	Absolute Magenta® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500, 22lb (10kg) bag	14638
	Absolute Magenta™ toner for use in Ricoh Aficio MP C 2000, 2500, 3000, 360g	13175
	Absolute Yellow® toner for use in Ricoh Aficio® MP C 2000, 2500, 3000, 3500, 4500, 22lb (10kg) bag	14639
	Absolute Yellow™ toner for use in Ricoh Aficio MP C 2000, 2500, 3000, 360g	13176
	Smartchip™ Black (20,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000	14952
	Smartchip™ Cyan (15,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000	14953
	Smartchip™ Magenta (15,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000	14954
	Smartchip™ Yellow (15,000 pages) for use in Ricoh Aficio MP C 3000, 2500, 2000	14955
	RICOH AFICIO IPSIO CX 7100, 7500	
	Uni Drum with gears for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000	9270
	RICOH AP 1400, 1600	
	Absolute Black® toner for use in Ricoh AP 1400, 1600, 22 lb (10 kg) bag	9344
	Absolute Black® toner for use in Ricoh AP 1400, 1600, 285g	5128
	RICOH AP 400, 410	
	Clear Seal™ adhesive for carrier hopper for use in Ricoh AP 400, 410, 50 pack	9773
	Clear Seal™ adhesive for toner hopper for use in Ricoh AP 400, 410, 50 pack	9772
	Smartchip™ for use in Ricoh AP 400, 410 (15,000 pages)	12175
	Unidrum™ with gears for use in Ricoh AP 400, 410	9768
	Wiper blade for use in Ricoh AP 400, 410, 4 pack	11775
	X-Generation® Black toner for use in Ricoh AP 400, 410, 500g	17330
	X-Generation® toner developer for use in Ricoh AP 400, 410, 45g	17341
	RICOH AP 600, 610, 2600, 2610	
	Clear Seal™ adhesive for carrier hopper for use in Ricoh AP 600, 610, 2600, 2610, 50 pack	9776
	Clear Seal™ adhesive for toner hopper for use in Ricoh AP 600, 610, 2600, 2610, 50 pack	9775
	Smartchip™ for use in Ricoh AP 2610, 2600, 610, 600 toner (20,000 pages)	15219
	Unidrum™ with gears for use in Ricoh AP 600, 610, 2600, 2610	9778
	Wiper blade for use in Ricoh AP 600, 610, 2600, 2610, 10 pack	9777
	X-Generation® Black toner for use in Ricoh AP 600, 610, 2600, 2610, 550g	17335
	X-Generation® toner carrier for use in Ricoh AP 600, 610, 2600, 2610, 65g	17339
	RICOH IMAGIO P TYPE 2	
	Unidrum™ S drum with gears for use in Ricoh Imagio P Type 2	8707
	RICOH IMAGIO CA, CF, DA SERIES TYPE 1	
	Absolute Black® toner for use in Ricoh Imagio CA, CF, DA Series, Type 1, 350g	8151
	RICOH IMAGIO TYPE 18	
	Absolute Black® toner for use in Ricoh Imagio Type 18, 490g	8730
	RICOH IMAGIO TYPE 4	
	Absolute Black® toner for use in Ricoh Imagio Type 4, 700g	8148
	RICOH IMAGIO TYPE 7	
	Absolute Black® toner for use in Ricoh Imagio Type 7, 630g	8732
	RICOH IMAGIO TYPE 900	
	Absolute Black® toner for use in Ricoh Imagio Type 900, 22 lb (10 kg)	6758
	Absolute Black® toner for use in Ricoh Imagio Type 900, 310g	6624
	RICOH IPSIO CX 6000, 6100, 6600	
	Absolute Black® toner for use in Ricoh Ipsio CX 6000, 6100, 6600, 490g	9734
	Absolute Cyan™ toner for use in Ricoh Ipsio CX 6000, 6100, 6600, 310g	9735

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Absolute Magenta™ toner for use in Ricoh Ipsio CX 6000, 6100, 6600, 310g	9736
	Absolute Yellow™ toner for use in Ricoh Ipsio CX 6000, 6100, 6600, 310g	9738
	RICOH IPSIO SP C 710, 711	
	Absolute Black® Glossy toner for use in Ricoh Ipsio SP C 710, 711, (6,000 pages)	11727
	Absolute Black® Glossy toner for use in Ricoh Ipsio SP C 710, 711, 22 lb (10kg) bag	12729
	Absolute Cyan™ glossy toner for use in Ricoh Ipsio SP C 710, 711 (6,000 pages)	11728
	Absolute Cyan™ glossy toner for use in Ricoh Ipsio SP C 710, 711, 22 lb (10kg) bag	12730
	Absolute Magenta™ glossy toner for use in Ricoh Ipsio SP C 710, 711 (6,000 pages)	11729
	Absolute Magenta™ glossy toner for use in Ricoh Ipsio SP C 710, 711, 22 lb (10kg) bag	12731
	Absolute Yellow™ glossy toner for use in Ricoh Ipsio SP C 710, 711, (6,000 pages)	11730
	Absolute Yellow™ glossy toner for use in Ricoh Ipsio SP C 710, 711, 22 lb (10kg) bag	12732
	Drum unit sealing cover for use in Ricoh Ipsio SP C 710, 10 pack	15246
	Smartchip™ Black toner for use in Ricoh Ipsio SP C 710, 711 (6,000 pages)	13264
	Smartchip™ Cyan toner for use in Ricoh Ipsio SP C 710, 711 (6,000 pages)	13267
	Smartchip™ Magenta toner for use in Ricoh Ipsio SP C 710, 711, (6,000 pages)	13268
	Smartchip™ Yellow toner for use in Ricoh Ipsio SP C 710, 711 (6,000 pages)	13270
	RICOH IPSIO SP C 810, 811 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811, 22 lb (10 kg) bag	12562
	Absolute Black® toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811, 400g	12566
	Absolute Cyan™ toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811, 22 lb (10 kg) bag	12563
	Absolute Cyan™ toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811, 360g	12567
	Absolute Magenta™ toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811, 22 lb (10 kg) bag	12564
	Absolute Magenta™ toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811, 360g	12568
	Absolute Yellow™ toner for use in Ricoh Ipsio SPC 810, 811, Aficio SPC 810, 811, 22 lb (10 kg) bag	12565
	Absolute Yellow™ toner for use in Ricoh Ipsio SPC 810, Aficio SPC 810, 811, 360g	12569
	Smartchip™ Black for use in Ricoh Ipsio SPC 810, 811 (635008)(Japan)(20,000 pages)	13722
	Smartchip™ Cyan for use in Ricoh Ipsio SPC 810, 811 (635011)(Japan)(15,000 pages)	13723
	Smartchip™ Magenta for use in Ricoh Ipsio SPC 810, 811 (635010)(Japan)(15,000 pages)	13724
	Smartchip™ Yellow for use in Ricoh Ipsio SPC 810, 811 (635009)(Japan)(15,000 pages)	13725
	Unidrum™ with gears for use in Ricoh Ipsio SPC 810, Aficio SPC 811	17522
	RICOH IPSIO SP C 820, 821 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® Glossy toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 400g	17951
	Absolute Black® toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 22 lb (10 kg) bag	17947
	Absolute Black® toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 400g	17943
	Absolute Cyan™ Glossy toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 360g	17952
	Absolute Cyan™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 22 lb (10 kg) bag	17948
	Absolute Cyan™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 360g	17944
	Absolute Magenta™ Glossy toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 360g	17953
	Absolute Magenta™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 22 lb (10 kg) bag	17949
	Absolute Magenta™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 360g	17945
	Absolute Yellow™ Glossy toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 360g	17954
	Absolute Yellow™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 22 lb (10 kg) bag	17950
	Absolute Yellow™ toner for use in Ricoh Ipsio SPC 820, 821, Aficio SPC 820, 821, 360g	17946
	Smartchip™ Black for use in Ricoh Aficio SPC 811 (820000)(20,000 pages)	13727
	Smartchip™ Cyan for use in Ricoh Aficio SPC 811 (820024)(15,000 pages)	13728
	Smartchip™ Magenta for use in Ricoh Aficio SPC 811 (820016)(15,000 pages)	13729
	Smartchip™ Yellow for use in Ricoh Aficio SPC 811 (820008)(15,000 pages)	13730
	RICOH CL 7000	
	Black toner for use in Ricoh CL 7000, 510g	8833
	Black toner for use in Ricoh CL 7000, 7100, 480g	10382
	Drum with gears for use in Ricoh CL 7000	9695
	Yellow toner for use in Ricoh CL 7000, 275g	8836
	RICOH CL 7200, 7300	
	Absolute Black® toner for use in Ricoh CL 7200, 7300, 22 lb (10kg) bag	11426
	Absolute Black® toner for use in Ricoh CL 7200, 7300, 485g	10023
	Absolute Cyan™ toner for use in Ricoh CL 7200, 7300, 210g	10024
	Absolute Cyan™ toner for use in Ricoh CL 7200, 7300, 22 lb (10kg) bag	11427
	Absolute Magenta™ toner for use in Ricoh CL 7200, 7300, 210g	10025
	Absolute Magenta™ toner for use in Ricoh CL 7200, 7300, 22 lb (10kg) bag	11428
	Absolute Yellow™ toner for use in Ricoh CL 7200, 7300, 210g	10026
	Absolute Yellow™ toner for use in Ricoh CL 7200, 7300, 22 lb (10kg) bag	11429
	SAMSUNG®	
	SAMSUNG CLX 4195 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Samsung CLX 4195, 70g (2,500 pages)	17959
	Absolute Cyan™ toner for use in Samsung CLX 4195, 60g (1,800 pages)	17960
	Absolute Magenta™ toner for use in Samsung CLX 4195, 60g (1,800 pages)	17961
	Absolute Yellow™ toner for use in Samsung CLX 4195, 60g (1,800 pages)	17962
	PCR roller for use in Samsung CLX 4195, 6260, 10 pack	17963
	Shipping lock and drum cover set for use in Samsung CLX 4195, 10 set	18217
	Smartchip™ Black for use in Samsung CLP 415, CLX 4195 (CLT-K504S/ELS)(2,500 pages)(EUR)	18051
	Smartchip™ Black for use in Samsung CLP 415, CLX 4195 (CLT-K504S/SEE)(2,500 pages)(ASIA PACIFIC)	18097
	Smartchip™ Black for use in Samsung CLP 415, CLX 4195 (CLT-K504S/XAA)(2,500 pages)	17906
	Smartchip™ Cyan for use in Samsung CLP 415, CLX 4195 (CLT-C504S/ELS)(1,800 pages)(EUR)	18052
	Smartchip™ Cyan for use in Samsung CLP 415, CLX 4195 (CLT-C504S/SEE)(1,800 pages)(ASIA PACIFIC)	18098
	Smartchip™ Cyan for use in Samsung CLP 415, CLX 4195 (CLT-C504S/XAA)(1,800 pages)	17907
	Smartchip™ Magenta for use in Samsung CLP 415, CLX 4195 (CLT-M504S/ELS)(1,800 pages)(EUR)	18053
	Smartchip™ Magenta for use in Samsung CLP 415, CLX 4195 (CLT-M504S/SEE)(1,800 pages)(ASIA PACIFIC)	18099

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Smartchip™ Magenta for use in Samsung CLP 415, CLX 4195 (CLT-M504S/XAA)(1,800 pages)	17908
	Smartchip™ Yellow for use in Samsung CLP 415, CLX 4195(CLT-Y504S/ELS)(1,800 pages)(EUR)	18054
	Smartchip™ Yellow for use in Samsung CLP 415, CLX 4195(CLT-Y504S/SEE)(1,800 pages)(ASIA PACIFIC)	18100
	Smartchip™ Yellow for use in Samsung CLP 415, CLX 4195(CLT-Y504S/XAA)(1,800 pages)	17909
	SuMMIT® drum with gears for use in Samsung CLP 415, 680, CLX 4195, 6260 (CLT504/506)	17870
	Uni drum® OPC with gears for use in Samsung CLP 415, 680, CLX 4195, 6260 (CLT504/506)	17871
	SAMSUNG CLP 365, CLX 3305 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Samsung CLP 365, CLX 3305 (1,500 pages)	17968
	Absolute Black® toner for use in Samsung CLP 365, CLX 3305, 22lb (10kg) bag	18061
	Absolute Cyan® toner for use in Samsung CLP 365, CLX 3305, 22lb (10kg) bag	18062
	Absolute Cyan™ toner for use in Samsung CLP 365, CLX 3305 (1,000 pages)	17969
	Absolute Magenta® toner for use in Samsung CLP 365, CLX 3305, 22lb (10kg) bag	18063
	Absolute Magenta™ toner for use in Samsung CLP 365, CLX 3305 (1,000 pages)	17970
	Absolute Yellow® toner for use in Samsung CLP 365, CLX 3305, 22lb (10kg) bag	18064
	Absolute Yellow™ toner for use in Samsung CLP 365, CLX 3305 (1,000 pages)	17971
	Drum cover for use in Samsung CLP 365, 10 pack	18218
	Smartchip™ Black for use in Samsung CLP 365, CLX 3305 (CLT-K406S/ELS)(1,500 pages)(EUR)	18047
	Smartchip™ Black for use in Samsung CLP 365, CLX 3305 (CLT-K406S/SEE)(1,500 pages)(ASIA PACIFIC)	18093
	Smartchip™ Black for use in Samsung CLP 365, CLX 3305 (CLT-K406S/XAA)(1,500 pages)	17964
	Smartchip™ Cyan for use in Samsung CLP 365, CLX 3305 (CLT-C406S/ELS)(1,000 pages)(EUR)	18048
	Smartchip™ Cyan for use in Samsung CLP 365, CLX 3305 (CLT-C406S/SEE)(1,000 pages)(ASIA PACIFIC)	18094
	Smartchip™ Cyan for use in Samsung CLP 365, CLX 3305 (CLT-C406S/XAA)(1,000 pages)	17965
	Smartchip™ Magenta for use in Samsung CLP 365, CLX 3305 (CLT-M406S/ELS)(1,000 pages)(EUR)	18049
	Smartchip™ Magenta for use in Samsung CLP 365, CLX 3305 (CLT-M406S/SEE)(1,000 pages)(ASIA PACIFIC)	18095
	Smartchip™ Magenta for use in Samsung CLP 365, CLX 3305 (CLT-M406S/XAA)(1,000 pages)	17966
	Smartchip™ Yellow for use in Samsung CLP 365, CLX 3305 (CLT-Y406S/ELS)(1,000 pages)(EUR)	18050
	Smartchip™ Yellow for use in Samsung CLP 365, CLX 3305 (CLT-Y406S/SEE)(1,000 pages)(ASIA PACIFIC)	18096
	Smartchip™ Yellow for use in Samsung CLP 365, CLX 3305 (CLT-Y406S/XAA)(1,000 pages)	17967
	SAMSUNG CLX 3160 FN	
	Absolute Black® toner for use in Samsung CLX 3160 FN, 22 lb (10 kg) bag	11803
	Absolute Black® toner for use in Samsung CLX 3160 FN, 90g (2,000 pages)	10167
	Absolute Cyan™ toner for use in Samsung CLP 300, CLX 3160 FN, 22 lb (10 kg) bag	11804
	Absolute Cyan™ toner for use in Samsung CLP 300, CLX 3160 FN, 48g (1,000 pages)	10168
	Absolute Magenta™ toner for use in Samsung CLP 300, CLX 3160 FN, 22 lb (10 kg) bag	11805
	Absolute Magenta™ toner for use in Samsung CLP 300, CLX 3160 FN, 48g (1,000 pages)	10169
	Absolute Yellow™ toner for use in Samsung CLP 300, CLX 3160 FN, 22 lb (10kg) bag	11806
	Absolute Yellow™ toner for use in Samsung CLP 300, CLX 3160 FN, 48g (1,000 pages)	10170
	PCR roller for use in Samsung CLP 300, CLX 3160 FN, 10 Pack	12329
	Seal toner hopper fill plug for use in Samsung CLP 300, CLX 3160 FN, 100 pack (32mm)	11625
	Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN, 10 pack	11571
	Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN (USA, Latin America) 10 pack	11646
	Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN (EUROPE) 10 pack	16153
	Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN (USA) 10 pack	16149
	Smartchip™ Black for use in Samsung CLP 300, CLX 3160 FN (USA)	10907
	Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN, 10 pack	11572
	Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN (EUROPE) 10 pack	16154
	Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN (USA) 10 pack	16150
	Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN (USA)	10908
	Smartchip™ Cyan for use in Samsung CLP 300, CLX 3160 FN (USA, Latin America) 10 pack	11647
	Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN, 10 pack	11573
	Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN (USA, Latin America) 10 pack	11648
	Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN (EUROPE) 10 pack	16155
	Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN (EU)	13492
	Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN (USA) 10 pack	16151
	Smartchip™ Magenta for use in Samsung CLP 300, CLX 3160 FN (USA)	10909
	Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN 10 pack	11574
	Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN (USA, Latin America) 10 pack	11649
	Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN (EUROPE) 10 pack	16156
	Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN (EU)	13493
	Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN (USA) 10 pack	16152
	Smartchip™ Yellow for use in Samsung CLP 300, CLX 3160 FN (USA)	10910
	SAMSUNG CLX 6200, 6210, 6240	
	Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 75g (2,500 pages)	12473
	Absolute Cyan™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 65g (2,000 pages)	12499
	Absolute Magenta™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 65g (2,000 pages)	12500
	Absolute Yellow™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 65g (2,000 pages)	12501
	Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 165g (5,500 pages)	12502
	Absolute Cyan™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 165g (5,000 pages)	12503
	Absolute Magenta™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 165g (5,000 pages)	12504
	Absolute Yellow™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 165g (5,000 pages)	12505
	ASIC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (2,500 pages)	12506
	ASIC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (2,000 pages)	12507
	ASIC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (2,000 pages)	12508
	ASIC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (2,000 pages)	12509
	ASIC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (5,500 pages)	12510
	ASIC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (5,000 pages)	12511
	ASIC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (5,000 pages)	12512
	ASIC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (5,000 pages)	12513
	Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 22 lb (10 kg) bag	13099
	Absolute Cyan™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 22 lb (10 kg) bag	13100

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Absolute Magenta™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 22 lb (10 kg) bag	13101
	Absolute Yellow™ toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 22 lb (10 kg) bag	13102
	ASIC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, (EU)(2,500 pages)	13813
	ASIC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (EU)(2,000 pages)	13814
	ASIC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, (EU)(2,000pages)	13815
	ASIC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, (EU)(2,000 pages)	13816
	ASIC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (EU)(5,500 pages)	13817
	ASIC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (EU)(5,000 pages)	13818
	ASIC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, (EU)(5,000 pages)	13819
	ASIC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (EU)(5,000 pages)	13820
	PCR roller for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 10 pack	14214
	Unidrum™ with gears for use in Samsung CLP 610, 615, 620, 660, 670 CLX 6200, 6210, 6220, 6240, 6250	14462
	SuMMiit® OPC drum with gears for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240	15289
	ASIC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (2,000 pages)(US)10 pack	16390
	ASIC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (5,000 pages)(US)10 pack	16391
	ASIC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (EU)(2,000 pages)10 pack	16393
	ASIC Smartchip® Cyan for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (EU)(5,000 pages)10 pack	16394
	ASIC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (2,500 pages)(US)10 pack	16395
	ASIC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (2,000 pages)(US)10 pack	16396
	ASIC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (2,000 pages)(US)10 pack	16397
	ASIC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (5,000 pages)10 pack	16398
	ASIC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (5,000 pages)(US)10 pack	16399
	ASIC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (5,000 pages)(US)10 pack	16400
	ASIC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, (EU)(2,500 pages)10 pack	16402
	ASIC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, (EU)(2,000pages), 10 pack	16403
	ASIC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, (EU)(2,000 pages)10 pack	16404
	ASIC Smartchip® Black for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (EU)(5,500 pages)10 pack	16405
	ASIC Smartchip® Magenta for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, (EU)(5,000 pages)10 pack	16406
	ASIC Smartchip® Yellow for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240 (EU)(5,000 pages)10 pack	16407
	Absolute Black® toner for use in Samsung CLP 610, 660, CLX 6200, 6210, 6240, 165g (5,500 pages)	17959
	SAMSUNG CLX 6220, 6250	
	Unidrum™ with gears for use in Samsung CLP 610, 615, 620, 660, 670 CLX 6200, 6210, 6220, 6240, 6250	14462
	Absolute Black® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250, (5,000 pages)	15583
	Absolute Cyan® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250, (4,000 pages)	15584
	Absolute Magenta® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250, (4,000 pages)	15585
	Absolute Yellow® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250, (4,000 pages)	15586
	Smartchip™ Black for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 (CLTK508L)(5,000 pages)	15587
	ASIC Encrypto Smartchip™ Black for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 (CLTK508L)(5,000 pages)(US)	16424
	ASIC Encrypto Smartchip™ Cyan for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 (CLTK508L)(4,000 pages)(US)	16425
	ASIC Encrypto Smartchip™ Magenta for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 (CLTM508L)(4,000 pages)(US)	16426
	ASIC Encrypto Smartchip™ Yellow for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 (CLTY508L)(4,000 pages)(US)	16427
	ASIC Encrypto Smartchip™ Black for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 (CLTK5082L)(5,000 pages)(EU)	16428
	ASIC Encrypto Smartchip™ Cyan for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 (CLTK5082L)(4,000 pages)(EU)	16429
	ASIC Encrypto Smartchip™ Magenta for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 (CLTM5082L)(4,000 pages)(EU)	16430
	ASIC Encrypto Smartchip™ Yellow for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 (CLTY5082L)(4,000 pages)(EU)	16431
	Absolute Black® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250, 22lb(10kg) bag	16440
	Absolute Cyan® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250, 22lb(10kg) bag	16442
	Absolute Magenta® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250,22lb(10kg) bag	16443
	Absolute Yellow® toner for use in Samsung CLP 615, 620, 670, CLX 6220, 6250 22lb(10kg) bag	16444
	SAMSUNG CLP 680, CLX 6260 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	SuMMiit® drum with gears for use in Samsung CLP 415, 680, CLX 4195, 6260 (CLT504/506)	17870
	Uni drum® OPC with gears for use in Samsung CLP 415, 680, CLX 4195, 6260 (CLT504/506)	17871
	Smartchip™ Black for use in Samsung CLP 680, CLX 6260 (CLT-K506L/XAA)(6,000 pages)	17914
	Smartchip™ Cyan for use in Samsung CLP 680, CLX 6260 (CLT-C506L/XAA)(3,500 pages)	17915
	Smartchip™ Magenta for use in Samsung CLP 680, CLX 6260 (CLT-M506L/XAA)(3,500 pages)	17916
	Smartchip™ Yellow for use in Samsung CLP 680, CLX 6260 (CLT-Y506L/XAA)(3,500 pages)	17917
	PCR roller for use in Samsung CLP 415, 680, CLX 4195, 6260, 10 pack	17963
	Smartchip™ Black for use in Samsung CLP 680, CLX 6260 (CLT-K506L/ELS)(6,000 pages)(EUR)	18055
	Smartchip™ Cyan for use in Samsung CLP 680, CLX 6260 (CLT-C506L/ELS)(3,500 pages)(EUR)	18056
	Smartchip™ Magenta for use in Samsung CLP 680, CLX 6260 (CLT-M506L/ELS)(3,500 pages)(EUR)	18057
	Smartchip™ Yellow for use in Samsung CLP 680, CLX 6260 (CLT-Y506L/ELS)(3,500 pages)(EUR)	18058
	Smartchip™ Black for use in Samsung CLP 680, CLX 6260 (CLT-K506L/SEE)(6,000 pages)(ASIA PACIFIC)	18101
	Smartchip™ Cyan for use in Samsung CLP 680, CLX 6260 (CLT-C506L/SEE)(3,500 pages)(ASIA PACIFIC)	18102
	Smartchip™ Magenta for use in Samsung CLP 680, CLX 6260 (CLT-M506L/SEE)(3,500 pages)(ASIA PACIFIC)	18103
	Smartchip™ Yellow for use in Samsung CLP 680, CLX 6260 (CLT-Y506L/SEE)(3,500 pages)(ASIA PACIFIC)	18104
	Drum cover for use in Samsung CLP 680, CLX 6260, 10 pack	18219
	SAMSUNG CLX 8380 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Smartchip™ Black for use in Samsung CLX 8380 (CLX-K8380A)(20,000 pages)	15946
	Smartchip™ Cyan for use in Samsung CLX 8380 (CLX-C8380A)(15,000 pages)	15947
	Smartchip™ Magenta for use in Samsung CLX 8380 (CLX-M8380A)(15,000 pages)	15948
	Smartchip™ Yellow for use in Samsung CLX 8380 (CLX-Y8380A)(15,000 pages)	15949
	Absolute Black® toner for use in Samsung CLX 8380, 675g (20,000 pages)	17926
	Absolute Cyan™ toner for use in Samsung CLX 8380, 420g (15,000 pages)	17927
	Absolute Magenta™ toner for use in Samsung CLX 8380, 420g (15,000 pages)	17928
	Absolute Yellow™ toner for use in Samsung CLX 8380, 420g (15,000 pages)	17929
	Smartchip™ Black for use in Samsung CLX 8380 (CLX-K8380A)(20,000 pages)(EUR)	18153
	Smartchip™ Cyan for use in Samsung CLX 8380 (CLX-C8380A)(20,000 pages)(EUR)	18154
	Smartchip™ Magenta for use in Samsung CLX 8380 (CLX-M8380A)(20,000 pages)(EUR)	18155
	Smartchip™ Yellow for use in Samsung CLX 8380 (CLX-Y8380A)(20,000 pages)(EUR)	18156
	Smartchip™ Black for use in Samsung CLX 8380 (CLX-K8380A)(20,000 pages)(EXP)	18157

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Smartchip™ Cyan for use in Samsung CLX 8380 (CLX-C8380A)(20,000 pages)(EXP)	18158
	Smartchip™ Magenta for use in Samsung CLX 8380 (CLX-M8380A)(20,000 pages)(EXP)	18159
	Smartchip™ Yellow for use in Samsung CLX 8380 (CLX-Y8380A)(20,000 pages)(EXP)	18160
	SAMSUNG CLX 8385 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Smartchip™ Black for use in Samsung CLX 8385 (CLX-K8385A/ELS)(20,000 pages)(EU)	17451
	Smartchip™ Cyan for use in Samsung CLX 8385 (CLX-C8385A/ELS)(15,000 pages)(EU)	17452
	Smartchip™ Magenta for use in Samsung CLX 8385 (CLX-M8385A/ELS)(15,000 pages)(EU)	17453
	Smartchip™ Yellow for use in Samsung CLX 8385 (CLX-Y8385A/ELS)(15,000 pages)(EU)	17454
	Smartchip™ Black for use in Samsung CLX 8385 (CLX-K8385A/ELS)(20,000 pages)(US)	17839
	Smartchip™ Cyan for use in Samsung CLX 8385 (CLX-C8385A/ELS)(15,000 pages)(US)	17840
	Smartchip™ Magenta for use in Samsung CLX 8385 (CLX-M8385A/ELS)(15,000 pages)(US)	17841
	Smartchip™ Yellow for use in Samsung CLX 8385 (CLX-Y8385A/ELS)(15,000 pages)(US)	17842
	SAMSUNG CLX 9250, 9258, 9350, 9358 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Smartchip™ Black for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-K606S)(25,000 pages)(EUR)	18162
	Smartchip™ Black for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-K606S)(25,000 pages)(EXP)	18166
	Smartchip™ Black for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-K606S)(25,000 pages)(DOM)	18170
	Smartchip™ Cyan for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-C607S)(15,000 pages)(DOM)	18221
	Smartchip™ Magenta for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-M607S)(15,000 pages)(DOM)	18222
	Smartchip™ Yellow for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-Y607S)(15,000 pages)(DOM)	18223
	Smartchip™ Cyan for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-C607S)(15,000 pages)(EUR)	18224
	Smartchip™ Magenta for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-M607S)(15,000 pages)(EUR)	18225
	Smartchip™ Yellow for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-Y607S)(15,000 pages)(EUR)	18226
	Smartchip™ Cyan for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-C607S)(15,000 pages)(EXP)	18227
	Smartchip™ Magenta for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-M607S)(15,000 pages)(EXP)	18228
	Smartchip™ Yellow for use in Samsung CLX 9250, 9258, 9350, 9358(CLT-Y607S)(15,000 pages)(EXP)	18229
	SAMSUNG SCX 6345	
	Absolute Black® developer carrier for drum unit for use in Samsung SCX 6345, 340g	11645
	Absolute Black® toner for use in Samsung SCX 6345, 22 lb (10 kg) bag	11416
	Absolute Black® toner for use in Samsung SCX 6345, 560g	11415
	Clear adhesive seal for use in Samsung SCX 6345, 50 pack	14584
	Doctor blade for use in Samsung SCX 6345, 10 pack	11418
	Mag Roller Sleeve for use in Samsung SCX 6345, 10 pack	11473
	PCR roller for use in Samsung SCX 6345, 10 pack	11475
	Smartchip™ drum unit for use in Samsung SCX 6345	13478
	Smartchip™ toner cartridge for use in Samsung SCX 6345	11417
	Wiper blade for use in Samsung SCX 6345, 10 pack	11420
	SAMSUNG SCX 6555, 6545 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	TEXT grade toner for use in Samsung SCX 6555, 6545, 685g (25,000 pages)	14093
	Smartchip™ toner with connector for use in Samsung SCX 6555, 6545 (SCX-D6555A)(25,000 pages)	14094
	TEXT grade toner for use in Samsung SCX 6555, 6545, 22 lb (10kg) bag	17317
	Absolute Black® toner for use in Samsung SCX 6555, 6545, 22 lb (10kg) bag	17525
	Unidrum™ OPC with gears for use in Samsung SCX 6555, 6545 (80,000 pages)	17527
	Absolute Black® toner for use in Samsung SCX 6555, 6545, 720g (25,000 pages)	17536
	Smartchip™ drum unit for use in Samsung SCX 6555, 6545 (80,000 pages)	17537
	Absolute Black® developer for use in Samsung SCX 6555, 6545, 330g (80,000 pages)	17571
	OEM style cable for use in Samsung SCX 6555 (MOQ-2,000pcs)	17648
	SAMSUNG SCX 3405, SF 760	
	Smartchip™ for use in Samsung ML 2160, 2165, SCX 3405, SF 760 (MLT-D101S/WW)(1,500 pages)	17069
	Smartchip™ for use in Samsung ML 2165, 2160, SCX 3405, SF 760 (MLT-D101S/XAA)(1,500 pages)(US)	17071
	Unidrum™ with gears for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165	17473
	SuMMIT® drum with gears for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165	17474
	Absolute Black toner® for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165, 70g (1,500 pages)	17475
	Absolute Black toner® for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165, 22lb (10kg) bag	17476
	Wiper blade for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165, 10 pack	17477
	Doctor blade for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160 1165	17478
	PCR roller for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165, 10 pack	17479
	Developer roller for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165	17480
	Smartchip™ for use in Samsung ML 2165, 2160, SCX 3405, SF 760 (MLT-D101S/ELS)(1,500 pages)(EUR)	18040
	SuMMIT® drum with gears for use in Samsung ML 2165, 2160, SCX 3405, SF 760, Dell B 1160, 1165,100 pack	18112
	Smartchip™ for use in Samsung ML 2165, 2160, SCX 3405, SF 760 (MLT-D101S/SEE)(1,500 pages)	18206
	SAMSUNG SCX 4300	
	Absolute Black® toner for Samsung SCX 4300, 75g (2,000 pages)	13323
	PCR roller for use in Samsung SCX 4300, 10 pack	13325
	Doctor blade for use in Samsung SCX 4300, 10 pack	13326
	Unidrum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100	15203
	Absolute Black® toner for use in Samsung SCX 4300, 22lb(10kg)bag	15343
	ASiC Encrypto Smartchip™ for use in Samsung SCX 4300(MLT-D109S)(2,000pages)(US)	16412
	ASiC Encrypto Smartchip™ for use in Samsung SCX 4300 (MLT-D1092S)(2,000pages)(EU)	16413
	SAMSUNG SCX 4500	
	Absolute Black® toner for use in Samsung ML 1630, 1631, SCX 4500, 40g (2,000 pages)	11939
	ASiC Smartchip® for use in Samsung ML 1630, 1631, SCX 4500	11940
	Fill plug for use in Samsung ML 1630, 1631, SCX 4500, 100 pack	12189
	Unidrum™ with gears for use in Samsung ML 1630, 1631, SCX 4500	12203
	X-Generation® Doctor blade for use in Samsung ML 1630, 1631, SCX 4500, 10 pack	12351
	Wiper blade for use in Samsung ML 1630, 1631, SCX 4500, 10 pack	12352
	Developer roller for use in Samsung ML 1630, 1631, SCX 4500, 10 pack	12733

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	PCR roller for use in Samsung ML 1630, 1631, SCX 4500, 10 pack	12734
	Supply roller for use in Samsung ML 1630, 1631, SCX 4500, 10 pack	12735
	Developer Roller End Felt for use in Samsung ML 1630, 1631, SCX 4500, 10 sets	13009
	Toner Adder Roller End Foam for use in Samsung ML 1630, 1631, SCX 4500, 10 sets	13010
	Absolute Black® toner for use in Samsung ML 1630, 1631, SCX 4500, 22 lb (10kg) bag	13868
	ASIC Smartchip® for use in Samsung ML 1630, 1631, SCX 4500, 10 pack	16364
	X-Generation® Wiper blade for use in Samsung ML 1630, 1631, SCX 4500 10 pack	17081
	SuMMIT® drum with gears for use in Samsung ML 1630, 1631, SCX 4500, 100 pack	18121
	SAMSUNG SCX 4600, 4623, SF 650	
	Absolute Black® toner for use in Samsung ML 1910, 1915, 2525, 2545, SCX 4600, 4623, SF 650, 90g (2,500 pages)	15119
	X-Generation® Wiper blade for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623, SF 650, 10 pack	15124
	Absolute Black® toner for use in Samsung ML 1910, 1915, 2525, 2545, SCX 4600, 4623, SF 650, 50g (1,500 pages)	15127
	ASIC Encrypto Smartchip™ for use in Samsung 1910, 2525, 2545, 2580, SCX 4600, 4610, 4623, 650F(MLT-D105S)(1,500pages)(US)	16414
	Unidrum™ with gears for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623	16415
	SuMMIT® drum with gears for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623	16416
	ASIC Encrypto Smartchip™ for use in Samsung 1910, 2525, 2545, 2580, SCX 4600, 4610, 4623, 650F(MLT-D105L)(2,500pages)(US)	16418
	ASIC Encrypto Smartchip™ for use in Samsung 1910, 2525, 2580, SCX 4600, 4610, 4623, 650F(MLT-D1052L) (2,500pages)(EU)	16419
	Absolute Black® toner for use in Samsung ML 1910, 1915, 2525, 2545, SCX 4600, 4623, SF 650, 22lb (10kg) bag	17270
	SuMMIT® drum with gears for use in Samsung ML 1910, 1915, 2525, 2545, 2580, SCX 4600, 4623, 100 pack	18108
	SAMSUNG SCX 4824, 4825, 4826, 4828	
	Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, 145g (5,000 pages)	12109
	Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, 65g (2,000 pages)	12106
	X-Generation® Wiper blade for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, 10 pack (MLT-D209)	17078
	SAMSUNG SCX 4833, 4835, 5639, 5737, 5739 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 4835, 5639, 5737, 5739, 22lb (10kg) bag	16912
	Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739, 285g (MLT-D205E)(10,000 pages)	16794
	Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739, 145g (MLT-D205L)(5,000 pages)	16333
	Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, SCX 4833, 4835, 5737, 70g (MLT-D205S)(2,000 pages)	16773
	Developer roller for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 4835, 5737, 10 pack	16337
	PCR roller for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 4835, 5737, 10 pack	16338
	X-Generation® Wiper blade for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 4835, 5737, 10 pack (MLT-D205)	16335
	SAMSUNG SCX 4016, 4216, SF 560, 755	
	Absolute Black® toner for use in Samsung SCX 4016, 4216, SF 560, 755, 105g	9168
	Absolute Black® toner for use in Samsung SCX 4016, 4216, SF 560, 755, 22 lb (10 kg) bag	9610
	Developer roller for use in Samsung SCX 4016, 4216, SF 560, 755, 9 pack	5292
	PCR roller for use in Samsung SCX 4016, 4216, SF 560, 755, 10 pack	5293
	Smartchip™ fuse for use in Samsung SCX 4016, 4216, SF 560, 755, 10 pack	10203
	SuMMIT® drum w/gears for use in Samsung SCX 4016, 4216, SF 560, 755, 5 pack	12035
	Unidrum™ with gears for use in Samsung SCX 4016, 4216, SF 560, 755	15207
	Wiper blade for use in Samsung SCX 4016, 4216, SF 560, 755, 10 pack	4948
	SAMSUNG SCX 4100, 4116	
	Absolute Black® toner for use in Samsung SCX 4100, 4116, 22 lb (10 kg) bag	9640
	Absolute Black® toner for use in Samsung SCX 4100, 4116, 75g (3,000 pages)	9639
	Doctor blade w/ sponge for use in Samsung SCX 4200, 4100, 4116, 10 pack	10550
	Unidrum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100	15203
	Wiper blade for use in Samsung SCX 4200,4100, 4116, 10 pack	10549
	SAMSUNG SCX 4200	
	Absolute Black® toner for use in Samsung SCX 4200, 22 lb (10 kg) bag	10546
	Absolute Black® toner for use in Samsung SCX 4200, 75g (3,000 pages)	10545
	Doctor blade w/ sponge for use in Samsung SCX 4200, 4100, 4116, 10 pack	10550
	Smartchip™ for use in Samsung SCX 4200	10548
	Smartchip™ for use in Samsung SCX 4200, 10 pack	16120
	Top cover for use in Samsung SCX 4200	11465
	Unidrum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100	15203
	Wiper blade for use in Samsung SCX 4200,4100, 4116, 10 pack	10549
	SAMSUNG SCX 4300	
	Absolute Black® toner for use in Samsung SCX 4300, 22lb(10kg)bag	15343
	Absolute Black® toner for Samsung SCX 4300, 75g (2,000 pages)	13323
	ASIC Encrypto Smartchip™ for use in Samsung SCX 4300 (MLT-D1092S)(2,000pages)(EU)	16413
	ASIC Encrypto Smartchip™ for use in Samsung SCX 4300(MLT-D109S)(2,000pages)(US)	16412
	Doctor blade for use in Samsung SCX 4300, 10 pack	13326
	PCR roller for use in Samsung SCX 4300, 10 pack	13325
	Unidrum™ with gears for use in Samsung SCX 4300, 4200, 4116, 4100	15203
	SAMSUNG SCX 4521, 4321	
	Absolute Black® toner for use in Samsung SCX 4521, 4321, 22 lb (10 kg) bag	10439
	Absolute Black® toner for use in Samsung SCX 4521, 4321, 90g (3,000 pages)	10438
	Developer roller for use in Samsung SCX 4521, 4321, 10 pack	10443
	Doctor blade for use in Samsung SCX 4521, 4321, 10 pack	16818
	PCR roller for use in Samsung SCX 4521, 4321, 10 pack	10444
	Smartchip™ fuse for use in Samsung SCX 4521, 4321, 10 pack	10446
	Supply roller for use in Samsung SCX 4521, 4321, 10 pack	10445
	Unidrum™ OEM Style with gears for use in Samsung SCX 4725, 4521, 4321	16113
	Wiper blade for use in Samsung SCX 4725, 4521, 4321, 10 pack	10441

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	SAMSUNG SCX 4720, 4520	
	Universal cover top for use in Samsung ML 2250, 2251, 2252, SCX 4720, 4520, Dell 1600	6298
	Absolute Black® toner for use in Samsung SCX 4720, 4520, 150g (5,000 pages)	9528
	Absolute Black® toner for use in Samsung SCX 4720, 4520, 100g (3,000 pages)	9529
	Absolute Black® toner for use in Samsung SCX 4720, 4520, 22 lb (10 kg) bag	9530
	Developer roller for use in Samsung SCX 4720, 4520, 10 pack	9533
	PCR roller for use in Samsung SCX 4720, 4520, 10 pack	9534
	Wiper blade for use in Samsung SCX 4720, 4520, 10 pack	9535
	Doctor blade for use in Samsung SCX 4720, 4520, 10 pack	9536
	Smartchip™ for use in Samsung SCX 4720, 4520 (5,000 pages)	9537
	Smartchip™ for use in Samsung SCX 4720, 4520 (5,000 pages)	9537
	SuMMiT® drum w/gears for use in Samsung SCX 4720, 4520	12036
	Smartchip™ for use in Samsung SCX 4720, 4520 (3,000 pages)	12256
	Unidrum™ with gears for use in Samsung SCX 4720, 4520	15196
	Smartchip™ for use in Samsung SCX 4720, 4520 (3,000 pages) 10 pack	16122
	Smartchip™ for use in Samsung SCX 4720, 4520 (5,000 pages) 10 pack	16125
	SAMSUNG SCX 4725	
	Absolute Black® toner for use in Samsung SCX 4725, 22 lb (10 kg) bag	11666
	Absolute Black® toner for use in Samsung SCX 4725, 90g (3,000 pages)	11665
	ASIC Smartchip® for use in Samsung SCX 4725, (3,000 pages)	11667
	ASIC Smartchip® for use in Samsung SCX 4725, (3,000 pages), 10 pack	16277
	Conversion kit for Samsung ML 1640, 2240, SCX 4725	14425
	Developer roller for use in Samsung SCX 5530, 5330, 4725, 10 pack	10993
	Doctor blade for use in Samsung SCX 4725, 10 pack	16817
	PCR roller for use in Samsung SCX 4725, 10 pack	11672
	Smartchip™ for use in Samsung SCX 4725,	12051
	SuMMiT® drum w/gears for use in Samsung SCX 4725, 5 pack	12037
	Unidrum™ OEM Style with gears for use in Samsung SCX 4725, 4521, 4321	16113
	Wiper blade for use in Samsung SCX 4725, 4521, 4321, 10 pack	10441
	SAMSUNG SCX 5112, 5312, 5315	
	Absolute Black® toner for use in Samsung SCX 5112, 5312, 5315, 200g	8977
	Absolute Black® toner for use in Samsung SCX 5112, 5312, 5315, 22 lb (10 kg) bag	5472
	Developer roller for use in Samsung SCX 5112, 5312, 5315, 9 pack	5180
	Doctor blade for use in Samsung SCX 5112, 5312, 5315, 10 pack	8979
	Smartchip™ drum unit fuse for use in Samsung SCX 5112, 5312, 5315, 10 pack	5083
	SuMMiT® drum w/gears for use in Samsung SCX 5112, 5312, 5315	12038
	Wiper blade for use in Samsung SCX 5112, 5312, 5315, 10 pack	8978
	SAMSUNG SCX 5530, 5330	
	Absolute Black® toner for use in Samsung SCX 5530, 5330, 110g (4,000 pages)	11947
	Absolute Black® toner for use in Samsung SCX 5530, 5330, 215g (8,000 pages)	10960
	Absolute Black® toner for use in Samsung SCX 5530, 5330, 22 lb (10 kg) bag	10961
	ASIC Smartchip® for use in Samsung SCX 5530, 5330 (4,000 pages) (USA region)	11946
	ASIC Smartchip® for use in Samsung SCX 5530, 5330 (4,000 pages) (USA, EUR region), 10 pack	16375
	ASIC Smartchip® for use in Samsung SCX 5530, 5330 (8,000 pages) (USA, EUR region)	10963
	ASIC Smartchip® for use in Samsung SCX 5530, 5330 (8,000 pages) (USA, EUR region), 10 pack	16372
	Developer roller for use in Samsung SCX 5530, 5330, 4725, 10 pack	10993
	PCR roller for use in Samsung SCX 5530, 5330, 10 pack	10994
	SuMMiT® drum w/gears for use in Samsung SCX 5530, 5330	12039
	Unidrum™ with gears for use in Samsung SCX 5530, 5330	15774
	X-Generation® Doctor blade for use in Samsung SCX 5530, 5330	18086
	X-Generation® Wiper blade for use in Samsung SCX 5530, 5330, 10 pack	18120
	SAMSUNG SCX 5935, 5835, 5635 MFP	
	Absolute Black® toner for use in Samsung SCX 5935, 5835, 5635 MFP, 110g (4,000 pages)	13880
	Absolute Black® toner for use in Samsung SCX 5935, 5835, 5635 MFP, 22 lb (10kg) bag	14904
	Absolute Black® toner for use in Samsung SCX 5935, 5835, 5635 MFP, 280g (10,000 pages)	13878
	Smartchip™ for use in Samsung SCX 5935 MFP (MLT-D206L) (10,000 pages)	15741
	SuMMiT® drum with gears for use in Samsung SCX 5935, 5835, 5635 MFP	13885
	Wiper blade for use in Samsung SCX 5935, 5835, 5635, 10 pack	15870
	SAMSUNG SCX 6320, 6220, 6120, 6520	
	Absolute Black® toner for use in Samsung SCX 6320, 6220, 6120, 6520, 22 lb (10 kg)	9557
	Absolute Black® toner for use in Samsung SCX 6320, 6220, 6120, 6520, 250g	9556
	Developer roller for use in Samsung SCX 6320, 6220, 6120, 6520, 5 pack	15746
	Doctor blade for use in Samsung SCX 6320, 6220, 6120, 6520, 10 pack	11553
	PCR roller for use in Samsung SCX 6320, 6220, 6120, 6520, 10 pack	9560
	Smartchip™ drum unit fuse for use in Samsung SCX 6322, 6320, 6220, 6120, 6520, 10 pack	9866
	Smartchip™ toner for use in Samsung SCX 6320, 6220, 6120, 6520, (8,000 pages)	9867
	Smartchip™ toner for use in Samsung SCX 6320, 6220, 6120, 6520, (8,000 pages) 10 pack	16127
	SuMMiT® drum with gears for use in Samsung SCX 6320, 6220, 6120, 6520	14937
	X-Generation® Wiper blade for use in Samsung SCX 6320, 6220, 6120, 6520	17973
	SAMSUNG SCX 7128, 7135, 7145	
	Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145, 176 lb (80 kg)	5285
	Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145, 480g	5287
	Ecographics toner for use in Samsung SCX 7128, 7135, 7145, 176lbs (80kg)	5289
	Ecographics toner for use in Samsung SCX 7128, 7135, 7145, 198lbs (90kg)	16933
	Ecographics™ toner for use in Samsung SCX 7128, 7135, 7145, 320g	5924
	Uni Drum with gears for use in Samsung SCX 7128, 7135, 7145	5288

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	SAMSUNG SCX 3200, 3205	
	X-Generation® Black toner for use in Samsung ML 1860, 1665,1660, SCX 3205, 3200, 45g (1,500 pages)	15906
	X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 22 lb (10 kg) bag	15908
	Developer roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 10 pack	15950
	PCR roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 10 pack	15951
	Drum cover for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 10 pack	15957
	Name plate for use in Samsung ML 1665, 1660, SCX 3205, 3200, 10 pack	15975
	SuMMIT® OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	16014
	X-Generation® Wiper blade for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 10 pack	16105
	X-Generation® Doctor blade for use in Samsung ML 1865, 1665, 1660, SCX 3205, 3200, 5 pack	16158
	ASIC Encrypto Smartchip™ for use in Samsung ML 1665, 1860, 1865, SCX 3200, 3205 (MLT-D1042S) (1,500 pages) (EU)	16432
	ASIC Encrypto Smartchip™ for use in Samsung ML 1665, 1661, 1660, 1865, SCX 3200 (MLT-D104S) (1,500 pages) (US)	16433
	ASIC Encrypto Smartchip™ for use in Samsung ML 1665, 1661, 1660, 1675, 1865, SCX 3200, 3205 (MLT-D104S) (1,500pages)	17246
	SuMMIT® OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 100 pack	17418
	X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 1kg	17674
	SAMSUNG SCX 4828, 4826, 4825, 4824	
	Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, 65g (2,000 pages)	12106
	Absolute Black® toner for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828, 22 lb (10 kg) bag	12107
	Absolute Black® toner for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, 145g (5,000 pages)	12109
	Developer roller sealing blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828, 50 pack	13007
	Recovery blade for use in Samsung ML 2450, 2850, 2855, SCX 4824, 4825, 4826, 4828, 50 pack	13008
	PCR roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650, 10 pack	13488
	ASIC Encrypto Smartchip™ for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209S)(US)(2,000 pages)	13858
	Developer roller for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4825, 4824, SF 650, 10 pack	14073
	Doctor blade for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650, 10 pack	14074
	Doctor blade sealing foam for use in Samsung ML 1910, 2450, 2525, 2545, 2850, 2855, SCX 4600, 4828, 4824, SF 650, 100 pack	14501
	ASIC Encrypto Smartchip™ for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209L)(US)(5,000 pages)	15970
	Smartchip cover for use in Samsung® ML 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, 10 pack (MLT-D209)	16453
	ASIC Encrypto Smartchip™ for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D2092L)(EU)(5,000 pages)	16731
	ASIC Encrypto Smartchip™ for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209S)(2,000 pages)(EU)	16732
	X-Generation® Wiper blade for use in Samsung ML 2450, 2850, 2851, 2855, SCX 4824, 4825, 4826, 4828, 10 pack (MLT-D209)	17078
	ASIC Encrypto Smartchip™ for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209S)(EXP)(2,000 pages)	17320
	ASIC Encrypto Smartchip™ for use in Samsung ML 2855, SCX 4828, 4826, 4825, 4824 (MLT-D209S)(EXP)(5,000 pages)	17321
	SAMSUNG SCX 4728, 4729 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	X-Generation® Black toner for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729, 95g (2,500 pages)	16913
	X-Generation® Black toner for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729, TBAg (1,500 pages)	16914
	ASIC Encrypto Smartchip™ for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729 (MLT-D103L) (2,500pages) (EUR)	16986
	ASIC Encrypto Smartchip™ for use in Samsung ML 2955, 2951, 2955, SCX 4728, 4729 (MLT-D103S) (1,500pages) (EUR)	16987
	SAMSUNG SCX 4729	
	X-Generation® Black toner for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729, 95g (2,500 pages)	16913
	X-Generation® Black toner for use in Samsung ML 2950, 2951, 2955, SCX 4728, 4729, TBAg (1,500 pages)	16914
	ASIC Encrypto Smartchip™ for use in Samsung ML 2955, SCX 4729 (MLT-D103L)(2,500 pages)(US)	16790
	ASIC Encrypto Smartchip™ for use in Samsung ML 2955, SCX 4729 (MLT-D103L)(2,500pages)(EXP)	17280
	ASIC Encrypto Smartchip™ for use in Samsung ML 2955, SCX 4729 (MLT-D103S)(1,500pages)(US)	16791
	SAMSUNG SCX 4833, 4835, 5639, 5737, 5739 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, 3750, SCX 4833, 4835, 5639, 5737, 5739, 22lb (10kg) bag	16912
	Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739, 285g (MLT-D205E)(10,000 pages)	16794
	Absolute Black® toner for use in Samsung ML 3310, 3312, 3710, 3712, SCX 4833, 4835, 5639, 5737, 5739,145g (MLT-D205L)(5,000 pages)	16333
	ASIC Encrypto Smartchip™ for use in Samsung ML 3710, 3712, SCX 5639, 5739 (MLT-D205E)(10,000 pages)(EXP)	16993
	ASIC Encrypto Smartchip™ for use in Samsung ML 3710, SCX 5637 (MLT-D205E)(10,000pages)(USA)	16353
	ASIC Encrypto Smartchip™ for use in Samsung ML 3710, SCX 5737 (MLT-D205E)(10,000pages)(EU)	16951
	SAMSUNG SCX 3205, 3200	
	X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 22 lb (10 kg) bag	15908
	X-Generation® Black toner for use in Samsung ML 1860, 1665,1660, SCX 3205, 3200, 45g (1,500 pages)	15906
	X-Generation® Black toner for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 1kg	17674
	X-Generation® Wiper blade for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 10 pack	16105
	Developer roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 10 pack	15950
	Drum cover for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 10 pack	15957
	PCR roller for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 10 pack	15951
	SuMMIT® OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200, 100 pack	17418
	SuMMIT® OPC drum for use in Samsung ML 1860, 1665, 1660, SCX 3205, 3200	16014
	SAMSUNG SCX 7128, 7135, 7145	
	Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145, 176 lb (80 kg)	5285
	Absolute Black® toner for use in Samsung SCX 7128, 7135, 7145, 480g	5287
	Ecographics toner for use in Samsung SCX 7128, 7135, 7145, 176lbs(80kg)	5289
	Ecographics toner for use in Samsung SCX 7128, 7135, 7145, 198lbs(90kg)	16933
	Ecographics™ toner for use in Samsung SCX 7128, 7135, 7145, 320g	5924
	Uni Drum with gears for use in Samsung SCX 7128, 7135, 7145	5288
	SHARP®	
	SHARP AL 1000, 2021, 2031, 2041, 2051 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® developer for use in Sharp AL 1000, 2021, 2031, 2041, 2051, 190g	6032
	Absolute Black® toner for use in Sharp AL 1000, 2021, 2030, 2031, 2041, 2051, 220g	6031
	Absolute Black® toner for use in Sharp AL 1000, 2021, 2031, 2041, 2051, 22 lb (10 kg) bag	8128
	Developer for use in Sharp AL 1000, 2021, 2031, 2041, 2051, 55 lb (25 kg)	5620
	Seal shipping cover protector for use in Sharp AL 1000, 2021, 2031, 2041, 2051, 100 pack	6532
	Smartchip™ for use in Sharp AL 2021, 2031, 2041, 2051 (AL204TD)(6,000 pages)	16098

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Smartchip™ for use in Sharp AL 2021, 2031, 2041, 2051 (AL204TD)(6,000 pages) 25 pack	17296
	SuMMiT® drum with gears for use in Sharp AL 1000, 2021, 2031, 2041, 2051, 5 pack	12708
	Unidrum™ with gears for use in Sharp AL 1000, 2021, 2031, 2041, 2051	16785
	X-Generation® Wiper blade for use in Sharp AL 1000, 2021, 2031, 2041, 2051, 10 pack	6015
	SHARP AR 650, 800	
	Developer for use in Sharp AR 650, AR 800, 1,500g	14219
	SHARP AR 162, 162s, 163, 164	
	Smartchip™ w/ housing for use in Sharp AR 162, 162s, 163, 164 (USA)	13832
	Smartchip™ w/housing for use in Sharp AR 162,162s, 163, 164, 201, 202, 207 T (AR202T) (EU)	11384
	SHARP AR 160, 161, 200, 205, AL 1600	
•	X-Generation® Wiper blade for use in Sharp AR 160, 161, 200, 205, AL 1600,	5974
•	Absolute Black® toner for use in Sharp AR 160, 161, 200, 205, AL 1600, 320g (use 2 per cartridge)	6481
•	Absolute Black® toner for use in Sharp AR 160, 161, 200, 205, AL 1600, 22 lb (10 kg) bag	6482
•	Absolute Black® developer for use in Sharp AR 160, 161, 200, 205, AL 1600, 390g	6483
•	Seal cover for use in Sharp AR 160, 161, 200, 205, AL 1600, 10 pack	6485
•	Absolute Black® toner for use in Sharp AR 160, 161, 200, 205, AL 1600, 640g	9384
•	Absolute Black® developer for use in Sharp AR 160, 161, 200, 205, AL 1600, 55lb (25kg) bag	11472
•	Smartchip™ w/ housing for use in Sharp AR 162, 162s, 163, 164, ARM 160, 162, 205, 207 (USA)	13832
•	SuMMiT® Drum with gears for us in Sharp AR 160, 161, 200, 205 AL 160	17521
	SHARP AR 5020, 5220, 5316, 5320	
•	Absolute Black® toner for use in Sharp AR 5020, 5220, 5316, 5320, 320g	10344
•	Absolute Black® toner for use in Sharp AR 5020, 5220, 5316, 5320, 22 lb (10 kg) bag	10345
•	Absolute Black® developer for use in Sharp AR 5020, 5220, 5316, 5320, 275g	10346
•	Smartchip™ for use in Sharp AR 5020, 5220, 5316, 5320, AR-016FT (Africa, Middle East & Philippines)	10951
•	Smartchip™ for use in Sharp AR 5020, 5220, 5316, 5320, AR-016LT (Other regions)	10952
•	Absolute Black® developer for use in Sharp AR 5020, 5220, 5316, 5320, 400g	14502
•	Smartchip™ for use in Sharp AR 5020, 5220, 5316, 5320, AR-016TD (USA)	15133
•	Unidrum™ with gears for use in Sharp AR 5020, 5220, 5316, 5320	16281
•	SuMMiT® drum with gears for use in Sharp AR 5020, 5220, 5316, 5320	17619
	SHARP AR 200, 205, AL 2000	
•	X-Generation® Wiper blade for use in Sharp AR 160, 161, 200, 205, AL 1600, (10/2011 new formulation)	5974
•	Absolute Black® toner for use in Sharp AR 160, 161, 200, 205, AL 1600, 320g (use 2 per cartridge)	6481
•	Absolute Black® toner for use in Sharp AR 160, 161, 200, 205, AL 1600, 22 lb (10 kg) bag	6482
•	Seal cover for use in Sharp AR 160, 161, 200, 205, AL 1600, 10 pack (special order)	6485
•	Absolute Black® toner for use in Sharp AL 2000, AR 200, 205, 310g (use 2 per cartridge)	6658
•	Absolute Black® toner for use in Sharp AL 2000, AR 200, 205, 22 lb (10 kg) bag	6659
•	Absolute Black® developer for use in Sharp AL 2000, AR 200, 205, 395g	6660
•	Absolute Black® toner for use in Sharp AR 160, 161, 200, 205, AL 1600, 640g	9384
•	SuMMiT® Drum with gears for us in Sharp AR 160, 161, 200, 205 AL 160	17521
•	Absolute Black® toner for use in Sharp AL 2000, AR 200, 205, 198lbs (90kg) barrel	18263
	SHARP AR 450, 350, 280	
	Absolute Black® developer carrier for use in Sharp AR 450, 350, 280, 390g	10954
	Smartchip™ toner for use in Sharp AR 450, 350, 280	10950
	SHARP AR 455 MD	
	Absolute Black® developer carrier for use in Sharp AR 455 MD, 400g (75,000 pages)	14211
	Absolute Black® developer for use in Sharp AR 455 MD, 55lb (25kg) bag	14550
	Absolute Black® toner for use in Sharp AR 455 NT/T, 198lbs (90kg) barrel (same as 14583 formulation)	16830
	Absolute Black® toner for use in Sharp AR 455 NT/T, 800g (25,000 pages)	14209
	Replacement toner cartridge for use in Sharp AR M 351, 355, 451, 455, 750g (AR455NT)	14372
	Smartchip™ for use in Sharp AR 455 NT, (US, Canada, Mexico)	13950
	Smartchip™ for use in Sharp AR 455 T (AR455T) (EU)	13920
	Unidrum™ OPC for use in Sharp AR 455 DR	14212
	SHARP AR 500, 501, 505, 507	
	Absolute Black® toner for use in Sharp AR 500, 501, 505, 507, 650g	9093
	SHARP AR M 550, 620, 700	
	Absolute Black® toner for use in Sharp AR M 550, 620, 700 1500g	15873
	SHARP AR 270, 310, NT, AR M 208, 236, 237, 257, 276, 277, 317	
	Absolute Black® toner for use in Sharp AR 270, 310, NT, AR M 208, 236, 237, 257, 276, 277, 317, 740g	9094
	Unidrum™ with gears for use in Sharp AR 270 ND	10296
	SHARP AR 5618D, AR 5623D, MX M182, MX M182D, MX M202D, MX M232D (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
•	Smartchip™ for use in Sharp AR 5618D, AR 5623D, MX M182, MX M182D, MX M202D, MX M232D (MX235NT) (16,000pages)	18259
	SHARP AR 020ST, AR 5516, 5520	
	Smartchip™ for use in Sharp AR 020ST, AR 5516, 5520 (Asia Pacific)	18262
	SHARP DX B 350 P (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Sharp DX B 350 P, 785g (18,000 pages)	17809
	Clear Seal™ adhesive for use in Sharp DX B 350 P, 50 pack	14353
	Doctor blade for use in Sharp DX B 350 P, 10 pack	14354
	PCR (recosted) roller for use in Sharp DX B 350 P, 10 pack	14352
	Smartchip™ for use in Sharp DX B 350 P (DX-B35DTH)(18,000 pages)	14349
	Unidrum™ with gears for use in Sharp DX B 350 P	14350

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Wiper blade for use in Sharp DX B 350 P, 10 pack	14351
	X-Generation® Black toner for use in Sharp DX B 350 P, 790g (18,000 pages)	14348
	SHARP FO DC 550, FO 55 ND, 4400, 4450	
	Absolute Black® developer for use in Sharp FO 55 ND, 4400, 4450, DC 550, 190g	17387
	Absolute Black® toner for use in Sharp FO 55 ND, 4400, 4450, DC 550, 220g	10462
	Smartchip™ for use in Sharp FO 55 ND, 4400, 4450, DC 550 (FO-55ND) (8,000pages) (US)	10463
	SuMMIT® drum with gear for use in Sharp FO 55 ND, 4400, 4450, DC 550, 5 pack	16591
	X-Generation® wiper blade for use in Sharp FO 55 ND, 4400, 4450, DC 550, 10 pack	17388
	SHARP FO 2081 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® developer for use in Sharp FO-2081 (FO56ND), 190g	17760
	Absolute Black® toner for use in Sharp FO-2081 (FO56ND), 220g (6,000 pages)	17481
	Smartchip™ for use in Sharp FO-2081 (FO56ND) (6,000pages)	17449
	SuMMIT® drum with gears for use in Sharp FO 2081, 5 pack	17838
	SHARP FO 26 ND, 2600, 3800	
	Absolute Black® toner for use in Sharp FO 26 ND, 2600, 3800, 22 lb (10 kg)	6428
	Absolute Black® toner for use in Sharp FO 26 ND, 2600, 3800, 80g (2,000 pages)	5621
	Unidrum™ with gears for use in Sharp FO 26 ND, 2600, 3800	6936
	SHARP FO 28ND	
	Absolute Black® toner for use in Sharp FO 28 ND, 85g	6270
	Smartchip™ toner for use in Sharp AR 450, 350, 280, 10950	
	SHARP FO 29 ND, 3800, 3150, 2950	
	Absolute Black® toner for use in Sharp FO 29 ND, 3800, 3150, 2950, 100g (3,000 pages)	10215
	SHARP FO 35 ND, 3350	
	Absolute Black® toner for use in Sharp FO 35 ND, 3350, 250g	5587
	SHARP FO 45 ND, 4500, 5500, 6550, 7500	
	Absolute Black® toner for use in Sharp FO 45 ND, 4500, 5500, 6550, 7500, 90g	6269
	SHARP FO 47 ND, 4700	
	Absolute Black® toner for use in Sharp FO 47 ND, 4700, 22 lb (10kg)	7157
	Absolute Black® toner for use in Sharp FO 47 ND, 4700, 200g	7717
	SuMMIT® with gears for use in Sharp FO 47 ND, 4700	16596
	Black toner for use in Sharp FO 47ND, 200g	18852
	SHARP FO 48 ND, 3450, 4800, 5400	
	Absolute Black® toner for use in Sharp FO 48 ND, 3450, 4800, 5400, 320g	5622
	Developer for use in Sharp FO 48 ND, 3450, 4800, 5400, 180g	5623
	Smartchip™ reset fuse for use in Sharp Fax FO 3450,4800, 5400, FO 48ND (2 per cartridge)	5627
	SHARP JX 9200	
	Absolute Black® toner for use in Sharp JX 9200, 22 lb (10 kg) bag	6098
	Absolute Black® toner for use in Sharp JX 9200, 82g	617
	Unidrum™ S with gears for use in Sharp JX 9200	6935
	SHARP JX 9600, 9400	
	Absolute Black® toner for use in Sharp JX 9600, 9400, 22b (10kg) bag	5382
	Absolute Black® toner for use in Sharp JX 9600, 9400, 310g	620
	Developer for use in Sharp JX 9600, 9400, 175g	628
	Felt for use in Sharp JX 9600, 9400, 10 pack	630
	Smartchip™ reset fuse for use in Sharp JX 9600, 9400, each (2 per cartridge)	633
	Unidrum™ S gearless for use in Sharp JX 9600, 9400	632
	Wand for use in Sharp JX 9600, 9400, 10 pack	7771
	Wand for use in Sharp JX 9600, 9400, 100 pack	5846
	Wiper blade for use in Sharp JX 9600, 9400, 10 pack	8351
	SHARP MX 2300N, 2700N, 3500N, 3501N, 4501 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (18,000 pages)	13753
	Absolute Black® toner for use in Sharp MX 3500N, 3501N, 4501, (36,000 pages)	13752
	Absolute Cyan™ toner for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (15,000 pages)	13754
	Absolute Magenta™ toner for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (15,000 pages)	13755
	Absolute Yellow™ toner for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (15,000 pages)	13756
	Smartchip™ Black for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (MX27GTBA) (EU) (18,000 pages)	13758
	Smartchip™ Black for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (MX27NTBA) (USA) (18,000 pages)	13757
	Smartchip™ Black for use in Sharp MX 3500N, 3501N, 4501, (MX45GTBA) (EU) 36,000 pages	13751
	Smartchip™ Black for use in Sharp MX 3500N, 3501N, 4501, (MX45NTBA) (USA) 36,000 pages	13750
	Smartchip™ Cyan for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (MX27GTCA) (EU) (15,000 pages)	13762
	Smartchip™ Cyan for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (MX27NTCA) (USA) (15,000 pages)	13759
	Smartchip™ Magenta for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (MX27GTMA) (EU) (15,000 pages)	13763
	Smartchip™ Magenta for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (MX27NTMA) (USA) (15,000 pages)	13760
	Smartchip™ Yellow for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (MX27GTYA) (EU) (15,000 pages)	13764
	Smartchip™ Yellow for use in Sharp MX 2300N, 2700N, 3500N, 3501N, 4501, (MX27NTYA) (USA) (15,000 pages)	13761
	SHARP MX-M 200 D (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Sharp MX-M 200 D (MX-206NT)(16,000 pages) 525g	17668
	Smartchip™ toner for use in Sharp MX-M 200 D (MX-206NT)(16,000 pages)(US)	17583

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	SHARP SF 1014 Toner refill bottle for use in Sharp SF 1014, 260g	11820
	SHARP SF 7300, 7320, 7350, 7370 Refill bottles for use in Sharp SF 7300, 7320, 7350, 7370, 260g (SF-730MT1)	11839
	TOSHIBA®	
	TOSHIBA E STUDIO 200 CP	
	Absolute Black® toner for use in Toshiba e Studio 200 CP, 270g (12,000 pages)	10142
	Absolute Cyan™ toner for use in Toshiba e Studio 200 CP, 270g (12,000 pages)	10143
	Absolute Magenta™ toner for use in Toshiba e Studio 200 CP, 270g (12,000 pages)	10144
	Absolute Yellow™ toner for use in Toshiba e Studio 200 CP, 270g (12,000 pages)	10145
	Smartchip™ for use in Toshiba e-Studio 200 Series (T2025) (3,000pages)	17139
	TOSHIBA E STUDIO 205 CP	
	Absolute Magenta™ toner for use in Toshiba e Studio 205 CP, 205g (5,000 pages)	11693
	Absolute Black® toner for use in Toshiba e Studio 205 CP, 310g (8,000 pages)	11691
	Absolute Yellow™ toner for use in Toshiba e Studio 205 CP, 205g (5,000 pages)	11694
	Absolute Cyan™ toner for use in Toshiba e Studio 205 CP, 205g (5,000 pages)	11692
	Smartchip™ Black for use in Toshiba e Studio 205 CP (8,000 pages)	11695
	Smartchip™ Cyan for use in Toshiba e Studio 205 CP (5,000 pages)	11696
	Smartchip™ Magenta for use in Toshiba e Studio 205 CP (5,000 pages)	11697
	Smartchip™ Yellow for use in Toshiba e Studio 205 CP (5,000 pages)	11698
	TOSHIBA E STUDIO 12, 15, 120, 150	
	Absolute Black® toner for use in Toshiba e Studio 12, 15, 120, 150, 238g	11509
	Developer for use in Toshiba e-Studio 12, 15, 120, 150 175g	11510
	X-Generation® Wiper blade for use in Toshiba e Studio 12, 15, 120, 150, 10 pack	11512
	TOSHIBA E STUDIO 16, 20, 25, 250	
	Absolute Black® toner for use in Toshiba e Studio 16, 20, 25, 250, 335g	8822
	Unidrum™ with gears for use in Toshiba e Studio 16, 20, 25, 160, 200, 230, 250, 280 (33,000 pages)	8543
	TOSHIBA E STUDIO 161, T 1620	
	Absolute Black® toner for use in Toshiba e Studio 161, T 1620, 537g	11567
	SuMMiT® drum with gears for use in Toshiba e Studio 161, T 1620	16382
	Wiper blade for use in Toshiba e Studio 161, T 1620, 10 pack	11570
	Absolute Black® compatible developer for use in Toshiba e Studio 161, T 1620, 390g	11568
	TOSHIBA E STUDIO 163, 165, 203, 205, T 1640	
	Smartchip™ for use in Toshiba e Studio 163, 165, 203, 205, T 1640	11701
	Absolute Black® drum unit carrier developer for use in Toshiba e Studio 163, 165, 203, 205, 480g	11514
	Absolute Black® toner for use in Toshiba e Studio 163, 165, 203, 205, T 1640, 675g	11513
	TOSHIBA E STUDIO 168, 208, 258	
	Unidrum™ with gears for use in Toshiba e Studio 168, 208, 258	12673
	Wiper blade for use in Toshiba e-studio 168, 208, 258	12669
	Smartchip™ for use in Toshiba e Studio 163, 165, 203, 205, T 1640	11701
	TOSHIBA E STUDIO 20 P, 25 P (same as Lexmark T 430)	
	• Shim washer for use in Lexmark 4059, T 420, 430, 520, 610, 620, 630, 100 pack	6140
	• Universal waste hopper for use in Lexmark T 420, 430	6297
	• Shim washer for use in Lexmark 4059, T 420, 430, 520, 610, 620, 630, 100 pack	7003
	• Wiper blade for use in Lexmark T 420, 430, X 422, IBM 1422, 10 pack	8396
	• Absolute Black® toner for use in Lexmark T 430, X 422, IBM 1422, 325g (12,000 pages)	9623
	• Absolute Black® toner for use in Lexmark T 430, X 422, IBM 1422, 155g (6,000 pages)	9625
	• Absolute Black® toner for use in Lexmark T 430, X 422, IBM 1422, 22 lb (10kg) bag	10780
	• Developer roller for use in Lexmark T 420, 430, X 422, 10 pack	11857
	• SuMMiT® drum w/gears for use in Lexmark T 420, 430, X 422, IBM 1422, 5 pack	12025
	• Superchip™ Universal for use in Lexmark T 430 (12,000 pages) (Worldwide)	13456
	• Smartchip™ MICR for use in Lexmark T 430, (8,000 pages) (Worldwide)	14131
	TOSHIBA E STUDIO 320 P (same as Lexmark T 430)	
	• Shim washer for use in Lexmark 4059, T 420, 430, 520, 610, 620, 630, 100 pack	6140
	• Universal waste hopper for use in Lexmark T 420, 430	6297
	• Shim washer for use in Lexmark 4059, T 420, 430, 520, 610, 620, 630, 100 pack	7003
	• Wiper blade for use in Lexmark T 420, 430, X 422, IBM 1422, 10 pack	8396
	• Absolute Black® toner for use in Lexmark T 430, X 422, IBM 1422, 325g (12,000 pages)	9623
	• Absolute Black® toner for use in Lexmark T 430, X 422, IBM 1422, 155g (6,000 pages)	9625
	• Absolute Black® toner for use in Lexmark T 430, X 422, IBM 1422, 22 lb (10kg) bag	10780
	• Developer roller for use in Lexmark T 420, 430, X 422, 10 pack	11857
	• SuMMiT® drum w/gears for use in Lexmark T 420, 430, X 422, IBM 1422, 5 pack	12025
	• Superchip™ Universal for use in Lexmark T 430 (12,000 pages) (Worldwide)	13456
	• Smartchip™ MICR for use in Lexmark T 430, (8,000 pages) (Worldwide)	14131
	TOSHIBA E STUDIO CP 220, 205 (same as Lexmark C 520)	
	• Absolute Black® toner for use in Lexmark C 520, 522, 524, 530, 532, 534, 155g (4,000 pages)	10171
	• Absolute Black® toner for use in Lexmark C 520, 522, 524, 530, 532, 534, 310g (8,000 pages)	10585
	• Smartchip™ Black for use in Lexmark C 520, 522, 524, 530, 532, 534, (8,000 pages)	10985
	• Smartchip™ Cyan for use in Lexmark C 520, 522, 524, 530, 532, 534, (5,000 pages)	10986
	• Smartchip™ Magenta for use in Lexmark C 520, 522, 524, 530, 532, 534, (5,000 pages)	10987
	• Smartchip™ Yellow for use in Lexmark C 520, 522, 524, 530, 532, 534, (5,000 pages)	10988

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
•	Absolute Black® toner for use in Lexmark C 520, 530, 65g (1,500 pages)	11298
•	Absolute Cyan™ toner for use in Lexmark C 520, 530, 65g (1,500 pages)	11299
•	Absolute Yellow™ toner for use in Lexmark C 520, 530, 65g (1,500 pages)	11301
•	Smartchip™ Black for use in Lexmark C 520, 530, (1,500 pages)	11302
•	Smartchip™ Cyan for use in Lexmark C 520, 530, (1,500 pages)	11303
•	Smartchip™ Magenta for use in Lexmark C 520, 530, (1,500 pages)	11304
•	Smartchip™ Yellow for use in Lexmark C 520, 530, (1,500 pages)	11305
•	X-Generation® Cyan toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (7,000 pages)	11306
•	X-Generation® Magenta toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (7,000 pages)	11307
•	X-Generation® Yellow toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (7,000 pages)	11308
•	Smartchip™ Cyan for use in Lexmark C 520, 522, 524, 530, 532, 534, (7,000 pages)	11309
•	Smartchip™ Magenta for use in Lexmark C 520, 522, 524, 530, 532, 534, (7,000 pages)	11310
•	Smartchip™ Yellow for use in Lexmark C 520, 522, 524, 530, 532, 534, (7,000 pages)	11311
•	Seal toner hopper fill plug for use in Lexmark C 520, 522, 524, 530, 532, 534, 734, 736, 100 pack (32mm)	11626
•	Smartchip™ Black for use in Lexmark C 520, 522, 524, 530, 532, 534, (4,000 pages)	11807
•	Smartchip™ Cyan for use in Lexmark C 520, 522, 524, 530, 532, 534, (3,000 pages)	11808
•	Smartchip™ Magenta for use in Lexmark C 520, 522, 524, 530, 532, 534, (3,000 pages)	11809
•	Smartchip™ Yellow for use in Lexmark C 520, 522, 524, 530, 532, 534, (3,000 pages)	11810
•	X-Generation® Black toner for use in Lexmark C 520, 522, 524, 530, 532, 534, 22 lb (10 kg) bag	12725
•	X-Generation® Cyan toner for use in Lexmark C 520, 522, 524, 530, 532, 534, 22 lb (10kg) bag	12726
•	X-Generation® Magenta toner for use in Lexmark C 520, 522, 524, 530, 532, 534, 22 lb (10 kg) bag	12727
•	X-Generation® Yellow toner for use in Lexmark C 520, 522, 524, 530, 532, 534, 22 lb (10kg) bag	12728
•	X-Generation® Black toner for use in Lexmark C 520, 522, 524, 530, 532, 534 (4,000 pages)	12742
•	X-Generation® Cyan toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (3,000 pages)	12743
•	X-Generation® Magenta toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (3,000 pages)	12744
•	X-Generation® Yellow toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (3,000 pages)	12745
•	Absolute Black® toner for use in Lexmark C 520, 522, 524, 530, 532, 534, 22 lb (10 kg) bag	13011
•	Developer roller cover for use in Lexmark C 520, 522, 524, 530, 532, 534, 730, 734, 736, 10 pack	14120
•	X-Generation® Black toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (8,000 pages)	14424
•	X-Generation® Cyan toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (5,000 pages)	16288
•	X-Generation® Magenta toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (5,000 pages)	16289
•	X-Generation® Yellow toner for use in Lexmark C 520, 522, 524, 530, 532, 534, (5,000 pages)	16290
•	Developer roller for use in Lexmark C 736, 734, 730, 534, 532, 530, 524, 522, 520, 10 pack	18876
•	Doctor blade for use in Lexmark C 736, 734, 730, 534, 532, 530, 524, 522, 520, 10 pack	18877
	TOSHIBA E STUDIO 520, 550, 600, 650, 720, 810, 850	
	Unidrum™ F with gears for use in Toshiba e Studio 520, 550, 600, 650, 720, 810, 850 (500,000 pages)	5161
	TOSHIBA E STUDIO 350, 450	
	Upper Fuser Roller for use in Toshiba E-Studio 350, 450 (6LA27552000)	15085
	Upper Picker Finger for use in Toshiba E-Studio 350, 358, 450, 458, 6 pack (44202983000)	15086
	TOSHIBA E STUDIO 28, 35, 45, T 3500	
	Absolute Black® toner for use in Toshiba e Studio 28, 35, 45, T 3500, 450g	8823
	Unidrum™ F with gears for use in Toshiba e Studio 28, 35, 45, 350, 450 (150,000 pages)	8991
	Wiper blade for use in Toshiba e Studio 28, 35, 45, 350, 450	12583
	TOSHIBA E STUDIO 358, 458, DP2800, 3500, 4500	
	Upper Fuser Roller for use in Toshiba E-Studio 358, 458, DP2800, 3500, 4500 (44299019000)	15084
	TOSHIBA E STUDIO 2500C, 3500C, 3510C	
	Absolute Black® toner for use in Toshiba e Studio 2500C, 3500C, 3510C, 600g	12593
	Absolute Magenta™ toner for use in Toshiba e Studio 2500C, 3500C, 3510C, 590g	12619
	Absolute Yellow™ toner for use in Toshiba e Studio 2500C, 3500C, 3510C, 22 lb (10 kg) bag	12625
	Absolute Yellow™ toner for use in Toshiba e Studio 2500C, 3500C, 3510C, 590g	12621
	TOSHIBA E STUDIO 500 P	
	Smartchip™ for use in Toshiba e-Studio 500 P	11154
	TOSHIBA E STUDIO 250 CP	
	Smartchip for toner cartridge for use in Toshiba e Studio 250 CP	6713
	TOSHIBA E STUDIO 270 P, 300 P	
	Toshiba e-Studio 270 P, 300 P Superchip Universal™	11699
	TOSHIBA E STUDIO 170 F	
	Smartchip™ for use in Toshiba e Studio 170 F (6,000 pages) (US version)	12050
	SuMMIT® drum with gears for use in Toshiba e Studio 170 F	16594
	TOSHIBA E STUDIO 190 P (same as Lexmark Optra E 321)	
	Toshiba e Studio 190 P (see Lexmark Optra E 321)	5659
	Absolute Black® toner for use in Lexmark Optra E 321, 323, 80g (3,000 pages)	6775
	Shipping lock for use in Lexmark Optra E 320, 321, 322, 323, 220, 10 pack	8255
	Absolute Black® toner for use in Lexmark Optra E 321, 323, 22 lb (10 kg) bag	8568
	Absolute Black® toner for use in Lexmark Optra E 321, 323, 155g (6,000 pages)	8569
	Wiper blade for use in Lexmark Optra E 321, 323, 10 pack	8571
	Doctor bar for use in Lexmark Optra E 220, 320, 321, 322, 323, 10 pack	9899
	Developer roller for use in Lexmark Optra E 320, 321, 322, 10 pack	10839
	SuMMIT® drum w/gears for use in Lexmark Optra E 220, 320, 321, 322, 323	12023
	Superchip™ Universal for use in Lexmark Optra E 321, 323, 220 (2,500 pages) (Worldwide)	13442
	Superchip™ Universal for use in Lexmark Optra E 321, 323, 220 (6,000 pages) (Worldwide)	13445
	Smartchip™ MICR for use in Lexmark Optra E 321, IBM 1312, Source Tech 9216 (3,250 pages) (Worldwide)	14129

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	TOSHIBA BD 1340, 1350, 1370	
	Unidrum™ F with gears for use in Toshiba BD 1340, 1350, 1370	9000
	Wiper blade for use in Toshiba BD 1340, 1350, 1370	12581
	TOSHIBA T 2060, 2860, 2870	
	Unidrum™ F with gears for use in Toshiba T 2060, 2860, 2870, 20 pack (80,000 pages)	9004
	Wiper blade for use in Toshiba T 2060, 2860, 2870	12582
	XEROX®	
	XEROX PHASER 7500 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Xerox Phaser 7500 (19,800 pages)	16055
	Absolute Cyan® toner for use in Xerox Phaser 7500 (17,800 pages)	16056
	Absolute Magenta® toner for use in Xerox Phaser 7500 (17,800 pages)	16057
	Absolute Yellow® toner for use in Xerox Phaser 7500 (17,800 pages)	16058
	Smartchip™ Black for use in Xerox Phaser 7500 (106R01439)(19,800 pages)(USA, EU)	15958
	Smartchip™ Black for use in Xerox Phaser 7500 (106R01446)(17,800 pages)(Latin America, East EU, Africa)	16680
	Smartchip™ CMYK drum unit for use in Xerox Phaser 7500 (108R00861) (80,000 pages)	15962
	Smartchip™ Cyan for use in Xerox Phaser 7500 (106R01436)(17,800 pages)(USA, EU)	15959
	Smartchip™ Cyan for use in Xerox Phaser 7500 (106R01443)(17,800 pages)(Latin America, East EU, Africa)	16681
	Smartchip™ Magenta for use in Xerox Phaser 7500 (106R01437)(17,800 pages)(USA, EU)	15960
	Smartchip™ Magenta for use in Xerox Phaser 7500 (106R01444)(17,800 pages)(Latin America, East EU, Africa)	16690
	Smartchip™ Yellow for use in Xerox Phaser 7500 (106R01438)(17,800 pages)(USA, EU)	15961
	Smartchip™ Yellow for use in Xerox Phaser 7500 (106R01445)(17,800 pages)(Latin America, East EU, Africa)	16691
	SuMMIT® drum with gears and insert for use in Xerox Phaser 7500	17647
	X-Generation® drum with gears and insert for use in Xerox Phaser 7500	17569
	X-Generation® Glossy Black toner for use in Xerox Phaser 7500, 390g (19,800 pages)	17493
	X-Generation® Glossy Cyan toner for use in Xerox Phaser 7500, 310g (17,800 pages)	17494
	X-Generation® Glossy Magenta toner for use in Xerox Phaser 7500, 325g (17,800 pages)	17495
	X-Generation® Glossy Yellow toner for use in Xerox Phaser 7500, 370g (17,800 pages)	17496
	XEROX PHASER 6121 MFP (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Xerox Phaser 6121 MFP (2,600 pages)	17877
	Absolute Cyan™ toner for use in Xerox Phaser 6121 MFP (2,600 pages)	17878
	Absolute Magenta™ toner for use in Xerox Phaser 6121 MFP (2,600 pages)	17879
	Absolute Yellow™ toner for use in Xerox Phaser 6121 MFP (2,600 pages)	17880
	Developer roller cover for use in Xerox Phaser 6121 MFP, 10 pack	18289
	Smartchip™ Black for use in Xerox Phaser 6121 MFP (106R01469)(2,600 pages) (EU)	16189
	Smartchip™ Cyan for use in Xerox Phaser 6121 MFP (106R01466)(2,600 pages) (EU)	16190
	Smartchip™ Magenta for use in Xerox Phaser 6121 MFP (106R01467)(2,600 pages) (EU)	16191
	Smartchip™ Yellow for use in Xerox Phaser 6121 MFP (106R01468)(2,600 pages) (EU)	16192
	XEROX PHASER 6500, WORKCENTRE 6505 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Smartchip™ Black for use in Xerox Phaser 6500, WC 6505 (106R01604)(3,000 pages)	17349
	Smartchip™ Black for use in Xerox Phaser 6500, WC 6505 (106R1597)(3,000 pages)	16546
	Smartchip™ Cyan for use in Xerox Phaser 6500, WC 6505 (106R01601)(2,500 pages)	17350
	Smartchip™ Cyan for use in Xerox Phaser 6500, WC 6505 (106R1594)(2,500 pages)	16547
	Smartchip™ Magenta for use in Xerox Phaser 6500, WC 6505 (106R01602)(2,500 pages)	17352
	Smartchip™ Magenta for use in Xerox Phaser 6500, WC 6505 (106R1595)(2,500 pages)	16548
	Smartchip™ Yellow for use in Xerox Phaser 6500, WC 6505 (106R01603)(2,500 pages)	17353
	Smartchip™ Yellow for use in Xerox Phaser 6500, WC 6505 (106R1596)(2,500 pages)	16549
	X-Generation® Black toner for use in Xerox Phaser 6500, WC 6505, 45g (3,000 pages)	16635
	X-Generation® Cyan toner for use in Xerox Phaser 6500, WC 6505, 40g (2,500 pages)	16636
	X-Generation® Magenta toner for use in Xerox Phaser 6500, WC 6505, 40g (2,500 pages)	16637
	X-Generation® Yellow toner for use in Xerox Phaser 6500, WC 6505, 40g (2,500 pages)	16638
	XEROX PHASER 6600, WORKCENTRE 6605 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Xerox Phaser 6600, WC 6605, 130g (8,000 pages)	18323
	Absolute Black® toner for use in Xerox Phaser 6600, WC 6605, 22lb (10kg) bag	18779
	Absolute Cyan® toner for use in Xerox Phaser 6600, WC 6605, 22lb (10kg) bag	18780
	Absolute Cyan® toner for use in Xerox Phaser 6600, WC 6605, 70g (6,000 pages)	18324
	Absolute Magenta® toner for use in Xerox Phaser 6600, WC 6605, 22lb (10kg) bag	18781
	Absolute Magenta® toner for use in Xerox Phaser 6600, WC 6605, 65g (6,000 pages)	18325
	Absolute Yellow® toner for use in Xerox Phaser 6600, WC 6605, 22lb (10kg) bag	18782
	Absolute Yellow® toner for use in Xerox Phaser 6600, WC 6605, 70g (6,000 pages)	18326
	Smartchip™ Black for use in Xerox Phaser 6600, WC 6605 (WW)(8,000 pages)	18327
	Smartchip™ Cyan for use in Xerox Phaser 6600, WC 6605 (WW)(6,000 pages)	18328
	Smartchip™ Magenta for use in Xerox Phaser 6600, WC 6605 (WW)(6,000 pages)	18329
	Smartchip™ Yellow for use in Xerox Phaser 6600, WC 6605 (WW)(6,000 pages)	18330
	XEROX PHASER 3635 MFP	
	Absolute Black® toner for use in Xerox Phaser 3635 MFP 22 lb (10 kg) bag	16943
	Absolute Black® toner for use in Xerox Phaser 3635 MFP, 135g (5,000 pages)	13212
	Absolute Black® toner for use in Xerox Phaser 3635 MFP, 290g (10,000 pages)	13213
	Developer roller for use in Xerox Phaser 3635 MFP, 10 pack	13214
	PCR roller for use in Xerox Phaser 3635 MFP, 10 pack	16624
	Smartchip™ for use in Xerox Phaser 3635 MFP (108R00795)(10,000 pages)	13218
	Smartchip™ for use in Xerox Phaser 3635 MFP (108R00796)(10,000 pages)	18818
	SuMMIT® drum with gears for use in Xerox Phaser 3635 MFP	13851
	Unidrum™ with gears for use in Xerox Phaser 3635 MFP	15773
	X-Generation® Black toner for use in Xerox Phaser 3635 MFP 22 lb (10 kg) bag	16944
	X-Generation® Black toner for use in Xerox Phaser 3635 MFP, 285g (10,000 pages)	16625
	X-Generation® Doctor blade for use in Xerox Phaser 3635 MFP with sealing foam	18085
	X-Generation® Wiper blade for use in Xerox Phaser 3635 MFP, 10 pack	18118

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	XEROX PHASER 7400	
	Absolute Yellow glossy toner™ for use in Xerox Phaser 7400, (18,000 pages)	13517
	Absolute Yellow™ toner for use in Xerox Phaser 7400, (18,000 pages)	9439
	Replacement Black toner cartridge for use in Xerox Phaser 7400 (10106R01080)(15,000 pages)	15719
	Replacement Cyan toner cartridge for use in Xerox Phaser 7400 (10106R01077)(18,000 pages)	15720
	Replacement Magenta toner cartridge for use in Xerox Phaser 7400 (10106R01078)(18,000 pages)	15721
	Replacement Yellow toner cartridge for use in Xerox Phaser 7400 (10106R01079)(18,000 pages)	15722
	Smartchip™ Black for use in Xerox Phaser 7400, (15,000 pages)	10840
	Smartchip™ Cyan for use in Xerox Phaser 7400, (18,000 pages)	10841
	Smartchip™ drum unit fuse for use in Xerox Phaser 7400, 10 pack	10848
	Smartchip™ Magenta for use in Xerox Phaser 7400, (18,000 pages)	10842
	Smartchip™ Yellow for use in Xerox Phaser 7400, (18,000 pages)	10843
	Unidrum™ with gears for use in Xerox Phaser 7400	9599
	XEROX PHASER 7760 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Magenta™ toner for use in Xerox Phaser 7760, 390g (25,000 pages)	11189
	Absolute Yellow® toner for use in Xerox Phaser 7760, 22 lb (10kg) bag	14884
	Absolute Yellow® toner for use in Xerox Phaser 7760, 500g (25,000 pages)	14889
	Absolute Yellow™ toner for use in Xerox Phaser 7760, 390g (25,000 pages)	11190
	PCR roller for use in Xerox Phaser 7760, 10 pack	14124
	Smartchip™ Black toner for use in Xerox Phaser 7760 (106R01163)(32,000 pages)(WW)	11271
	Smartchip™ Black, Cyan, Magenta, Yellow drum unit for use in Xerox Phaser 7760 (108R00713)(35,000pages)	11920
	Smartchip™ Cyan toner for use in Xerox Phaser 7760 (106R01160)(25,000 pages)(WW)	11272
	Smartchip™ Magenta toner for use in Xerox Phaser 7760 (106R01161) (25,000 pages)(WW)	11273
	Smartchip™ Yellow toner for use in Xerox Phaser 7760 (106R01162) (25,000 pages)(WW)	11274
	Unidrum™ drum gearless for use in Xerox Phaser 7760	11887
	Wiper blade for use in Xerox Phaser 7760	14309
	X-Generation® Black toner for use in Xerox Phaser 7760, 700g (32,000 pages)	17595
	X-Generation® Cyan toner for use in Xerox Phaser 7760, 500g (25,000 pages)	17596
	X-Generation® drum gearless with insert for use in Xerox Phaser 7760	17559
	X-Generation® Magenta toner for use in Xerox Phaser 7760, 500g (25,000 pages)	17598
	X-Generation® Yellow toner for use in Xerox Phaser 7760, 500g (25,000 pages)	17599
	XEROX PHASER 6700 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Xerox Phaser 6700, 350g (18,000 pages)	17272
	Absolute Cyan® toner for use in Xerox Phaser 6700, 220g (12,000 pages)	17273
	Absolute Magenta® toner for use in Xerox Phaser 6700, 200g (12,000 pages)	17274
	Absolute Yellow® toner for use in Xerox Phaser 6700, 205g (12,000 pages)	17275
	Smartchip™ Black for use in Xerox Phaser 6700 (106R01510)(18,000 pages)	17313
	Smartchip™ Cyan for use in Xerox Phaser 6700 (106R01507) (12,000 pages)	17314
	Smartchip™ Magenta for use in Xerox Phaser 6700 (106R01508) (12,000 pages)	17315
	Smartchip™ Yellow for use in Xerox Phaser 6700 (106R01509) (12,000 pages)	17316
	Smartchip™ Black drum unit for use in Xerox Phaser 6700 (108R00974)(50,000 pages)	18175
	Smartchip™ Cyan drum unit for use in Xerox Phaser 6700 (108R00971)(50,000 pages)	18176
	Smartchip™ Magenta drum unit for use in Xerox Phaser 6700 (108R00972)(50,000 pages)	18177
	Smartchip™ Yellow drum unit for use in Xerox Phaser 6700 (108R00973)(50,000 pages)	18178
	XEROX PHASER 7700	
	Absolute Black® toner for use in Xerox Phaser 7700, 200g	9444
	Absolute Black® toner for use in Xerox Phaser 7700, 22 lb (10 kg) bag	11195
	Absolute Cyan™ toner for use in Xerox Phaser 7700, 200g	9445
	Absolute Cyan™ toner for use in Xerox Phaser 7700, 22 lb (10 kg) bag	11196
	Absolute Magenta™ toner for use in Xerox Phaser 7700, 200g	9446
	Absolute Magenta™ toner for use in Xerox Phaser 7700, 22 lb (10 kg) bag	9402
	Absolute Yellow™ toner for use in Xerox Phaser 7700, 200g	9447
	Absolute Yellow™ toner for use in Xerox Phaser 7700, 22 lb (10 kg) bag	9403
	PCR roller for use in Xerox Phaser 7750, 7700, C 2220, 10 pack	10948
	Recovery blade for use in Xerox Phaser 7700, C 2220, 7750, 100 pack	10900
	Unidrum™ gearless for use in Xerox Phaser 7700, C 2220	9988
	Wiper blade for use in Xerox Phaser 7700, 5 pack	12185
	XEROX PHASER 7750	
	Absolute Black® toner for use in Xerox Phaser 7750, 600g (32,000 pages)	11183
	Absolute Cyan™ toner for use in Xerox Phaser 7750, 400g (22,000 pages)	11184
	Absolute Magenta™ toner for use in Xerox Phaser 7750, 400g (22,000 pages)	11185
	Absolute Yellow™ toner for use in Xerox Phaser 7750, 400g (22,000 pages)	11186
	PCR roller for use in Xerox Phaser 7750, 7700, C 2220, 10 pack	10948
	Recovery blade for use in Xerox Phaser 7700, C 2220, 7750, 100 pack	10900
	Unidrum™ gearless for use in Xerox Phaser 7750	11922
	Wiper blade for use in Xerox Phaser 7750, C 2220, 10 pack	11464
	XEROX PHASER 7800 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Smartchip™ Black for use in Xerox Phaser 7800 (106R01569)(24,000 pages)(USA, EU)	17681
	Smartchip™ Black for use in Xerox Phaser 7800 (106R01573)(24,000 pages)(South America, East EU, Africa)	18179
	Smartchip™ Cyan for use in Xerox Phaser 7800 (106R01566)(17,200 pages)(USA, EU)	17682
	Smartchip™ Cyan for use in Xerox Phaser 7800 (106R01570)(17,200 pages)(South America, East EU, Africa)	18180
	Smartchip™ Magenta for use in Xerox Phaser 7800 (106R01567)(17,200 pages)(USA, EU)	17683
	Smartchip™ Magenta for use in Xerox Phaser 7800 (106R01571)(17,200 pages)(South America, East EU, Africa)	18181
	Smartchip™ Yellow for use in Xerox Phaser 7800 (106R01572)(17,200 pages)(South America, East EU, Africa)	18182
	Smartchip™ Yellow for use in Xerox Phaser 7800 (106R01568)(17,200 pages)(USA, EU)	17684
	Smartchip™ CMYK drum unit for use in Xerox Phaser 7800 (108R01582)(145,000 pages)(WW)	17693
	SuMMiT® drum with gears and insert for use in Xerox Phaser 7800	17699
	Unidrum™ with gears and insert for use in Xerox Phaser 7800	17698

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	XEROX PHASER 3320, WORKCENTRE 3315, 3325	
	Absolute Black® toner for use in Xerox Phaser 3320, WorkCentre 3315, 3325, 145g (5,000pages)	17669
	Absolute Black® toner for use in Xerox Phaser 3320, WorkCentre 3315, 3325, 22 lb (10 kg) bag	17659
	Absolute Black® toner for use in Xerox Phaser 3320, WorkCentre 3315, 3325, 285g (11,000pages)	17658
	Clear Seal for use in Xerox Phaser 3320, WC 3315, 3325 50 pack	17897
	Developer roller for use in Xerox Phaser 3320, WorkCentre 3315, 3325, 10 pack	17660
	Doctor blade for use in Xerox Phaser 3320, WorkCentre 3315, 3325, 10 pack	17661
	PCR roller for use in Xerox Phaser 3320, WorkCentre 3315, 3325, 10 pack	17662
	Shipping lock for use in Xerox Phaser 3320, WorkCentre 3315, 3325, 10 pack	17750
	Smartchip™ for use in Xerox Phaser 3320 (106R02307)(11,000pages)	17657
	SuMMit® drum with gears for use in Xerox Phaser 3320, WorkCentre 3315, 3325	17663
	Unidrum™ with gears for use in Xerox Phaser 3320, WorkCentre 3315, 3325	17664
	X-Generation® Wiper blade for use in Xerox Phaser 3320, WorkCentre 3315, 3325, 10 pack	17665
	XEROX PHASER 6000, 6010, WORKCENTRE 6015, DP CP 105, 205, CM 205, Dell 1250, 1355 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Magenta® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP 105, 205, CM 205, Dell 1250, 1355, 30g (1,400 pages)	16808
	Absolute Magenta® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP 105, 205, CM 205, Dell 1250, 1355, 1kg	17802
	Absolute Yellow® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP 105, 205, CM 205, Dell 1250, 1355, 30g (1,400 pages)	16809
	Absolute Yellow® toner for use in Xerox Phaser 6000, 6010, WC 6015, DP CP 105, 205, CM 205, Dell 1250, 1355, 1kg	17803
	Smartchip™ Black for use in Xerox Phaser 6000, 6010, WC 6015 (106R01630) (2,000 pages)(US and W. EU)	16607
	Smartchip™ Black for use in Xerox Phaser 6000, 6010, WC 6015 (106R01634) (2,000 pages)	17355
	Smartchip™ Cyan for use in Xerox Phaser 6000, 6010, WC 6015 (106R01627) (1,000 pages)(US and W. EU)	16608
	Smartchip™ Cyan for use in Xerox Phaser 6000, 6010, WC 6015 (106R01631) (1,000 pages)	17356
	Smartchip™ Magenta for use in Xerox Phaser 6000, 6010, WC 6015 (106R01628) (1,000 pages)(US and W. EU)	16609
	Smartchip™ Magenta for use in Xerox Phaser 6000, 6010, WC 6015 (106R01632) (1,000 pages)	17357
	Smartchip™ Yellow for use in Xerox Phaser 6000, 6010, WC 6015 (106R01629) (1,000 pages)(US and W. EU)	16610
	Smartchip™ Yellow for use in Xerox Phaser 6000, 6010, WC 6015 (106R01633) (1,000 pages)	17358
	XEROX PHASER 3040, 3010, WORKCENTRE 3045 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045, 22lb (10kg) bag	17771
	Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045, 45g (2,200 pages)	17492
	Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045, 1kg	18246
	Absolute Black® toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045, 30g (1,000 pages)	17489
	Smartchip™ toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045 (106R02182) (2,200 pages) (US, Latin America)	17696
	Smartchip™ toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045 (106R02183) (2,200 pages)	17491
	Smartchip™ toner for use in Xerox Phaser 3040, 3010, WorkCentre 3045 (106R02180) (1,000 pages)	17490
	XEROX WORKCENTRE 5638, 5832 (also works with Document Centre 535/545/555; CopyCentre C35/C45/C55; WorkCentre M35, M45, M55; WorkCentre Pro 35/45/55; CopyCentre/WorkCentre/WorkCentre Pro 232, 238, 245; WorkCentre 5030)	
	Absolute Black® carrier for use in Xerox WorkCentre 5638, 5632, 22 lb (10 kg) bag	18977
	Absolute Black® toner for use in Xerox WorkCentre 5638, 5632, 1,200g (32,000 pages)	18975
	Absolute Black® toner for use in Xerox WorkCentre 5638, 5632, 22 lb (10 kg) bag	18976
	XEROX WORKCENTRE 5020, 5016 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Xerox Workcentre 5020, 5016, 260g	16965
	Doctor blade for use in Xerox WorkCentre 5020, 5016, 10 pack	16968
	Mag roller sleeve for use in Xerox WorkCentre 5020, 5016, 10 pack	16969
	Smartchip™ drum unit for use in Xerox Workcentre 5020, 5016 (101R432)	16963
	Smartchip™ toner unit for use in Xerox Workcentre 5020, 5016 (106R01277)	16921
	SuMMit® drum with gears for use in Xerox Workcentre 5020, 5016, 5 pack	16966
	Wiper blade for use in Xerox WorkCentre 5020, 5016, 10 pack	16967
	XEROX WORKCENTRE 4118, FAXCENTRE 2218	
	Developer roller for use in Xerox WorkCentre 4118, FaxCentre 2218, 5 pack	15748
	Doctor blade for use in Xerox WorkCentre 4118, FaxCentre 2218, 10 pack	10873
	Smartchip™ drum unit fuse for use in Xerox WorkCentre 4118, FaxCentre 2218, 10 pack	11589
	Smartchip™ for use in Xerox WorkCentre 4118, FaxCentre 2218, (8,000 pages) 10 pack	16128
	Smartchip™ for use in Xerox WorkCentre 4118, FaxCentre 2218, (8,000 pages)	10667
	SuMMIT® Drum with gears for use in Xerox WorkCentre 4118, FaxCentre 2218	15198
	X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218, 22 lb (10 kg) bag	9509
	X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218, 245g	5341
	X-Generation® Wiper blade for use in Xerox WorkCentre 4118, FaxCentre 2218	18045
	XEROX WORKCENTRE 5222, 5225, 5230 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Xerox WorkCentre 5222, 5225, 5230, 650g (30,000 pages)	15890
	Absolute Black® toner for use in Xerox WorkCentre 5222, 5225, 5230, 22 lb (10 kg) bag	15889
	Unidrum™ with gears for use in Xerox WorkCentre 5222, 5225, 5230	15894
	Wiper blade for use in Xerox WorkCentre 5222, 5225, 5230, 10 pack	15896
	Developer for drum unit for use in Xerox WorkCentre 5222, 5225, 5230 (80,000 pages)	15891
	Doctor blade for use in Xerox WorkCentre 5222, 5225, 5230, 10 pack	14108
	Seal for developer unit for use in Xerox WorkCentre 5222, 5225, 5230, 50 pack	15893
	Smartchip™ drum for use in Xerox WorkCentre 5222, 5225, 5230 (101R00435)(80,000 pages)	15898
	Smartchip™ drum unit for use in Xerox WorkCentre 5222, 5225, 5230 (101R00434)(50,000 pages)	14109
	Smartchip™ toner for use in Xerox WorkCentre 5222, 5225, 5230 (106R01413)(20,000 pages) (South America)	15897
	Smartchip™ toner for use in Xerox WorkCentre 5222, 5225, 5230 (106R1306) (30,000 pages) (US)	16531
	SuMMit® drum with gears for use in Xerox WorkCentre 5222, 5225, 5230	17013
	Unidrum™ OPC with gears for use in Xerox WorkCentre 5222, 5225, 5230	14107
	XEROX WORKCENTRE 4150	
	Absolute Black® developer carrier for drum unit for use in Xerox WorkCentre 4150, 338g	11643
	Absolute Black® toner for use in Xerox WorkCentre 4150, 22 lb (10 kg) bag	11555
	Absolute Black® toner for use in Xerox WorkCentre 4150, 560g	11554
	Developer roller for use in Xerox WorkCentre 4150, 10 pack	11560

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Doctor blade for use in Xerox WorkCentre 4150, 10 pack	11557
	PCR roller for use in Xerox WorkCentre 4150, 10 pack	11561
	Smartchip™ drum unit for use in Xerox WorkCentre 4150 (013R00623) (US, EU, Australia, NZ)	11644
	Smartchip™ toner cartridge for use in Xerox WorkCentre 4150 (6R01275) (US, EU, Australia, NZ)	11556
	Smartchip™ toner cartridge for use in Xerox WorkCentre 4150 (6R01276)(Latin America, Asia, India, Africa)	14452
	Wiper blade for use in Xerox WorkCentre 4150, 10 pack	11559
	XEROX WORKCENTRE 4260, 4250 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner developer for use in Xerox Workcentre 4260, 4250, 330g (80,000 pages)	17572
	Absolute Black® toner for use in Xerox Workcentre 4260, 4250, 725g (25,000 pages)	17538
	Smartchip™ drum unit for use in Xerox WorkCentre 4250, 4260 (113R00755) (US)	17642
	Smartchip™ with connector for use in Xerox Workcentre 4250, 4260 (106R01409)(25,000 pages)	15605
	TEXT grade toner for use in Xerox Workcentre 4260, 4250, 690g (25,000 pages)	16073
	Unidrum™ OPC with gears for use in Xerox WorkCentre 4250, 4260 (80,000 pages)	17833
	XEROX WORKCENTRE 7120, 7125 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Absolute Black® toner for use in Xerox Workcentre 7120, 7125 (22,000 pages)	17539
	Absolute Cyan® toner for use in Xerox Workcentre 7120, 7125 (15,000 pages)	17540
	Absolute Magenta® toner for use in Xerox Workcentre 7120, 7125 (15,000 pages)	17541
	Absolute Yellow® toner for use in Xerox Workcentre 7120, 7125 (15,000 pages)	17542
	Smartchip™ Black drum unit for use in Xerox Workcentre 7120, 7125 (013R00657) (67,000 pages)	18188
	Smartchip™ Black toner for use in Xerox Workcentre 7120, 7125 (006R01457) (22,000 pages) (US and EUR)	17543
	Smartchip™ Black toner for use in Xerox Workcentre 7120, 7125 (006R01461) (22,000 pages) (South America)	18184
	Smartchip™ Cyan drum unit for use in Xerox Workcentre 7120, 7125 (013R00660) (51,000 pages)	18189
	Smartchip™ Cyan toner for use in Xerox Workcentre 7120, 7125 (006R01460) (15,000 pages) (US and EUR)	17544
	Smartchip™ Cyan toner for use in Xerox Workcentre 7120, 7125 (006R01464) (15,000 pages) (South America)	18185
	Smartchip™ Magenta drum unit for use in Xerox Workcentre 7120, 7125 (013R00659) (51,000 pages)	18190
	Smartchip™ Magenta toner for use in Xerox Workcentre 7120, 7125 (006R01459) (15,000 pages) (US and EUR)	17545
	Smartchip™ Magenta toner for use in Xerox Workcentre 7120, 7125 (006R01463) (15,000 pages) (South America)	18186
	Smartchip™ Yellow drum unit for use in Xerox Workcentre 7120, 7125 (013R00658) (51,000 pages)	18191
	Smartchip™ Yellow toner for use in Xerox Workcentre 7120, 7125 (006R01458) (15,000 pages) (US and EUR)	17546
	Smartchip™ Yellow toner for use in Xerox Workcentre 7120, 7125 (006R01462) (15,000 pages) (South America)	18187
	XEROX WORKCENTRE 7525, 7530, 7535, 7545, 7556 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Smartchip™ Black toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 (006R01513) (26,000 pages) (USA)	17060
	Smartchip™ Black toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 (006R01517) (26,000 pages) (S. America, Mexico, ME)	17056
	Smartchip™ CMYK drum unit for use in Xerox WC 7525, 7530, 7535, 7540, 7545, 7556 (013RR00662) (125,000 pages)	17558
	Smartchip™ Cyan toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 (006R01516)(15,000 pages)(USA)	17061
	Smartchip™ Cyan toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 (006R01520)(15,000 pages)(S. America, Mexico, ME)	17057
	Smartchip™ Magenta toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 (006R01515)(15,000 pages)(USA)	17062
	Smartchip™ Magenta toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 (006R01519)(15,000 pages)(S. America, Mexico, ME)	17058
	Smartchip™ Yellow toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 (006R01514)(15,000 pages)(USA)	17063
	Smartchip™ Yellow toner for use in Xerox WorkCentre 7525, 7530, 7535, 7545, 7556 (006R01518)(15,000 pages)(S. America, Mexico, ME)	17059
	XEROX WORKCENTRE 7425, 7428, 7435 (THIS IS ALSO AN EASY TO REMANUFACTURE CARTRIDGE)	
	Smartchip™ Black toner for use in Xerox WorkCentre 7425, 7428, 7435 (006R01395)(26,000 pages)(USA & EU)	17048
	Smartchip™ Black toner for use in Xerox WorkCentre 7425, 7428, 7435 (006R01399)(26,000 pages)(S. America, Mexico, ME)	17052
	Smartchip™ CMYK drum unit for use in Xerox WorkCentre 7435, 7428, 7425 (113R00647) (61,000 pages)	17613
	Smartchip™ Cyan toner for use in Xerox WorkCentre 7425, 7428, 7435 (006R01398)(15,000 pages)(USA & EU)	17049
	Smartchip™ Cyan toner for use in Xerox WorkCentre 7425, 7428, 7435 (006R01400)(15,000 pages)(S. America, Mexico, ME)	17053
	Smartchip™ Magenta toner for use in Xerox WorkCentre 7425, 7428, 7435 (006R01397)(15,000 pages)(USA & EU)	17050
	Smartchip™ Magenta toner for use in Xerox WorkCentre 7425, 7428, 7435 (006R01401)(15,000 pages)(S. America, Mexico, ME)	17054
	Smartchip™ Yellow toner for use in Xerox WorkCentre 7425, 7428, 7435 (006R01396)(15,000 pages)(USA & EU)	17051
	Smartchip™ Yellow toner for use in Xerox WorkCentre 7425, 7428, 7435 (006R01402)(15,000 pages)(S. America, Mexico, ME)	17055
	SuMMIT® drum with gears and insert for use in Xerox Work Centre 7425, 7428, 7435	17646
	X-Generation® Black toner for use in Xerox Work Centre 7425, 7428, 7435 (26,000 pages)	17131
	X-Generation® Cyan toner for use in Xerox Work Centre 7425, 7428, 7435 (15,000 pages)	17132
	X-Generation® drum with gears and insert for use in Xerox Work Centre 7425, 7428, 7435	17601
	X-Generation® Magenta toner for use in Xerox Work Centre 7425, 7428, 7435 (15,000 pages)	17133
	X-Generation® Yellow toner for use in Xerox Work Centre 7425, 7428, 7435 (15,000 pages)	17134
	XEROX WORKCENTRE PRO C 7346, 7345, 7336, 7328, 3545, 2636, 2128	
	Absolute Black® toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128, 590g	10956
	Absolute Yellow™ toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128, 380g	10959
	X-Generation® Black toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128 (26,000 pages)	17127
	X-Generation® Cyan toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128 (16,000 pages)	17128
	X-Generation® Magenta toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128 (16,000 pages)	17129
	X-Generation® Yellow toner for use in Xerox Work Centre Pro C 7346, 7345, 7336, 7328, 3545, 2636, 2128 (16,000 pages)	17130
	XEROX WORKCENTRE PRO C 32, 40	
	Absolute Black® toner for use in Xerox WorkCentre Pro C 32, 40, 200g	9813
	Absolute Cyan™ toner for use in Xerox WorkCentre Pro C 32, 40, 200g	9814
	Absolute Magenta™ toner for use in Xerox WorkCentre Pro C 32, 40, 200g	9815
	Absolute Yellow™ toner for use in Xerox WorkCentre Pro C 32, 40, 200g	9816
	Smartchip with connector for use in Xerox WorkCentre Pro C 32, 40	13944
	Unidrum™ gearless for use in Xerox WorkCentre Pro C 32, 40	11886
	XEROX WORKCENTRE PRO C 320, 315	
	Doctor blade for use in Xerox WorkCentre Pro 320, 315, 10 pack	9257
	GEAR set for drum for use in Xerox WC Pro 320, 315 (560 per box)	5851
	Mag roller sleeve for use in Xerox WorkCentre Pro 320, 315, 10 pack	8527
	Unidrum™ Blue gearless for use in Xerox WorkCentre Pro 320, 315, 420, 415	10930
	X-Generation® Wiper blade for use in Xerox WorkCentre Pro 320, 315, 5 pack	17997

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	Wiper blade for use in Xerox WorkCentre Pro 320, 315, 10 pack	8526
	SuMMIT® drum w/gears for use in Xerox WorkCentre Pro 420, 415, 320, 315, 5 pack	12361
	Absolute Black® toner for use in Xerox WorkCentre Pro 320, 315, 22 lb (10 kg) bag	9260
	Absolute Black® toner for use in Xerox WorkCentre Pro 320, 315, 500g	8329
	XEROX WORKCENTRE PRO C 420, 415	
	Doctor blade for use in Xerox WorkCentre Pro 420, 415, 10 pack	9256
	Mag roller sleeve for use in Xerox WorkCentre Pro 420, 415, 10 pack	8914
	Smartchip™ for use in Xerox WorkCentre Pro 420, 415 (101R70024)	9872
	Wiper blade for use in Xerox WorkCentre Pro 420, 415, 10 pack	8911
	SuMMIT® drum w/gears for use in Xerox WorkCentre Pro 420, 415, 320, 315, 5 pack	12361
	Unidrum™ Blue gearless for use in Xerox WorkCentre Pro 320, 315, 420, 415	10930
	Absolute Black® toner for use in Xerox WorkCentre Pro 420, 415, 22 lb (10 kg) bag	8902
	Absolute Black® toner for use in Xerox WorkCentre Pro 420, 415, 500g	8901
	XEROX DOCUPRINT C 3210, 2100	
	Absolute Black® toner developer for use in Xerox DocuPrint C 3210, 2100, 70g	13559
	Absolute Black® toner for use in Xerox DocuPrint C 3210, 2100, 22lb(10kg)	14861
	Absolute Cyan™ toner for use in Xerox DocuPrint C 3210, 2100,(6,000 pages)	11202
	Absolute Magenta® toner for use in Xerox DocuPrint C 3210, 2100, 22lb(10kg)	14863
	Absolute Magenta™ toner (6,000 pages) for use in Xerox DocuPrint C 3210, 2100,	11203
	Absolute Magenta™ toner developer for use in Xerox DocuPrint C 3210, 2100, 70g	13564
	Absolute Yellow® toner for use in Xerox DocuPrint C 3210, 2100, 22lb(10kg)	14864
	Absolute Yellow™ toner developer for use in Xerox DocuPrint C 3210, 2100, 70g	13584
	Absolute Yellow™ toner for use in Xerox DocuPrint C 3210, 2100, (6,000 pages)	11204
	Black, Cyan, Magenta, Yellow carrier® 110 lb (50 kg) barrel for use in Xerox DocuPrint C 3210, 2100	14865
	Drum cover for use in Xerox DocuPrint C 3210, 2100, 10 pack	11242
	Toner fill hole plastic seal for use in Xerox DocuPrint C 3210, 2100, 100 pack	8300
	Unidrum™ with gears for use in Xerox DocuPrint C 3210, 2100	11206
	Wiper blade for use in Xerox DocuPrint C 3210, 2100, 10 pack	11207
	XEROX DOCUPRINT C 3290 SF	
	Absolute Black® toner developer for use in Xerox Docuprint C 3290 SF, 72g	13965
	Absolute Black® toner for use in Xerox Docuprint C 3290 SF, (8,000 pages)	13955
	Absolute Cyan™ toner developer for use in Xerox Docuprint C 3290 SF, 72g	13966
	Absolute Cyan™ toner for use in Xerox Docuprint C 3290 SF, (6,000 pages)	13956
	Absolute Magenta™ toner developer for use in Xerox Docuprint C 3290 SF, 72g	13967
	Absolute Magenta™ toner for use in Xerox Docuprint C 3290 SF, (6,000 pages)	13957
	Absolute Yellow™ toner for use in Xerox Docuprint C 3290 SF, (6,000 pages)	13958
	Absolute Yellow™ toner for use in Xerox Docuprint C 3290 SF, developer 72g	13968
	Drum cover for use in Xerox Docuprint C 3290 SF, 10 pack	13969
	Unidrum™ with gears for use in Xerox Docuprint C 3290 SF	16498
	XEROX DOCUPRINT 220, 230, 240, 332, 340, 425, 440	
	Absolute Black® toner for use in Xerox DC 220, 230, 240, 332, 340, 425, 440, 1025g	5271
	Absolute Black® toner for use in Xerox DC 220, 230, 240, 332, 340, 425, 440, 22 lb (10 kg) bag	8508
	Doctor blade for use in Xerox DC 220, 230, 240, 332, 340, 425, 440, 10 pack	7011
	OPC Drum with gears for use in Xerox DC 220, 230	5639
	PCR roller for use in Xerox DC 220, 230, 240, 332, 340, 425, 440, 10 pack	5909
	Smartchip™ w/housing for use in Xerox DC 220, 230, 420, (OEM 113R00275), 10 pack	9103
	Smartchip™ w/housing for use in Xerox DC 220, 230, 420, (OEM 113R00483), 10 pack	9104
	Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00276, 10 pack	8768
	Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00313, 10 pack (Canada)	5782
	Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00318, 10 pack	8769
	Smartchip™ w/housing for use in Xerox DC 220, 230, 420, 113R00484, 10 pack (Latin America)	5773
	Smartchip™ with housing for use in Xerox DC 220, 230, 420, (OEM 113R00278), 10 pack	8171
	Xerox DC 220, 230, 420, Smartchip™ w/housing, 10 pack (OEM 113R00314) (Latin America)	8170
	XEROX DOCUPRINT 2050	
	Absolute Black® toner for use in Xerox DocuPrint 2050, 320g (10,000 pages)	11290
	Unidrum™ with gears for use in Xerox DocuPrint 2050	11291
	XEROX WORKCENTRE 4118, FAXCENTRE 2218	
	Doctor blade for use in Xerox WorkCentre 4118, FaxCentre 2218, 10 pack	10873
	Smartchip™ for use in Xerox WorkCentre 4118, FaxCentre 2218 (8,000 pages) 10 pack	16128
	Smartchip™ for use in Xerox WorkCentre 4118, FaxCentre 2218 (8,000 pages)	10667
	SuMMIT® Drum with gears for use in Xerox WorkCentre 4118, FaxCentre 2218	15198
	X-Generation® Wiper blade for use in Xerox WorkCentre 4118, FaxCentre 2218	18045
	Developer roller for use in Xerox WorkCentre 4118, FaxCentre 2218, 5 pack	15748
	X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218, 22 lb (10 kg) bag	9509
	X-Generation® toner for use in Xerox WorkCentre M 20, C 20, 4118, FaxCentre 2218, 245g	5341
	X-Generation® Wiper blade for use in Xerox WorkCentre 4118, FaxCentre 2218	18045
	XEROX FAXCENTRE F 116, 1012	
	Absolute Black® toner for use in Xerox FaxCentre F 116, 1012, 90g	16128
	SuMMIT® drum with gears for use in Xerox FaxCentre F 116, 1020	16600
	XEROX DOCUCENTRE 450, 400, 320	
	Upper heat roller for use in Xerox Docucentre 450, 400, 320	16244
	XEROX DOCUCENTRE 6550, 5540	
	Upper heat roller for use in Xerox Docucentre 6550, 5540	16242

COPIER/MFP/MPS PRODUCTS

New	Engine Model	UniNet Part #
	XEROX DOCUCOLOR C 3535, 2240, 1632	
	Absolute Black® toner for use in Xerox DocuColor C 3535, 2240, 1632, 200g	9709
	Absolute Cyan™ toner for use in Xerox DocuColor C 3535, 2240, 1632, 200g	9710
	Absolute Magenta™ toner for use in Xerox DocuColor C 3535, 2240, 1632, 200g	9711
	Absolute Yellow™ toner for use in Xerox DocuColor C 3535, 2240, 1632, 200g	9712
	Unidrum™ gearless for use in Xerox DocuColor C 3535, 2240, 1632	11884
	XEROX DOCUCOLOR 12, 1256, 50	
	Absolute Black® toner for use in Xerox Docucolor 12, 1256, 50, 22 lb bag	8333
	Absolute Magenta™ toner for use in Xerox Docucolor 12, 1256, 50, 22 lb bag	9090
	Absolute Yellow™ toner for use in Xerox Docucolor 12, 1256, 50, 22 lb bag	9091
	Absolute Yellow™ toner for use in Xerox Docucolor 12, 1256, 50, 380g (11,000 pages)	10651
	Universal toner carrier for use in Xerox Docucolor 12, 1256, 50, 22 lb (10 kg) bag	9088
	Universal toner carrier K/C/M/Y carrier for use in Xerox Docucolor 12, 1256, 50, 120g (11,000 pages)	10652
	XEROX DOCUCOLOR 2045, 2060, 5252, 6060	
	Absolute Black® toner for use in Xerox Docucolor 2045, 2060, 5252, 6060, 1620g	8337
	Absolute Cyan™ toner for use in Xerox Docucolor 2045, 2060, 5252, 6060, 1620g	8338
	Absolute Magenta™ toner for use in Xerox Docucolor 2045, 2060, 5252, 6060, 1620g	8339
	Absolute Yellow™ toner for use in Xerox Docucolor 2045, 2060, 5252, 6060, 1620g	8340
	Universal toner carrier K/C/M/Y for use in Xerox Docucolor 2045, 2060, 5252, 6060, 320g	8299
	XEROX DOCUCOLOR 4 LP	
	Absolute Black® toner for use in Xerox Docucolor 4 LP, 200g	8043
	Absolute Cyan™ toner for use in Xerox Docucolor 4 LP, 200g	8044
	Absolute Magenta™ toner for use in Xerox Docucolor 4 LP, 200g	8046
	Absolute Yellow™ toner for use in Xerox Docucolor 4 LP, 200g	8045
	Universal toner carrier for use in Xerox Docucolor 4 LP, 60g	9057
	XEROX 5318, 5320	
	Absolute Black® toner for use in Xerox 5318, 5320, 460g, 2 pack	782
	Smartchip™ reset fuse for use in Xerox 5318, 5320, 5322, 10 pack	5892
	XEROX 5614, 5114, 5113	
	Absolute Black® toner for use in Xerox 5614, 5114, 5113, 240g	7472
	Smartchip™ for use in Xerox 5614, 5114, 5113 (18,000 page yield)	7725
	Smartchip™ for use in Xerox 5614, 5114, 5113 (36,000 page yield)	7726
	XEROX XC 5210, 5220, 5222	
	Absolute Black® developer for use in Xerox XC 5210, 5220, 5222, 140g (6R333)	5335
	Absolute Black® toner for use in Xerox XC 5210, 5220, 5222, 80g (6R333)	5337

REPLACEMENT TONER CARTRIDGES

New	Product Description	OEM #	UniNet Part #
	CANON® Replacement black toner cartridge for use in Canon NP 1010, 1020	F41-6601-000	101
	Replacement black toner cartridge for use in Canon NP 6080, 6150, 6080, 6550, 6650, 7000, 7050, 8070, 8530, 8570	F41-9502-740	107
	Replacement black toner cartridge for use in Canon IR 1600, 2000, 2010	GPR8	213
	Replacement black toner cartridge for use in Canon NP 1215, 2020, 2120	NPG1	457
	Replacement toner cartridge for use in Canon NP 4050, 4080, 4145, C 400	NPG 4/1375A004AA	5274
	Replacement toner cartridge for use in Canon NP 3030, 3050, C 300	NPG 5	5275
	Replacement black toner cartridge for use in Canon IR 1210, 1230, 1270, 1300, 1310, 1330, 1370, 1510, 1530, 1570 1630, 1670	GPR 10	5613
	Replacement black toner cartridge for use in Canon NP 6030, 6025, 6330	NPG 7 /1377A002AA	5824
	Replacement toner cartridge for use in Canon NP 6012, 6118, 6412, 7120, 7130, C 120, 130	NPG 11	6354
	Replacement black toner cartridge for use in Canon NP 6050	NPG 10	6973
	Replacement black toner cartridge for use in Canon IR 2200, 2220, 2800, 3300, 3320	GPR-6 /6647A003A/AA	7068
	Replacement black toner cartridge for use in Canon GP 40	F42-3201-700	7179
	Replacement black toner cartridge for use in Canon NP 4335, 4835	F41-6001-100	7231
	Replacement black toner cartridge for use in Canon IR 550, 600	F42-1401-200D	7497
	Replacement black toner cartridge for use in Canon IR 200, 330, 400	F42-3201-700	7498
	Replacement black toner cartridge for use in Canon GP 30, 55	F41-8601-000	7502
	Replacement black toner cartridge for use in Canon NP 6045, 6545, 6551, 6560	NPG 14 / F41-1923-740	7548
	Replacement black toner cartridge for use in Canon IR 6000, 6020, 5000, 5020, 4600	NPG-16/ GPR 4/F42-1401-200D	7549
	Replacement black toner cartridge for use in Canon NP 6085, 6285	NPG 12/ F41-7901-000	7550
	Replacement black toner cartridge for use in Canon NP 6035	NPG-13	7551
	Replacement toner cartridge for use in Canon Laser Class 710, A10	7621A001AA9216	
	Replacement Black toner cartridge for use in Canon IR C 3100, 3170	GPR-13K	11106
	Replacement Cyan toner cartridge for use in Canon IR C 3100, 3170	GPR-13C	11107
	Replacement Magenta toner cartridge for use in Canon IR C 3100, 3170	GPR-13M	11108
	Replacement Yellow toner cartridge for use in Canon IR C 3100, 3170	GPR-13Y	11109
	Replacement black toner cartridge for use in Canon GP 200,200F, 210, 210E, 210G	F42-1401-700	12289
	Replacement Black toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550, GPR 23	0452B003AA	12749
	Replacement Cyan toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550	0453B003AA	12750
	Replacement Magenta toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550	0454B004AA	12751
	Replacement Yellow toner cartridge for use in Canon IR C 3380, 3580,3480, 3080, 2880, 2550	0455B004AA	12752
	Replacement black toner cartridge for use in Canon™ Imagerunner 1018, 1019,1020, 1022, 1023, 1024, 1025	GPR22	12888
	Replacement black toner cartridge for use in Canon GP 200	F42-1401-700	12889
	Replacement black toner cartridge for use in Canon™ IR 2016, 2018, 2020, 2022, 2025, 2030	0384B003AA	12890
	Replacement black toner cartridge for use in Canon Imagerunner 2520, 2525, 2530	GPR35/2785B003AA	15088
	Replacement Black toner cartridge for use in Canon Imagerunner Advance C 7065, 7055	2792B003AA/GPR33	17290
	Replacement Cyan toner cartridge for use in Canon Imagerunner Advance C 7065, 7055	2796B003AA/GPR33	17291
	Replacement Magenta toner cartridge for use in Canon Imagerunner Advance C 7065, 7055	2800B003AA/GPR33	17292
	Replacement Yellow toner cartridge for use in Canon Imagerunner Advance C 7065, 7055	2804B003AA/GPR33	17293
	Replacement black toner cartridge for use in Canon Imagerunner 6055, 6065, 6075	GPR38	17329
	Replacement black toner cartridge for use in Canon Imagerunner 8085, 8105	GPR37	17590
	Replacement Black cartridge for use Canon Imagerunner Advance C 5045, 5054	2789B003AA	18627
	Replacement Cyan cartridge for use Canon Imagerunner Advance C 5045, 5054	2793B003AA	18628
	Replacement Magenta cartridge for use Canon Imagerunner Advance C 5045, 5054	2797B003AA	18629
	Replacement Yellow cartridge for use Canon Imagerunner Advance C 5045, 5054	2801B003AA	18630
	Replacement toner cartridge for use in Canon Imagerunner 1730, 1740, 1750	GPR-39/48	18705
	Replacement drum unit cartridge for use in Canon NP 1215	1316A001AA	9212
	FUJI XEROX®		
	Replacement toner cartridge, Black for use in Fuji Xerox Docuprint C 1190 FS	CT201260	14956
	Replacement toner cartridge, Cyan for use in Fuji Xerox Docuprint C 1190 FS	CT201261	14957
	Replacement toner cartridge, Magenta for use in Fuji Xerox Docuprint C 1190 FS	CT201262	14958
	Replacement toner cartridge, Yellow for use in Fuji Xerox Docuprint C 1190 FS	CT201263	14959
	KYOCERA®		
	Replacement black toner cartridge for use in Kyocera KM 4230, 5230, Ai 4040, 5050 (US)	37015011	4969
	Replacement black toner cartridge for use in Kyocera KM 4530, 5530, 6330, 7530	TK601	5075
	Replacement black toner cartridge for use in Kyocera KM Ai 2310, 3010	37016011	5079
	Replacement black toner cartridge for use in Kyocera KM 1505, 1510, 1810	37029011	5249
	Replacement black toner cartridge for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035 (US)	370AB011	5251
	Replacement black toner cartridge for use in Kyocera KM 1500 LA	TK 17 LA	5931
	Replacement black toner cartridge for use in Kyocera FS 1700	TK 20 H	5995
	Replacement black toner cartridge for use in Kyocera FS 1920	TK 57 H, 55 H	6809
	Replacement black toner cartridge for use in Kyocera FS 3820	TK 67, 65	6810
	Replacement black toner cartridge for use in Kyocera KM 1500, 1815	TK100	7047
	Replacement black toner cartridge for use in Kyocera FS 1700	TK 20 H	7612
	Replacement black toner cartridge for use in Kyocera FS 9100, 9500	TK 70 H	7764
	Replacement toner cartridge for use in Kyocera Mita DC 1560, 1860, 2360	37090011	7913
	Replacement black toner cartridge for use in Kyocera FS 1020, 1118	TK 18 H	8664
	Replacement black toner cartridge for use in Kyocera FS 1900	TK 50	9607
	Replacement black toner cartridge for use in Kyocera FS 3800	TK 60 H	9608
	Replacement black toner cartridge for use in Kyocera FS 720, 820, 1016	TK 112, 110	9630

REPLACEMENT TONER CARTRIDGES

New	Product Description	OEM #	UniNet Part #
	Replacement Black toner cartridge for use in Kyocera KM C 2230	0T5HNOUS	9795
	Replacement Cyan toner cartridge for use in Kyocera KM C 2230	0T5HNCUS	9796
	Replacement Magenta toner cartridge for use in Kyocera KM C 2230	0T5HNBUS	9797
	Replacement Yellow toner cartridge for use in Kyocera KM C 2230	0T5HNAUS	9798
	Replacement Black toner cartridge for use in Kyocera KM C 2030, 3130	TK 621(370-AJ011)	9799
	Replacement Cyan toner cartridge for use in Kyocera KM C 2030, 3130	TK 621(370-AJ511)	9800
	Replacement Magenta toner cartridge for use in Kyocera KM C 2030, 3130	TK 621(370-AJ411)	9801
	Replacement Yellow toner cartridge for use in Kyocera KM C 2030, 3130	TK 621(370-AJ311)	9802
	Replacement black toner cartridge for use in Kyocera FS 1000	TK 17 H	9817
	Replacement black toner cartridge for use in Kyocera KM 6230 (US)	TK 623 (37026011)	9980
	Replacement black toner cartridge for use in Kyocera KM Ai 6060, 5555	37013011	10009
	Replacement black toner cartridge for use in Kyocera KM 1620, 1650, 2020, 2050	TK 420, 421, 410, 411	10300
	Replacement black toner cartridge for use in Kyocera FS 1030	TK 122, 120	10420
	Replacement black toner cartridge for use in Kyocera FS 2000	TK 312, 310	11117
	Replacement black toner cartridge for use in Kyocera KM 2530, 3035, 3530, 4030, 4035, 5035 (EU)	370AB011, TK 2530	11319
	Replacement black toner cartridge for use in Kyocera FS 9530, 9130	TK 712	11372
	Replacement black toner cartridge for use in Kyocera KM 3050, 4050, 5050	TK 717, 719	11375
	Replacement black toner cartridge for use in Kyocera KM 8530	TK 631	11639
	Replacement black toner cartridge for use in Kyocera KM 3050, 4050, 5050, (EU)	TK 715	13093
	Replacement black toner cartridge for use in Kyocera KM 2540, 2560, 3040, 3060	TK 675, 679	13533
	Replacement black toner cartridge for use in Kyocera FS 1100	TK 137, 140, 142	14103
	Replacement black toner cartridge for use in Kyocera FS 1300, 1350	TK 132, 130	14366
	Replacement black toner cartridge for use in Kyocera FS 4020	TK 360, 362, 364	14802
	Replacement black toner cartridge for use in Kyocera FS 1320, 1370	TK 170,172,173,174	15967
	Replacement black toner cartridge for use in Kyocera Mita TASKalfa 180, 220, KM 1620	TK 437	16245
	Replacement black toner cartridge for use in Kyocera Mita TaskAlfa 420i, 520i	TK 725	16246
	Replacement black toner cartridge for use in Kyocera KM 1525, 1530, 1570, 2030, 2070	37028011	16748
	Replacement black toner cartridge for use in Kyocera Mita TASKalfa 255, 255 B, 305, FS 6025, 6030	TK 477	17029
	Replacement black toner cartridge for use in Kyocera FS 1035, 1135 MFP (US)	TK 1142	17535
	Replacement black toner cartridge for use in Kyocera FS 1035, 1135 MFP (EUR)	TK 1140	17582
	Replacement Black toner cartridge for use in Kyocera	TK 865	18275
	Replacement Cyan toner cartridge for use in Kyocera	TK 865	18276
	Replacement Magenta toner cartridge for use in Kyocera	TK 865	18277
	Replacement Yellow toner cartridge for use in Kyocera	TK 865	18278
	Replacement Black toner cartridge for use in Kyocera Taskalfa 350ci, 250ci	TK 867	18279
	Replacement Cyan toner cartridge for use in Kyocera Taskalfa 350ci, 250ci	TK 867	18280
	Replacement Magenta toner cartridge for use in Kyocera Taskalfa 350ci, 250ci	TK 867	18281
	Replacement Yellow toner cartridge for use in Kyocera Taskalfa 350ci, 250ci	TK 867	18282
	Replacement Black toner cartridge for use in Kyocera TASKalfa 3500, 4500, 5500 (EU)	TK6305	18313
	Replacement Black toner cartridge for use in Kyocera TASKalfa 3500, 4500, 5500 (US)	TK6307	18314
	Absolute Black® Replacement toner cartridge for use in Kyocera FS-1030MFP, 1130MFP		18479
	Absolute Black® Replacement toner cartridge for use in Kyocera FS-1035, 1135MFP	TK 1142	18480
	Absolute Black® Replacement toner cartridge for use in Kyocera FS-1035, 1135MFP	TK 1147	18481
	Absolute Black® Replacement toner cartridge for use in Kyocera FS-1035, 1135MFP	TK 1140	18482
	Replacement toner cartridge for use in Kyocera FS-1024, 1110, 1124	TK 1102	18706
	Replacement toner cartridge for use in Kyocera FS 6950	TK 442, 440,430	18707
KONICA MINOLTA®			
	Replacement black toner cartridge for use in Konica Minolta EP 470, 4230, 4232, 4233, 4250	8916-102	5315
	Replacement black toner cartridge for use in Konica Minolta EP 1030, 1031	8935-802	7684
	Replacement black toner cartridge for use in Konica Minolta EP 2120, 2130, 2150	8931-602	7905
	Replacement black toner cartridge for use in Konica Minolta EP 2080	8936-202	8158
	Replacement black toner cartridge for use in Konica Minolta EP 8015, 6001, 6000, 5050	MT601A, 602A	8162
	Replacement black toner cartridge for use in Konica Minolta Di 200, 250, 350	TN211	8969
	Replacement black toner cartridge for use in Konica Minolta Di 200, 250, 350	TN211	8969
	Replacement Black toner cartridge for use in Konica Minolta CF 2002, 3102	8937-905	9745
	Replacement Cyan toner cartridge for use in Konica Minolta CF 2002, 3102	8937-908	9746
	Replacement Magenta toner cartridge for use in Konica Minolta CF 2002, 3102	8937-907	9747
	Replacement Yellow toner cartridge for use in Konica Minolta CF 2002, 3102	8937-906	9748
	Replacement black toner cartridge for use in Konica Minolta Bizhub C 350, 450	4053-401	9749
	Replacement cyan toner cartridge for use in Konica Minolta Bizhub C 350, 450	4053-701	9750
	Replacement magenta toner cartridge for use in Konica Minolta Bizhub C 350, 450	4053-601	9751
	Replacement yellow toner cartridge for use in Konica Minolta Bizhub C 350, 450	4053-501	9752
	Replacement black toner cartridge for use in Konica Minolta Di 551, 650, 5510, 7210	604A,B	9974
	Replacement black toner cartridge for use in Konica Minolta Di 450, 470, 550	502A,B	9977
	Replacement black toner cartridge for use in Konica Minolta Di 450, 470, 550	502A,B	9977
	Replacement black toner cartridge for use in Konica Minolta Di 520, 620 (US)	603A,B	9978
	Replacement black toner cartridge for use in Konica Minolta Di 1810, 2010, 2510, 3010, 3510 (US)	205 A,B/305 A,B	9979
	Replacement black toner cartridge for use in Konica Minolta Di 750	8971-111	10226
	Replacement black toner cartridge for use in Konica Minolta Di 850	8937-807	10230
	Replacement Black toner cartridge for use in Konica Minolta Bizhub C 300, 352	8938-701	11094
	Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 300, 352	8938-704	11095
	Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 300, 352	8938-703	11096
	Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 300, 352	8938-702	11097
	Replacement black toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252	TN 210	11098
	Replacement cyan toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252	8938-508	11099
	Replacement magenta toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252	8938-507	11100
	Replacement yellow toner cartridge for use in Konica Minolta Bizhub C 250, 250P, 252	8938-506	11101
	Replacement Black toner cartridge for use in Konica Minolta Bizhub 350	8938-402	11613
	Replacement black toner cartridge for use in Konica Minolta Bizhub 200, 250	8938-415	11614
	Replacement Black toner cartridge for use in Konica Minolta Bizhub 350 (EU)	8938-402	11615
	Replacement black toner cartridge for use in Konica Minolta Bizhub 200, 250, 360	8938-413	11616

REPLACEMENT TONER CARTRIDGES

New	Product Description	OEM #	UniNet Part #
	Replacement black toner cartridge for use in Konica Minolta Bizhub 152,162,180,181 210 (EU)	8937-884	11617
	Replacement black toner cartridge for use in Konica Minolta Bizhub 152,162,180,181,210 (US)	8937-782	11618
	Replacement black toner cartridge for use in Konica Minolta Bizhub 360, 420, 421, 500, 501	8938-402	11619
	Replacement black toner cartridge for use in Konica Minolta Bizhub 600, 750	TN710	11620
	Replacement black toner cartridge for use in Konica Minolta Bizhub 920	TN910	11621
	Replacement black toner cartridge for use in Konica Minolta Di 520, 620 (EU)	8935-902	11636
	Replacement black toner cartridge for use in Konica Minolta EP 4000, 5000	8935-502, MT 501	11705
	Replacement Black toner cartridge for use in Konica Minolta Bizhub Pro C- 500	A0YM131, A0YM130, TN-510K, TN510K, 020V	11741
	Replacement Cyan toner cartridge for use in Konica Minolta Bizhub Pro C- 500	A0YM431, A0YM430, TN-510C, TN510C, 020Y	11742
	Replacement Magenta toner cartridge for use in Konica Minolta Bizhub Pro C- 500	A0YM331, A0YM330, TN-510M, TN510M, 020X	11743
	Replacement Yellow toner cartridge for use in Konica Minolta Bizhub Pro C- 500	A0YM231, A0YM230, TN-510Y, TN510Y, 020W	11744
	Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430	15738
	Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM330	15739
	Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM230	15740
	Replacement Black toner cartridge for use in Konica Minolta Bizhub C 253, 353	A0D7132	16293
	Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 253, 353	A0D7432	16295
	Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 253, 353	A0D7332	16296
	Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 253, 353	A0D7232	16297
	Replacement black toner cartridge for use in Konica Minolta Bizhub 363, 423	TN414	17015
	Replacement black toner cartridge for use in Konica Minolta Bizhub C 451	TN411K	17119
	Replacement black toner cartridge for use in Konica Minolta Bizhub C 550, 650	TN611K	17120
	Replacement cyan toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650	TN611C	17121
	Replacement magenta toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650	TN611M	17122
	Replacement yellow toner cartridge for use in Konica Minolta Bizhub C 451, 550, 650	TN611Y	17123
	Replacement black toner cartridge for use in Konica Minolta Bizhub 36, 42 (US)	TN415	17591
	Replacement black toner cartridge for use in Konica Minolta Bizhub 36, 42 (EU)	TN415	17592
	Replacement Black toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690 (US)	AOV301F	17604
	Replacement Cyan toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690 (US)	AOV301HF	17605
	Replacement Magenta toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690 (US)	AOV301CF	17606
	Replacement Yellow toner cartridge for use in Konica Minolta Magicolor 1600, 1650, 1690 (US)	AOV306F	17607
	Replacement Black toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510	TN 610, 612 universal	17850
	Replacement Cyan toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510	TN 610, 612 universal	17851
	Replacement Magenta toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510	TN 610, 612 universal	17852
	Replacement Yellow toner cartridge for use in Konica Minolta Bizhub Pro C-5500, 5501, 6500, 6510	TN 610, 612 universal	17853
	Replacement toner cartridge for use in Konica Minolta Bizhub 164, 184, 215		18292
	Replacement black toner cartridge for use in Konica Minolta Bizhub 223, 283, 363, 423	TN 217 /TN414	18315
	Replacement Cyan toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430, A0TM131, TN-613	18340
	Replacement Magenta toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430, A0TM131, TN-613	18341
	Replacement Yellow toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430, A0TM131, TN-613	18342
	Replacement Black toner cartridge for use in Konica Minolta Bizhub 363, 423	N414	18343
	Replacement Black toner cartridge for use in Minolta Bizhub C 220, 280, 360	TN216K	18308
	Replacement Cyan toner cartridge for use in Minolta Bizhub C 220, 280, 360	TN216C	18309
	Replacement Magenta toner cartridge for use in Minolta Bizhub C 220, 280, 360	TN216M	18310
	Replacement Yellow toner cartridge for use in Minolta Bizhub C 220, 280, 360	TN216Y	18311
	Replacement Black toner cartridge for use in Konica Minolta Bizhub C 452, 552, 652	A0TM430, A0TM131	18312
	LANIER®		
	Replacement black toner cartridge for use in Lanier 7335, 7345, Toshiba T 3560, 4560	117-0234	5980
	Replacement black toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C	885317	9563
	Replacement cyan toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C	885320	9564
	Replacement magenta toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C	885319	9565
	Replacement yellow toner cartridge for use in Lanier LD 024, 032, Ricoh Aficio 1224C, 1232 C	885318	9566
	Replacement black toner cartridge for use in Lanier 7355, 7365	1170227	16284
	NASHUATEC®		
	Replacement black toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850	885372BK	8138
	Replacement cyan toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850	888037	8139
	Replacement magenta toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850	888036	8140
	Replacement yellow toner cartridge for use in Nashuatec C 7435, 7428, Ricoh Aficio 3800, 3850	888035	8141
	OKIDATA®		
	Replacement black toner cartridge for use in Okidata Okipage 4W	52106201	477
	Replacement black toner cartridge for use in Okidata OL 400e	52107201	492
	Replacement black toner cartridge, compatible for use in Okidata Okipage 8W, 6W	52111701	7033
	Replacement Black Glossy toner cartridge for use in Okidata C 9000	41963604/41963600	10221
	Replacement Cyan Glossy toner cartridge for use in Okidata C 9000	41963603/41963607	10222
	Replacement Magenta glossy toner cartridge for use in Okidata C 9000	41963602/41963606	10223
	Replacement Yellow glossy toner cartridge for use in Okidata C 9000	41963601/41963605	10224
	Replacement Black Glossy toner cartridge for use in Okidata C 5100	42127404/42127408	10433
	Replacement Black glossy toner cartridge for use in Okidata C 7000, 7300, 7500	41304208	10844
	Replacement Cyan glossy toner cartridge for use in Okidata C 7000, 7300, 7500	41304207	10845

REPLACEMENT TONER CARTRIDGES

New	Product Description	OEM #	UniNet Part #
	Replacement Magenta glossy toner cartridge for use in Okidata C 7000, 7300, 7500	41304206	10846
	Replacement yellow glossy toner cartridge for use in Okidata C 7000, 7300, 7500	41304205	10847
	Replacement black toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP	43459304	12855
	Replacement cyan toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP	43459331	12856
	Replacement magenta toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP	43459330	12857
	Replacement yellow toner cartridge for use in Okidata C 3400, C 3530, 3600 MFP	43459329	12858
PANASONIC®			
	Replacement black toner cartridge for use in Panasonic KX P 4420	KX P 4420	527
	Replacement black toner cartridge for use in Panasonic DP 2310, 2330, 3010, 3030	DQ-TU15E	11679
	Replacement black toner cartridge for use in Panasonic DP 1520, 1820	DQ-TU10J-PU/PB	11680
	Replacement black toner cartridge for use in Panasonic DP 1510, 1810, 2010	DQ-TU10C	11681
	Replacement black toner cartridge for use in Panasonic DP 6530, 7240, 8130, 8540, 8570	T6510, T6510E	11685
	Replacement black toner cartridge for use in Panasonic FP 7781, 7760	FQ-TE70	11838
	Replacement black toner cartridge for use in Panasonic FP7728, 7735, 7742, 7750, 7830, 7835, 7845, 7850	FQTK20	13321
 Ricoh®			
	Replacement black toner cartridge for use in Ricoh Aficio 1015, 1018, 1113 (Type 1220)	888086	5246
	Replacement black toner cartridge for use in Ricoh Aficio 1022, 2022, 2032, 3030	888169	5247
	Replacement black toner cartridge for use in Ricoh 4080, 4150	5397-30	5278
	Replacement black toner cartridge for use in Ricoh Aficio 1013, 1013F, Type 1150	885257	5894
	Replacement black toner cartridge for use in Ricoh Aficio 200, 250	889613	7552
	Replacement black toner cartridge for use in Ricoh Aficio 220, 270	885208	7553
	Replacement black toner cartridge for use in Ricoh Aficio 350, 450	887725	7554
	Replacement black toner cartridge for use in Ricoh Aficio 550, 650	887740	7555
	Replacement Black toner cartridge for use in Ricoh Aficio 3800, 3850	885372BK	8138
	Replacement Cyan toner cartridge for use in Ricoh Aficio 3800	888037	8139
	Replacement Magenta toner cartridge for use in Ricoh Aficio 3800	888036	8140
	Replacement Yellow toner cartridge for use in Ricoh Aficio 3800	888035	8141
	Replacement black toner cartridge for use in Ricoh Aficio 551, 700, Type 5105	887994	8827
	Replacement black toner cartridge for use in Ricoh Aficio 1035, 1045, 4510	885247, 888062	8828
	Replacement black toner cartridge for use in Ricoh Aficio 850, 1050	888008	8829
	Replacement black toner cartridge for use in Ricoh Aficio 1085, 1105, 2090, 2105, Type 8105	888156, 8885340	8830
	Replacement Black toner cartridge for use in Ricoh Aficio 1224 C, 1232 C	885317	9563
	Replacement Cyan toner cartridge for use in Ricoh Aficio 1224 C, 1232 C	885320	9564
	Replacement Magenta toner cartridge for use in Ricoh Aficio 1224 C, 1232 C	885319	9565
	Replacement Yellow toner cartridge for use in Ricoh Aficio 1224 C, 1232 C	885318	9566
	Replacement Black toner cartridge for use in Ricoh Aficio 2232 C, 2238 C	888231	9567
	Replacement Cyan toner cartridge for use in Ricoh Aficio 2232 C, 2238 C	888234	9568
	Replacement Magenta toner cartridge for use in Ricoh Aficio 2232 C, 2238 C	888233	9569
	Replacement Yellow toner cartridge for use in Ricoh Aficio 2232 C, 2238 C	888232	9570
	Replacement black toner cartridge for use in Ricoh Aficio 400, 401, 500	11D, 10D	11842
	Replacement black toner cartridge for use in Ricoh Aficio 2035, 2045	3110, 3210D	11843
	Replacement cyan toner cartridge for use in Ricoh Aficio MP C 3500, 4500	888607	12559
	Replacement black toner cartridge for use in Ricoh Aficio MP C 3500, 4500	888604	12757
	Replacement magenta toner cartridge for use in Ricoh Aficio MP C 3500, 4500	888606	12758
	Replacement yellow toner cartridge for use in Ricoh Aficio MP C 3500, 4500	888605	12759
	Replacement Black toner for use in Ricoh Aficio MP C 2000, 2500, 3000	888636	12760
	Replacement cyan toner cartridge for use in Ricoh Aficio MP C 2000, 2500, 3000	888639	12761
	Replacement magenta toner cartridge for use in Ricoh Aficio MP C 2000, 2500, 3000	888638	12762
	Replacement yellow toner cartridge for use in Ricoh Aficio MP C 2000, 2500, 3000	888637	12763
	Replacement Black toner for use in Ricoh Aficio MP 2500	MP2500, A, E	13381
	Replacement black toner cartridge for use in Ricoh Aficio MP 3500, 4000, 4001, 4500, 5000	884922, 8400040	15936
	Replacement Black toner cartridge for use in Ricoh Aficio CL 7200, 7300, Type 160	888442	16313
	Replacement Cyan toner cartridge for use in Ricoh Aficio CL 7200, 7300, Type 160	888445	16314
	Replacement Magenta toner cartridge for use in Ricoh Aficio CL 7200, 7300, Type 160	888444	16315
	Replacement Yellow toner cartridge for use in Ricoh Aficio CL 7200, 7300, Type 160	888443	16316
	Replacement Black toner for use in Ricoh Aficio MP 8000 SP	885400	17028
	Replacement Black toner for use in Ricoh Aficio MP 5500, 6500, 7500 (Type-6110D)	841332	17125
	Replacement Black toner cartridge for use in Ricoh Aficio MPC-2051, 2551	841500	17854
	Replacement Cyan toner cartridge for use in Ricoh Aficio MPC-2051, 2551	841501	17855
	Replacement Magenta toner cartridge for use in Ricoh Aficio MPC-2051, 2551	841502	17856
	Replacement Yellow toner cartridge for use in Ricoh Aficio MPC-2051, 2551	841503	17857
	Replacement Black toner cartridge for use in Ricoh Aficio MPC-4051, 5051	841452	17858
	Replacement Black toner cartridge for in Ricoh Aficio MPC 4501, 5501	841452	17858
	Replacement Cyan toner cartridge for use in Ricoh Aficio MPC-4051, 5051	841455	17859
	Replacement Cyan toner cartridge for in Ricoh Aficio MPC 4501, 5501	841455	17859
	Replacement Magenta toner cartridge for use in Ricoh Aficio MPC-4051, 5051	841454	17860
	Replacement magenta toner cartridge for in Ricoh Aficio MPC 4501, 5501	841454	17860
	Replacement Yellow toner cartridge for use in Ricoh Aficio MPC-4051, 5051	841453	17861
	Replacement Yellow toner cartridge for in Ricoh Aficio MPC 4501, 5501	841453	17861
	Replacement Black toner cartridge for use in Ricoh Aficio MPC-6000, 7000	841084, 841288	17862
	Replacement Cyan toner cartridge for use in Ricoh Aficio MPC-6000, 7000	841085, 841289	17863
	Replacement Magenta toner cartridge for use in Ricoh Aficio MPC-6000, 7000	841086, 841290	17864
	Replacement Yellow toner cartridge for use in Ricoh Aficio MPC-6000, 7000	841087, 841291	17865
	Replacement black toner cartridge for use in Ricoh FT 4118, 3813	885117	5245
	Replacement black toner cartridge for use in Ricoh FT 4022, 4622, Type 450	887718	5248
	Replacement black toner cartridge for use in Ricoh Type 310	889264	6456
	Replacement black toner cartridge for use in Ricoh FT 4215, 4415, 4418, 4421	887523	7860

REPLACEMENT TONER CARTRIDGES

New	Product Description	OEM #	UniNet Part #
	Replacement toner cartridge for use in Ricoh Imagio MF 200	889613	8147
	Replacement black toner cartridge for use in Ricoh Imagio MF 250		8149
	Replacement cyan toner cartridge for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000	636341	8273
	Replacement Black toner cartridge toner for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000	636338	8274
	Replacement Magenta toner cartridge for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000	636340	8275
	Replacement Yellow toner cartridge for use in Ricoh Ipsio CX 7100, 7500, 8100, 8200, 9000	636339	8276
	Replacement black toner cartridge for use in Ricoh Imagio P		8706
	Replacement Black toner cartridge toner for use in Ricoh CL 7000	885406	8837
	Replacement Cyan toner cartridge for use in Ricoh CL 7000	885409	8838
	Replacement Magenta toner cartridge for use in Ricoh CL 7000	885408	8839
	Replacement Yellow toner cartridge for use in Ricoh CL 7000	885407	8840
	Replacement Black toner cartridge for use in Ricoh CL 5000	885325	9659
	Replacement Cyan toner cartridge for use in Ricoh CL 5000	885328	9660
	Replacement Magenta toner cartridge for use in Ricoh CL 5000	885327	9661
	Replacement yellow toner cartridge for use in Ricoh CL 5000	885326	9662
	Replacement Black toner cartridge for use in Ricoh Ipsio CX 6000, 6100, 6600		9663
	Replacement Cyan toner cartridge for use in Ricoh Ipsio CX 6000, 6100, 6600		9664
	Replacement Magenta toner cartridge for use in Ricoh Ipsio CX 6000, 6100, 6600		9665
	Replacement Yellow toner cartridge for use in Ricoh Ipsio CX 6000, 6100, 6600		9666
	Replacement black toner cartridge for use in Ricoh Aficio 2015, 2018 (Type 1130D/1230D)	888215	12233
	Replacement black toner cartridge for use in Ricoh Aficio 1515 (Type 1170D, 1270D)	888260	12234
	Replacement black toner cartridge for use in Ricoh Aficio 1060, 1075, 2051, 2060	885400	12235
	Replacement Black toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR	MPC400E/A	17389
	Replacement Cyan toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR	MPC400E/A	17391
	Replacement Magenta toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR	MPC400E/A	17392
	Replacement Yellow toner cartridge for use in Ricoh MP C 300, 300SR, 400, 400 SR	MPC400E/A	17393
	Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MP C 2800, 3300, 3333	841276	18467
	Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 2800, 3300, 3333	841279	18468
	Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 2800, 3300, 3333	841278	18469
	Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MP C 2800, 3300, 3333	841277	18470
	Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MP C 2050, 2550	841280	18471
	Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 2050, 2550	841281	18472
	Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 2050, 2550	841282	18473
	Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MP C 2050, 2550	841283	18474
	Absolute Black® Replacement toner cartridge for use in Ricoh Aficio MP C 4000, 5000, 5050	841284	18475
	Absolute Cyan® Replacement toner cartridge for use in Ricoh Aficio MP C 4000, 5000, 5050	841287	18476
	Absolute Magenta® Replacement toner cartridge for use in Ricoh Aficio MP C 4000, 5000, 5050	841286	18477
	Absolute Yellow® Replacement toner cartridge for use in Ricoh Aficio MP C 4000, 5000, 5050	841285	18478
	Replacement cartridge for use in Ricoh Aficio MP 301 SP	841714	18560
	Replacement Black cartridge for use in Ricoh Aficio MP C 3002, 3502	841647	18561
	Replacement Cyan cartridge for use in Ricoh Aficio MP C 3002, 3502	841650	18562
	Replacement Magenta cartridge for use in Ricoh Aficio MP C 3002, 3502	841649	18563
	Replacement Yellow cartridge for use in Ricoh Aficio MP C 3002, 3502	841648	18564
	SAMSUNG®		
	Replacement Black toner cartridge for use in Samsung CLP 300, CLX 3160 FN	CLP-K300A	12677
	Replacement Cyan toner cartridge for use in Samsung CLP 300, CLX 3160 FN	CLP-C300A	12678
	Replacement Magenta toner cartridge for use in Samsung CLP 300, CLX 3160 FN	CLP-M300A	12679
	Replacement yellow compatible toner cartridge for use in Samsung CLP 300, CLX 3160 FN	CLP-Y300A	12680
	Replacement Cyan toner cartridge for use in Samsung CLP 500, 550		12832
	Replacement Magenta toner cartridge for use in Samsung CLP 500, 550		12833
	Replacement yellow compatible toner cartridge for use in Samsung CLP 500, 550		12834
	Replacement Cyan toner cartridge for use in Samsung CLP 510		12852
	Replacement Magenta toner cartridge for use in Samsung CLP 510		12853
	Replacement yellow compatible toner cartridge for use in Samsung CLP 510		12854
	Replacement Cyan toner cartridge for use in Samsung CLP 350	CLP-C350A	14455
	Replacement Magenta toner cartridge for use in Samsung CLP 350	CLP-M350A	14456
	Replacement Yellow toner cartridge for use in Samsung CLP 350	CLP-Y350A	14457
	SAVIN®		
	Replacement Black toner cartridge for use in Savin® 2235, 2238, 2245, 2535, 2545		13802
	Replacement Black toner cartridge for use in Savin® C 2408, 3210		9563
	Replacement cyan toner cartridge for use in Savin® C 2408, 3210		9564
	Replacement magenta toner cartridge for use in Savin® C 2408, 3210		9565
	Replacement yellow toner cartridge for use in Savin® C 2408, 3210		9566
	Replacement magenta toner cartridge for use in Savin® C 3224, 3828		9569
	Replacement yellow toner cartridge for use in Savin® C 3224, 3828		9570
	SHARP®		
	Replacement black toner cartridge for use in Sharp AR 330, 400 NT		5326
	Replacement black toner cartridge for use in Sharp SF 2022, 2027, 2035	222NT, 235NT	5977
	Replacement black toner cartridge for use in Sharp SF 2216, 2220	226NT	7662
	Replacement black toner cartridge for use in Sharp SF 2025, 2030, 2530, 2040, 2540	SF230, 240NT	8984
	Replacement black toner cartridge for use in Sharp AR 5120, 5015, 5220	AR016T, FT, ST	11601
	Replacement black toner cartridge for use in Sharp AR 650, 800, 850	AR650NT	11641
	Replacement black toner cartridge for use in Sharp™ SF 2050, 2052, 2060, 3062, 2260	AR360NT	12881
	Replacement black toner cartridge™ for use in Sharp AR-M 162, 163, 164, 201	AR 201	13320
	Replacement black toner cartridge for use in Sharp AR M 351, 355, 451, 455	AR455NT	14372
	Replacement Black toner cartridge for use in Sharp® MX 2300, 2700	MX27NTBA	14715
	Replacement Cyan toner cartridge for use in Sharp® MX 2300, 2700	MX-27NTCA	14716

REPLACEMENT TONER CARTRIDGES

New	Product Description	OEM #	UniNet Part #
	Replacement Magenta toner cartridge for use in Sharp® MX 2300, 2700	MX-27NTMA	14717
	Replacement Yellow toner cartridge for use in Sharp® MX 2300, 2700	MX-27NTYA	14718
	Replacement Black toner cartridge for use in Sharp® MX 2300, 2700	MX27GTBA	14719
	Replacement Cyan toner cartridge for use in Sharp® MX 2300, 2700	MX27GTCA	14720
	Replacement Magenta toner cartridge for use in Sharp® MX 2300, 2700	MX27GTMA	14721
	Replacement Yellow toner cartridge for use in Sharp® MX 2300, 2700	MX27GTMA	14722
	Replacement Black toner cartridge for use in Sharp® MX 3501, 4501	MX45NTBA	14723
	Replacement Cyan toner cartridge for use in Sharp® MX 3501, 4501	MX45NTCA	14724
	Replacement Magenta toner cartridge for use in Sharp® MX 3501, 4501	MX45NTMA	14725
	Replacement Yellow toner cartridge for use in Sharp® MX 3501, 4501	MX45NTYA	14726
	Replacement black toner cartridge for use in Sharp AL-2021, 2031, 2041, 2051	AL-204TD	16521
	Replacement black toner cartridge for use in Sharp AR M 208, 236, 237, 256,257, 276, 277, 316, 317	AR270NT/310NT/T	17359
	Replacement black toner cartridge for use in Sharp MX-M 283,363,453, 503	MX500GT/NT	17447
	Replacement black toner cartridge for use in Sharp MX M 260		17588
	Replacement black toner cartridge for use in Sharp MX-M 200 D	MX-206NT	17849
	Replacement Black toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501	MX45NTB	17866
	Replacement Cyan toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501	MX45NTB	17867
	Replacement Magenta toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501	MX45NTB	17868
	Replacement Yellow toner cartridge for use in Sharp MX-3500, 3501, 4500, 4501	MX45NTB	17869
	Replacement black toner cartridge for use in Sharp AR 5516, 5520	AR020T	18029
	Replacement Black toner cartridge for use in Sharp® AR M 550, 620, 700		15873
	Replacement Black toner cartridge for use in Sharp MX 2600, 2601N, 3100N		18807
	Replacement Cyan toner cartridge for use in Sharp MX 2600, 2601N, 3100N		18808
	Replacement Yellow toner cartridge for use in Sharp MX 2600, 2601N, 3100N		18809
	Replacement Magenta toner cartridge for use in Sharp MX 2600, 2601N, 3100N		18810
	Replacement drum unit cartridge for use in Sharp FO-2081	FO55DR	17836
TOSHIBA®			
	Replacement black toner cartridge for use in Toshiba T 1340, 1350, 1370		4907
	Replacement copier black toner cartridge for use in Toshiba T 1550,1560		5960
	Replacement black toner cartridge for use in Toshiba T 3560, 4560 Lanier 7335, 7345		5980
	Replacement black toner cartridge for use in Toshiba T 5560, 6560		5981
	Replacement black toner cartridge for use in Toshiba T 1650, 1710, 2050, 2500		7967
	Replacement black toner cartridge for use in Toshiba T 2060, 2860, 2870		7969
	Replacement black toner cartridge for use in Toshiba T 3550, 4550		7971
	Replacement black toner cartridges for use in Toshiba T 120		8048
	Replacement black toner cartridge for use in Toshiba E Studio 28, 35, 45, T 3500		8831
	Replacement black toner cartridge for use in Toshiba E Studio 16, 160, T 1600		8832
	Replacement black toner cartridge for use in Toshiba E Studio 20, 25, T 2500		8989
	Replacement black toner cartridge for use in Toshiba E Studio 55, 65, 80, T 6570		8990
	Replacement black toner cartridge for use in Toshiba e Studio 163, 165, 203, 205	T1640	11566
	Replacement black toner cartridge for use in Toshiba e Studio 350, 352, 450, 452	T3520	11686
	Replacement black toner cartridge for use in Toshiba e Studio 620, 600, 720, 850	T-6000, T6000E	11687
	Replacement black toner cartridge for use in Toshiba e Studio 200L, 202L, 230, 232, 280, 282	T2320, 2340E	11688
	Replacement black toner cartridge for use in Toshiba e Studio 161,	T1620	11689
	Replacement black toner cartridge for use in Toshiba e Studio 55, 65, 80	T6570E	11690
	Replacement black toner cartridge for use in Toshiba e Studio 28, 35, 45	T 3500	11841
	Replacement black toner cartridge for use in Toshiba E Studio T 203L, 233, 283	T2840	12595
	Replacement black toner cartridge for use in Toshiba e Studio 12, 15, 120, 150	T1200	13430
	Replacement black toner cartridge for use in Toshiba e-Studio 202S, 203S		13953
	Replacement black toner cartridge for use in Toshiba e-Studio 242,212, 182, 181	T1810	15869
	Replacement black toner cartridge for use in Toshiba e Studio 205, 255, 305, 355, 455	T4530	15883
	Replacement black toner cartridge for use in Toshiba E studio 195, 225, 243, 245	T2450	17589
	Replacement toner cartridge for use in Toshiba e-Studio 350, 352, 353	T3520	18503
	Replacement toner cartridge Black for use in Toshiba e-Studio 2820, 2830, 2330	TCF28	18504
	Replacement toner cartridge Cyan for use in Toshiba e-Studio 2820, 2830, 2330	TCF28	18505
	Replacement toner cartridge Magenta for use in Toshiba e-Studio 2820, 2830, 2330	TCF28	18506
	Replacement toner cartridge Yellow for use in Toshiba e-Studio 2820, 2830, 2330	TCF28	18507
XEROX®			
	Absolute Black® Replacement toner cartridge for use in Xerox Phaser 6110	106R01274	12764
	Absolute Magenta® Replacement toner cartridge for use in Xerox Phaser 6110	106R01272	12765
	Absolute Yellow® Replacement toner cartridge for use in Xerox Phaser 6110	106R01273	12766
	Absolute Yellow® Replacement toner cartridge for use in Xerox Phaser 6110	106R01273	12766
	Absolute Cyan® Replacement toner cartridge for use in Xerox Phaser 6110	106R01273	12768
	Absolute Black® Replacement toner cartridge for use in Xerox Phaser 6360	106R01221	14491
	Absolute Cyan® Replacement toner cartridge for use in Xerox Phaser 6360	106R01218	14492
	Absolute Magenta® Replacement toner cartridge for use in Xerox Phaser 6360	106R01219	14493
	Absolute Yellow® Replacement toner cartridge for use in Xerox Phaser 6360	106R01220	14494
	Absolute Yellow® Replacement toner cartridge for use in Xerox Phaser 6360	106R01220	14494
	Replacement Black toner cartridge for use in Xerox Phaser 7400	10106R01080	15719
	Replacement Cyan toner cartridge for use in Xerox Phaser 7400	10106R01077	15720
	Replacement Magenta toner cartridge for use in Xerox Phaser 7400	10106R01078	15721
	Replacement Yellow toner cartridge for use in Xerox Phaser 7400	10106R01079	15722
	Replacement toner cartridge for use in Xerox DocuCentre 535, 545, 555	6R1046, 006R010446	15933
	Replacement Black toner cartridge for use in Xerox Phaser 6128 MFP	106R01455	16716
	Replacement Black toner cartridge for use in Xerox Phaser 6128 MFP	106R01455	16716
	Replacement Cyan toner cartridge for use in Xerox Phaser 6128 MFP	106R01452	16717
	Replacement Cyan toner cartridge for use in Xerox Phaser 6128 MFP	106R01452	16717
	Replacement Magenta toner cartridge for use in Xerox Phaser 6128 MFP	106R01453	16718
	Replacement Magenta toner cartridge for use in Xerox Phaser 6128 MFP	106R01453	16718

REPLACEMENT TONER CARTRIDGES

New	Product Description	OEM #	UniNet Part #
	Replacement Yellow toner cartridge for use in Xerox Phaser 6128 MFP	106R01454	16719
	Replacement Black toner cartridge for use in Xerox Phaser 6128 MFP	106R01459	16720
	Replacement Cyan toner cartridge for use in Xerox Phaser 6128 MFP	106R01456	16721
	Replacement Magenta toner cartridge for use in Xerox Phaser 6128 MFP	106R01457	16722
	Replacement Yellow toner cartridge for use in Xerox Phaser 6128 MFP	106R01458	16723
	Replacement toner cartridge for use in Xerox Phaser 4510 (Brasil)		17534
	Replacement Black toner cartridge for use in Xerox Phaser 6140		18041
	Replacement Black toner cartridge for use in Xerox Phaser 6140		18041
	Replacement Cyan toner cartridge for use in Xerox Phaser 6140		18042
	Replacement Magenta toner cartridge for use in Xerox Phaser 6140		18043
	Replacement Yellow toner cartridge for use in Xerox Phaser 6140		18044
	Replacement toner cartridge for use in Xerox 1012	6R257	741
	Replacement toner cartridge for use in Xerox WorkCentre 535, 545	106R367	6445
	Replacement toner cartridge for use in Xerox 5614, 5114, 5113	6R751, 6R752	7724
	Replacement cartridge for use in Xerox WorkCentre Pro 421	106R647	8825
	Replacement toner cartridge for use in Xerox XD 100	6R914	8985
	Replacement drum unit cartridge for use in Xerox XD 100	13R551	8986
	Replacement toner cartridge for use in Xerox WorkCentre 232, 238, 245, 255, 5665, 5675, 5687	006R01146	16253
	Replacement toner cartridge for use in Xerox WorkCentre M 20, C 20	106R01047	16496
	Replacement drum cartridge for use in Xerox WorkCentre M 20, C 20	113R00671	16497